Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > PPLEE /
- > PPLEE CR1023i Vibrating Digital Alarm Clock User Manual

PPLEE CR1023i

PPLEE CR1023i Vibrating Digital Alarm Clock User Manual

Model: CR1023i

1. Introduction

Thank you for choosing the PPLEE CR1023i Vibrating Digital Alarm Clock. This device is designed to provide a reliable and versatile wake-up experience, especially for heavy sleepers and individuals with hearing impairments. It features a large, dimmable LED display, dual alarms, multiple wake-up modes including a powerful bed shaker, a night light, and a convenient USB charging port.



Image 1.1: The PPLEE CR1023i alarm clock, bed shaker, and a smartphone connected for charging.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x PPLEE CR1023i Digital Alarm Clock
- 1 x Wired Bed Shaker
- 1 x Power Adapter
- 1 x Power Cable
- 1 x User Manual

Bed Shaker Placement



Image 2.1: All components included in the PPLEE CR1023i alarm clock package.

3. PRODUCT OVERVIEW

The PPLEE CR1023i features a clear digital display and intuitive controls for easy operation.

3.1. Controls and Display

Familiarize yourself with the buttons and display indicators on your alarm clock. The large LED digits show the current time, and indicators for AM/PM, Alarm 1, and Alarm 2 are present.



Image 3.1: Key features and components of the PPLEE CR1023i alarm clock.

4. INITIAL SETUP

- 1. **Power Connection:** Connect the power cable to the alarm clock and plug the power adapter into a standard electrical outlet. The display will light up.
- 2. **Bed Shaker Connection:** Plug the wired bed shaker into the designated port on the back of the alarm clock.
- 3. **Battery Backup (Optional):** For backup during power outages, insert 2 AAA batteries (not included) into the battery compartment. Note that the battery backup only maintains time settings and alarm functions; the display will not be active.

5. TIME AND DATE SETTINGS

5.1. Setting the Time

- 1. Press and hold the **TIME SET** button (usually located on the back or top) until the hour digits begin to flash
- 2. Use the **HOUR** and **MINUTE** buttons (or +/- buttons) to adjust the hour and minute. Pay attention to the AM/PM indicator.
- 3. Press **TIME SET** again to confirm and exit time setting mode.

5.2. 12H/24H Format and DST

The clock supports both 12-hour and 24-hour time formats, as well as Daylight Saving Time (DST) adjustments.

- To switch between 12H/24H: In normal time display mode, press the12/24H button (or a dedicated button, refer to the clock's labels) to toggle between the formats.
- To activate/deactivate DST: In normal time display mode, press and hold the DST button (or a dedicated button) to adjust the time by one hour forward or backward.



Image 5.1: Examples of 12H, 24H, and DST time display options.

6. ALARM SETTINGS

6.1. Setting Dual Alarms

- 1. Press and hold the **ALARM 1** button until the hour digits for Alarm 1 begin to flash.
- 2. Use the **HOUR** and **MINUTE** buttons (or +/- buttons) to set the desired alarm time.
- 3. Press ALARM 1 again to confirm the time.
- 4. Repeat steps 1-3 for ALARM 2 if a second alarm is needed.

Dual Alarm Clock Set 2 Alarms Based on Schedules











Image 6.1: Setting up two independent alarms for different schedules.

6.2. Wake-up Modes

Choose from three wake-up modes: Sound Only, Vibration Only, or Sound + Vibration.

- 1. After setting an alarm time, press the **ALARM 1/2** button repeatedly to cycle through the wake-up modes. The display will show corresponding icons (bell for sound, wavy lines for vibration, or both).
- 2. Select your preferred mode.



Image 6.2: The three available wake-up solutions: sound, vibration, or both.

6.3. Alarm Volume Adjustment

The alarm volume can be adjusted to 7 levels, from 50dB to 120dB.

- 1. While the alarm is sounding, or during alarm setup, use the **VOLUME** button (or +/- buttons) to adjust the sound level.
- 2. The display will indicate the current volume level (e.g., U01 for lowest, U07 for highest).



Image 6.3: Visual representation of the 7-level volume adjustment for the alarm.

6.4. Disabling an Alarm

To turn off a sounding alarm, press the **ALARM OFF** button. To disable an alarm completely, press the corresponding **ALARM 1/2** button until the alarm icon disappears from the display.

7. SNOOZE FUNCTION

When an alarm sounds, gently tap the large **SNOOZE** button on the top of the clock to activate the snooze function. The alarm will pause for 9 minutes and then sound again. You can repeat this process.



Image 7.1: Activating the 9-minute snooze by touching the top button.

8. BRIGHTNESS ADJUSTMENT

The large LED display features a 0-100% dimmable brightness control.

- 1. Locate the **rotary stepless switch** (often on the side or back of the clock).
- 2. Rotate the switch to adjust the display brightness to your desired level, from completely off to maximum brightness.



Image 8.1: Demonstrating the range of display brightness settings.

9. NIGHT LIGHT FUNCTION

The alarm clock includes a soft rear night light, providing a gentle illumination.

- To turn the night light on or off, tap the SNOOZE button.
- The night light offers a warm and relaxed ambiance, ideal for pre-bedtime or as a subtle light source during the night.



Image 9.1: The night light feature providing soft illumination.

10. USB CHARGING PORT

A built-in USB charging port allows you to charge your devices conveniently while you sleep.

- Locate the USB port on the side or back of the alarm clock.
- Connect your device's USB charging cable to this port.
- The charging function operates independently of the alarm clock's other settings.

11. BED SHAKER PLACEMENT

The wired bed shaker is designed to be placed in various locations to effectively wake heavy sleepers.

- **Under Pillow:** Place the shaker directly under your pillow for direct vibration.
- Under Fitted Sheet: Position the shaker under your fitted sheet, near your head or torso.
- Between Mattress and Box Spring: For a more subtle but still effective vibration, place it between the mattress and box spring.



Image 11.1: Recommended placements for the bed shaker.

12. CARE AND MAINTENANCE

• Cleaning: Wipe the clock and bed shaker with a soft, dry cloth. Do not use abrasive cleaners or

solvents.

- **Placement:** Place the clock on a stable, flat surface. Avoid direct sunlight, extreme temperatures, and high humidity.
- **Power:** Ensure the power adapter and cable are not damaged. Disconnect from power during electrical storms or when not in use for extended periods.

13. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is off.	No power, power outage, or brightness set to minimum.	Check power connection. If using battery backup, display will not show. Adjust brightness.
Alarm does not sound/vibrate.	Alarm not activated, incorrect mode selected, or volume too low.	Ensure alarm is set and activated (icon visible). Verify wake-up mode (sound/vibration). Adjust volume. Check bed shaker connection.
Time is incorrect.	Time not set correctly, or DST needs adjustment.	Re-set the time. Check 12H/24H format. Adjust DST if applicable.
USB charging not working.	Cable issue, device not compatible, or power issue.	Try a different USB cable. Ensure the clock is powered. Check device compatibility.

14. SPECIFICATIONS

Feature	Detail
Brand	PPLEE
Model Number	CR1023i
Display Type	Digital LED
Display Size	7 inch
Wake-up Modes	Sound, Vibration, Sound + Vibration
Alarm Volume	7 levels (50dB to 120dB)
Snooze Duration	9 minutes
Brightness Control	0-100% Dimmable (Rotary Switch)
Night Light	Yes (Soft rear light)
USB Charging Port	Yes (for external devices)
Power Source	Corded Electric
Battery Backup	Yes (2x AAA, not included; for time/alarm memory only)

Feature	Detail
Product Dimensions	1.77"W x 3.03"H (Clock unit)
Item Weight	13.7 ounces
Material	Plastic, Acrylonitrile Butadiene Styrene

15. WARRANTY INFORMATION


This product comes with an extended warranty. For specific details regarding warranty coverage and duration, please refer to the warranty card included in your package or contact customer support.

16. Customer Support

If you encounter any issues or have questions regarding your PPLEE CR1023i alarm clock, please contact our customer support team. You can typically find contact information on the product packaging, the warranty card, or by visiting the official PPLEE store on Amazon: PPLEE Store.

© 2023 PPLEE. All rights reserved.

Related Documents - CR1023i



PPLEE CR1008i Digital LED Alarm Clock with Bed Shaker User Manual

User manual for the PPLEE CR1008i Digital LED Alarm Clock with Bed Shaker, covering setup, operation, features, and warranty information.



PPLEE CR1018i Alarm Clock with USB Charger - User Manual

Detailed user manual for the PPLEE CR1018i alarm clock, featuring dual alarms, USB charging, dimmer, and bed shaker. Learn how to set time, alarms, volume, DST, and use the vibrator function.

