

## PPLEE CR1027

# PPLEE Wireless Vibrating Alarm Clock CR1027 User Manual

Model: CR1027

## 1. INTRODUCTION

---

Thank you for choosing the PPLEE Wireless Vibrating Alarm Clock. This device is designed to provide a reliable and effective wake-up solution, especially for heavy sleepers, individuals with hearing impairment, or those who prefer a silent alarm. It features wireless vibration, dual alarms, multiple awake modes, and a rechargeable battery for portability and convenience.

Please read this manual thoroughly before using the product to ensure proper operation and to maximize its features.



Image 1: Front view of the PPLEE Wireless Vibrating Alarm Clock, displaying the time and alarm indicators.

## 2. PRODUCT OVERVIEW

---

### Package Contents:

- PPLEE Wireless Vibrating Alarm Clock
- USB Type-C Charging Cable
- User Manual

### Device Layout:

# Portable Vibrating Alarm Clock ---for Heavy Sleepers



Image 2: Overview of the alarm clock showing its compact size and key features like Dual Alarms, 12/24 Hour mode, Child Lock, USB Charger, Snooze, Battery Powered, 3 Awake Modes, and 3-Levels Vibration Strength.

The alarm clock features a clear LCD display on the front. Control buttons are located on the top and sides for easy access. A Type-C charging port is located on the side.

## 3. SETUP

### 3.1 Charging the Device

Before first use, fully charge the alarm clock. Connect the provided USB Type-C cable to the charging port on the device and plug the other end into a USB power adapter (not included) or a computer USB port. The

battery indicator on the display will show charging status. A full charge takes approximately 4 hours and provides up to 3 months of operation.



Image 3: The alarm clock connected to a USB charging port, illustrating the Type-C connection.

### 3.2 Setting the Time

1. Press the **TIME/SNOOZE** button to enter time setting mode. The hour digits will flash.
2. Use the **+** and **-** buttons to adjust the hour.
3. Press **TIME/SNOOZE** again to confirm the hour and move to minute setting. The minute digits will flash.
4. Use the **+** and **-** buttons to adjust the minutes.
5. Press **TIME/SNOOZE** to confirm the minutes and exit time setting.

#### 12/24 Hour Format:

While in time setting mode, press the **VIBRATION SETTING** button to switch between 12-hour (AM/PM) and 24-hour formats.

#### Daylight Saving Time (DST) Function:

Press the **+** button on the top of the clock to activate or deactivate the DST function. When activated, the time will automatically advance by one hour.

### 3.3 Setting Alarms (Alarm 1 & Alarm 2)

The clock supports two independent alarms. Follow these steps for each alarm:

1. Press the **ALARM 1** or **ALARM 2** button to select the desired alarm. The alarm time will flash.
2. Use the **+** and **-** buttons to adjust the hour.
3. Press the selected **ALARM** button again to confirm the hour and move to minute setting.
4. Use the **+** and **-** buttons to adjust the minutes.
5. Press the selected **ALARM** button to confirm the minutes and exit alarm time setting.

# Digital Clock with Dual Alarms

## Set different alarm according your habits



Image 4: The alarm clock displaying two different alarm settings, one for a weekday and one for the weekend, illustrating the dual alarm functionality.

### Weekday/Weekend Mode:

After setting the alarm time, use the **WEEKDAY MODE** switch (located on the side/back) to select the alarm schedule:

- **MON-FRI:** Alarm activates Monday to Friday.
- **SAT-SUN:** Alarm activates Saturday and Sunday.
- **MON-SUN:** Alarm activates every day.

### Selecting Awake Modes:



The alarm clock offers three awake modes: vibrate only, ring only, or vibrate + ring. Press the **ALARM MODE** button (usually near the alarm setting buttons) repeatedly to cycle through these options. The corresponding icon will appear on the display.




Image 5: The alarm clock illustrating the three selectable alarm modes: Buzzer Sound & Vibration, Louder Buzzer Sound, and Vibration only.

#### Adjusting Vibration Strength:

The device has 3 levels of vibration strength (Low, Medium, High). Use the **VIBRATION SETTING** switch/button to select your preferred intensity.



Image 6: Close-up of the alarm clock indicating the three vibration strength levels (L, M, H) via a switch.

### Adjusting Alarm Volume:

If you select a ring or vibrate + ring mode, you can adjust the alarm volume. Use the **VOLUME** buttons (often combined with +/-, or a dedicated switch) to set the desired sound level. There are 5 adjustable volume levels.



Image 7: The alarm clock displaying adjustable alarm volume levels and different alarm types (Buzzer & Vibration, Vibrating, Buzzer).

## 4. OPERATING THE ALARM CLOCK

### 4.1 Snooze Function

When an alarm sounds or vibrates, press the large **SNOOZE/TIME** button on the top of the clock to temporarily silence it. The alarm will reactivate after 9 minutes.

# 9 Minutes Snooze



Image 8: The alarm clock with the snooze function activated, indicating a 9-minute delay before the alarm reactivates.

## 4.2 Child Lock Function

To prevent accidental changes to settings or to save battery power, activate the child lock. Locate the **CHILD LOCK** switch (usually on the side or bottom) and slide it to the 'ON' position. This will disable most buttons.





Image 9: The alarm clock demonstrating the child lock feature, showing a small switch to enable or disable it.

### 4.3 Backlight Operation

The LCD display has a built-in backlight. The screen will automatically dim after 30 seconds to save power. Press any button to activate the backlight for clear viewing in low-light conditions.

### 4.4 Optimal Placement for Vibration

For effective vibration, place the alarm clock in one of the following locations:

- Under your pillow.
- Under a fitted sheet.
- Between the mattress and box spring.



Image 10: Illustrations showing recommended placements for the vibrating alarm clock: under a pillow, under a fitted sheet, and between the mattress and box spring.

## 5. MAINTENANCE

### 5.1 Cleaning

Wipe the device with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the surface. Avoid exposing the device to excessive moisture.

### 5.2 Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Recharge the device when the low battery indicator appears. If storing the device for an extended period, charge it fully every few months.

## 6. TROUBLESHOOTING

- **Alarm not activating:**
  - Ensure the alarm is set correctly (time, AM/PM, weekday/weekend mode).
  - Check that the alarm mode (vibrate, ring, or both) is selected.
  - Verify the child lock is not engaged.
  - Ensure the battery is charged.
- **Display is dim or blank:**
  - Press any button to activate the backlight.
  - Charge the device if the battery is low.
- **Device not charging:**
  - Check the USB Type-C cable for damage and ensure it is securely connected.
  - Try a different USB power adapter or port.
- **Time inaccuracy:**
  - Reset the time manually.
  - Ensure the DST function is correctly set for your region.
- **Buttons unresponsive:**
  - Check if the child lock is engaged.
  - Try resetting the device by pressing the**RESET** button (if available, often a small pinhole).

## 7. SPECIFICATIONS

Feature	Description
Brand	PPLEE
Model Number	CR1027
Color	Black
Display Type	LCD Digital
Power Source	Battery Powered (Rechargeable Lithium Ion)
Battery Capacity	3000mAh
Charging Port	USB Type-C
Product Dimensions	3.35"W x 3.35"H (approximate)

Item Weight	1.6 ounces
Alarm Features	Dual Alarms, Weekday/Weekend Modes, 3 Awake Modes (Vibrate Only, Ring Only, Vibrate + Ring), 3 Vibration Strengths, 5 Adjustable Volumes, 9-Minute Snooze
Additional Features	Backlight, 12/24H Mode, DST Function, Child Lock

## 8. WARRANTY AND SUPPORT




### 8.1 Warranty Information




The PPLEE Wireless Vibrating Alarm Clock comes with a **Lifetime Warranty**. This warranty covers manufacturing defects and ensures the product's quality and performance under normal use.

### 8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact PPLEE customer support through the retailer's platform or visit the official PPLEE website for contact information. Please have your model number (CR1027) and purchase details ready when contacting support.

### Related Documents - CR1027

	<p><a href="#">PPLEE CR1018i Alarm Clock with USB Charger - User Manual</a></p> <p>Detailed user manual for the PPLEE CR1018i alarm clock, featuring dual alarms, USB charging, dimmer, and bed shaker. Learn how to set time, alarms, volume, DST, and use the vibrator function.</p>
	<p><a href="#">PPLEE CR1008i Digital LED Alarm Clock with Bed Shaker User Manual</a></p> <p>User manual for the PPLEE CR1008i Digital LED Alarm Clock with Bed Shaker, covering setup, operation, features, and warranty information.</p>
	<p><a href="#">PPLEE CR1018 Mirror Alarm Clock with USB Charger - User Manual</a></p> <p>Comprehensive user manual for the PPLEE CR1018 Mirror Alarm Clock with USB Charger. Learn how to set time, alarms, adjust brightness, use USB charging, and understand its features. Create your perfect sleep environment.</p>

 <p>The image shows the cover of the user manual for the PPLEE CR1008 Digital LED Alarm Clock. It features a digital display showing '10:38' and various icons for alarm, USB, and other functions. The text 'PPLEE' is at the top left, and 'Yisong E-commerce Co., Ltd.' is at the top right.</p>	<p><a href="#">PPLEE CR1008 Digital LED Alarm Clock User Manual</a></p> <p>Comprehensive user manual for the PPLEE CR1008 Digital LED Alarm Clock. This guide details setup, time and alarm setting, night light features, USB charging capabilities, DST adjustments, and warranty information provided by PPLEE and Yisong E-commerce Co.,Ltd.</p>
 <p>The image shows the cover of the user manual for the PPLEE CR1013 Wake-Up Alarm Clock. It features a digital display showing '10:35' and various icons for alarm, sunrise simulation, and other functions. The text 'PPLEE' is at the top left, and 'Yisong E-commerce Co., Ltd.' is at the top right.</p>	<p><a href="#">PPLEE CR1013 Wake-Up Alarm Clock User Manual</a></p> <p>Comprehensive user manual for the PPLEE CR1013 Wake-Up Alarm Clock, detailing setup, alarm settings, sunrise simulation, night light, white noise functions, and USB charging.</p>
 <p>The image shows the cover of the user manual for the PPLEE CR1001E Alarm Clock with USB Charger. It features a digital display showing '12:08' and various icons for alarm, USB, and other functions. The text 'PPLEE' is at the top left, and 'Yisong E-commerce Co., Ltd.' is at the top right.</p>	<p><a href="#">PPLEE CR1001E Alarm Clock with USB Charger - User Manual</a></p> <p>Comprehensive user manual for the PPLEE CR1001E digital alarm clock. Learn how to set time, alarms, use the dimmer, DST, and USB charging features. Features a large LED display and battery backup.</p>