

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ROCAM](#) /

› [ROCAM Loud Dual Alarm Clock with Bed Shaker User Manual](#)

## ROCAM CR1027

# ROCAM Loud Dual Alarm Clock with Bed Shaker User Manual

Model: CR1027 | Brand: ROCAM

## 1. INTRODUCTION

Thank you for choosing the ROCAM Loud Dual Alarm Clock with Bed Shaker. This portable and versatile alarm clock is designed to provide effective wake-up solutions for heavy sleepers, adults, kids, teens, and individuals with hearing impairments. Please read this manual thoroughly to understand all features and ensure optimal performance.

## 2. PACKAGE CONTENTS

Upon opening the package, please verify that all items listed below are included:

- 1 x ROCAM Loud Dual Alarm Clock
- 1 x USB Charging Cable
- 1 x Lanyard
- 1 x User Manual



Figure 2.1: The alarm clock, its packaging, and included lanyard.

### 3. PRODUCT OVERVIEW

---

Familiarize yourself with the various components and controls of your ROCAM alarm clock.

#### 3.1. Dimensions and Portability

# 3000

160 Using Days

mAh

## Large Capacity Rechargeable Battery

Portable / Cordless / Lightweight / Small



Figure 3.1: Front view of the alarm clock with its compact dimensions (3.35 inches x 1.12 inches x 3.35 inches).

The alarm clock features a compact and portable design, making it ideal for travel or discreet placement under a pillow. Its small size (approximately 3.34"W x 1.06"H) and lightweight nature (4.8 ounces) ensure convenience.

### 3.2. Controls and Display

## Dual Alarms 3 Working Modes

Weekday  
(MON-FRI)

Weekend  
(SAT-SUN)

All-7-day  
(MON-SUN)



Figure 3.2: Rear view of the alarm clock, highlighting the control buttons for settings.

The device features a clear digital display and intuitive controls for setting time, alarms, and other functions. Buttons are located on the top and rear for easy access.

## 4. SETUP

Before first use, it is recommended to fully charge the alarm clock.

1. Connect the provided USB charging cable to the clock's charging port.
2. Plug the other end of the cable into a compatible USB power adapter (not included).

3. Allow the device to charge until the battery indicator on the display shows a full charge.

## 5. CHARGING

---

The ROCAM alarm clock is equipped with a built-in 3000mAh rechargeable battery, offering extended standby time and cordless operation.

- A full charge provides ultra-long standby time, eliminating the need for frequent battery replacements.
- The battery indicator on the display will show the current charge level.

## 6. TIME AND DATE SETTING

---

To set the current time and display format:

# You always know what day it is today

MON

**TUE**

WED

THUR

FRI

SAT

SUN



## Customizable Time Format

Figure 6.1: The clock display showing current time, day of the week, and customizable time formats (12H, 24H, DST).

1. Press the **"Time Set"** button (refer to Figure 3.2 for button location).
2. Use the "+" and "-" buttons to adjust the hour. Press **"Time Set"** again to confirm and move to minutes.
3. Repeat for minutes.
4. Continue pressing **"Time Set"** to cycle through setting the year, month, and day.
5. To change the time format (12H/24H/DST), press the dedicated **"Format"** button or cycle through options during time setting. The display will show the current day of the week (MON-SUN).

## 7. ALARM SETTING

The ROCAM alarm clock supports two independent alarms and multiple wake-up modes.

## 7.1. Setting Dual Alarms

You can set two separate alarms, ideal for different schedules or roommates.

1. Press the "**Alarm 1**" or "**Alarm 2**" button to select the alarm you wish to set.
2. Use the "+" and "-" buttons to adjust the desired alarm time.
3. Press the respective alarm button again to confirm the time and move to the alarm working date setting.
4. Choose from: **Weekday (MON-FRI)**, **Weekend (SAT-SUN)**, or **Everyday (MON-SUN)**.
5. If the alarm is not manually stopped, it will ring for 30 minutes and vibrate for 3 minutes.



Figure 7.1: Illustration of dual alarm settings and selectable working modes.

## 7.2. Wake-up Modes and Vibration Levels

The alarm clock offers three distinct wake-up modes and adjustable vibration intensity:

- **Beeps:** Standard audible alarm.
- **Bed Shaker:** Silent vibration for discreet wake-up.
- **Beeps + Shaker:** Combination of audible and vibrating alarm for maximum effectiveness.

The bed shaker function has 3 adjustable shaking levels (Low, Medium, High) to suit individual preferences and sleeping habits.



Figure 7.2: Visual representation of the three available wake-up modes.

## 8. SNOOZE FUNCTION

---

When an alarm sounds, press the "**Snooze**" button to temporarily pause the alarm. The alarm will sound again after 9 minutes. This can be repeated up to 9 times.

## 9. BACKLIGHT AND CHILD LOCK

---

### 9.1. 30-Second Backlight Function

To conserve battery and prevent constant illumination, the display backlight activates for 30 seconds when any button is pressed. This allows you to check the time in the dark without draining power.

### 9.2. Child Lock Function

The child lock feature prevents accidental changes to settings. To activate or deactivate the child lock, slide the dedicated switch to the "**ON**" or "**OFF**" position. When "**ON**", the time display and buttons will be deactivated to prevent unintended adjustments.

# 30S Backlight Function & Child Lock

We can see the clock information even at night and also don't worry about accidental touch



Figure 9.1: Icons representing the 30-second backlight and child lock features.

## 10. MAINTENANCE

To ensure the longevity and proper functioning of your ROCAM alarm clock, follow these maintenance guidelines:

- Clean the device with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Do not expose the clock to extreme temperatures, direct sunlight, or high humidity.
- Keep the device away from water and other liquids.
- Store in a cool, dry place when not in use for extended periods.

## 11. TROUBLESHOOTING

If you encounter any issues with your alarm clock, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Clock not turning on/display blank.	Low battery or child lock activated.	Charge the device fully. Check if the child lock switch is in the "OFF" position.
Alarm not sounding/vibrating.	Alarm not set correctly, volume too low, or wrong wake-up mode selected.	Verify alarm time and working days. Adjust volume. Ensure correct wake-up mode (Beeps, Shaker, or Beeps + Shaker) is selected.
Time/settings change unexpectedly.	Child lock is off, or buttons are accidentally pressed.	Activate the child lock function to prevent accidental touches.
Vibration is too weak/strong.	Vibration level not adjusted.	Adjust the vibration level (Low, Medium, High) using the appropriate controls.

## 12. SPECIFICATIONS

Feature	Detail
Brand	ROCAM
Model Number	CR1027
Color	Black
Display Type	Digital
Power Source	Battery Powered (Rechargeable)
Battery Capacity	3000mAh Lithium Polymer
Product Dimensions	3.34"W x 1.06"H (approx.)
Item Weight	4.8 ounces (0.3 Pounds)
Special Features	Silent Clock, Cordless, Battery Indicator, Adjustable Volume, Dual Alarms, Bed Shaker, DST, Weekday/Weekend Modes, 30S Backlight, Child Lock
Material	Plastic

## 13. WARRANTY AND SUPPORT

ROCAM provides an **18-month warranty** for this product. If you encounter any issues or require assistance, please do not hesitate to contact our customer support team. Refer to the contact information provided on the product packaging or the official ROCAM website for expert assistance.

For further support, you may visit the [ROCAM Store on Amazon](#).

