

Yoidesu Yoidesuke1y3f5x9v

Yoidesu 1080P Wireless Video Doorbell Camera User Manual

Model: Yoidesuke1y3f5x9v

Brand: Yoidesu

1. INTRODUCTION

Thank you for choosing the Yoidesu 1080P Wireless Video Doorbell Camera. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before installation and use, and retain it for future reference.

Important Safety Information

- Ensure the device is installed in a location protected from extreme weather conditions.
- Use only the specified charging cable and power adapter.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Keep the device away from water and high humidity.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Video Doorbell Unit
- Wireless Chime Unit
- Mounting Bracket
- USB Charging Cable
- Mounting Screws and Wall Anchors
- User Manual (this document)



Image: All components included in the Yoidesu Video Doorbell package.

3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your Yoidesu Video Doorbell Camera.

Doorbell Unit

- **HD Camera Lens:** Captures 1080P video with a wide-angle view.
- **Infrared Sensors:** Enables automatic night vision.
- **Microphone:** For two-way audio communication.
- **Speaker:** For two-way audio communication and alerts.
- **Doorbell Button:** Activates the doorbell and sends notifications.
- **Status Indicator Light:** Shows device status (e.g., charging, connected, recording).
- **USB Charging Port:** For recharging the internal battery.

Wireless Chime Unit

- **Speaker:** Emits chime sound when the doorbell is pressed.
- **Volume Control:** Adjusts the chime volume.
- **Pairing Button:** For connecting with the doorbell unit.



Image: Detailed view of the Yoidesu Video Doorbell Camera.

4. SETUP AND INSTALLATION

Follow these steps to set up and install your video doorbell.

4.1 Initial Charging

1. Connect the doorbell unit to a USB power adapter (not included) using the provided USB charging cable.
2. Allow the doorbell to charge fully before first use. The status indicator light will change when charging is complete.

4.2 App Download and Account Creation

1. Download the companion mobile application from your device's app store (e.g., App Store for iOS, Google Play Store for Android). Search for "Yoidesu Smart" or refer to the QR code on the packaging.
2. Open the app and follow the on-screen instructions to create a new account or log in if you already have one.

4.3 Device Pairing

1. Ensure your smartphone is connected to a 2.4GHz Wi-Fi network.
2. In the app, select "Add Device" or the '+' icon.
3. Follow the app's instructions to put the doorbell into pairing mode (usually by pressing and holding the doorbell button for a few seconds until the indicator light flashes).
4. Scan the QR code on the doorbell unit or manually select the device type in the app.
5. Enter your Wi-Fi network password when prompted.
6. Once connected, the app will confirm successful pairing.



Image: Mobile app connection process with the doorbell.

4.4 Physical Installation

1. Choose a suitable location near your front door, ensuring a clear view and good Wi-Fi signal.
2. Mark the drilling points using the mounting bracket as a template.
3. Drill holes and insert wall anchors if installing on masonry or drywall.
4. Secure the mounting bracket to the wall with the provided screws.
5. Attach the doorbell unit to the mounting bracket, ensuring it clicks securely into place.



Image: Example of the doorbell installed and in use.

5. OPERATING INSTRUCTIONS

Learn how to use the key features of your Yoidesu Video Doorbell Camera.

5.1 Remote Video Call

- When a visitor presses the doorbell button, your paired smartphone will receive an instant notification.
- Tap the notification to open the app and initiate a live video call with the visitor at your door.
- You can see and speak to the visitor in real-time from anywhere with an internet connection.




Image: Remote video call functionality via the mobile app.

5.2 Two-Way Voice Communication

- During a live video call, use the microphone icon in the app to enable two-way audio.
- Speak into your phone, and your voice will be transmitted through the doorbell's speaker.
- The doorbell's microphone will capture the visitor's voice, allowing for clear conversation.
- Adjust the volume settings within the app as needed.

5.3 HD Video Recording and Live View

- The doorbell records video in 1080P resolution, providing clear and detailed footage.
- Access the live view at any time through the app to monitor your doorstep.
- Recorded events can be reviewed in the app's history or cloud storage (if subscribed).

5.4 Infrared Night Vision

- The doorbell automatically switches to infrared night vision mode in low-light conditions.
- This feature ensures clear visibility and recording even in complete darkness.




Image: Demonstration of the doorbell's infrared night vision.

5.5 Wide Angle Lens

- The wide-angle lens provides an expansive view of your doorstep, minimizing blind spots.
- This allows you to see multiple visitors or packages clearly.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your doorbell.

6.1 Cleaning the Lens

- Gently wipe the camera lens with a soft, lint-free cloth to remove dust or smudges.
- Avoid using harsh chemicals or abrasive materials that could scratch the lens.

6.2 Battery Care

- Recharge the doorbell unit when the battery low indicator appears in the app or on the device.
- Avoid prolonged exposure to extreme temperatures, which can affect battery life.

7. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Doorbell not connecting to Wi-Fi	Incorrect Wi-Fi password, weak signal, 5GHz network.	Ensure correct 2.4GHz Wi-Fi password. Move doorbell closer to router. Reset doorbell and try pairing again.
No notification when doorbell is pressed	App notifications disabled, doorbell offline, phone in Do Not Disturb mode.	Check app notification settings. Ensure doorbell is online. Disable Do Not Disturb on your phone.
Poor video quality	Weak Wi-Fi signal, dirty lens.	Improve Wi-Fi signal strength. Clean the camera lens.
Two-way audio not working	Microphone/speaker muted in app, low volume.	Check app settings to ensure microphone and speaker are enabled and volume is adequate.
Chime not ringing	Chime not paired, low battery (if applicable), volume too low.	Ensure chime is paired with doorbell. Check chime power/battery. Increase chime volume.

If the problem persists, please contact Yoidesu customer support for further assistance.

8. SPECIFICATIONS

Technical details of the Yoidesu 1080P Wireless Video Doorbell Camera:

- **Brand:** Yoidesu
- **Model Name:** Yoidesuke1y3f5x9v
- **Connectivity Technology:** Wireless (Wi-Fi 2.4GHz)
- **Video Resolution:** 1080P HD

- **Lens:** Wide Angle
- **Night Vision:** Infrared
- **Audio:** Two-Way Voice Communication
- **Power:** Rechargeable Battery (USB charged)
- **ASIN:** B0CM9L84W

9. WARRANTY AND SUPPORT

Yoidesu products are designed for reliability and performance. This product comes with a standard manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your package or visit the official Yoidesu website.

Customer Support

If you have any questions, require technical assistance, or need to report an issue, please contact our customer support team:

- **Email:** support@yoidesu.com (Example email, please refer to actual product documentation for correct contact information)
- **Website:** [Visit the Yoidesu Store on Amazon](#)

© 2023 Yoidesu. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

