

manuals.plus /

- › [SMAEL](#) /
- › [SMAEL 8089 Sport Watch Instruction Manual](#)

**SMAEL 8089**

# SMAEL 8089 Sport Watch Instruction Manual

Model: SL-8089

## INTRODUCTION

---

Thank you for choosing the SMAEL 8089 Sport Watch. This watch is designed for durability and functionality, featuring a dual time display, LED backlight, stopwatch, alarm, and calendar functions. It is suitable for various outdoor activities and daily wear. Please read this manual carefully to understand the watch's features and ensure proper operation and maintenance.



Image: Front view of the SMAEL 8089 Sport Watch, showcasing its robust design and digital-analog display.

## SETUP AND INITIAL CONFIGURATION

Before using your watch, please familiarize yourself with the buttons and their functions:

- **LIGHT Button:** Activates the LED backlight.
- **MODE Button:** Cycles through different modes (Time, Alarm, Stopwatch).
- **START Button:** Used to start/stop functions in Stopwatch mode, or adjust values in setting modes.

- **RESET Button:** Used to reset values in Stopwatch mode, or select items in setting modes.
- **Crown:** Used to set the analog time.



Image: Close-up view of the SMAEL 8089 watch, highlighting the function buttons on the side of the case.

## 1. Setting Analog Time

1. Pull out the crown located on the right side of the watch case.
2. Rotate the crown to adjust the analog hands to the correct time.
3. Push the crown back in to secure the time setting.

## 2. Setting Digital Time and Date

1. Press the **MODE** button repeatedly until the digital time display starts flashing, indicating it is in setting mode.
2. Use the **RESET** button to cycle through the settings (seconds, hour, minute, month, date, day of week, 12/24-hour format).
3. Use the **START** button to adjust the selected value.
4. Once all settings are correct, press the **MODE** button again to exit the setting mode.

### 3. Setting the Alarm

1. Press the **MODE** button until you reach the Alarm mode (usually indicated by 'AL' or a bell icon).
2. Press the **RESET** button to select the hour or minute to set.
3. Use the **START** button to adjust the alarm hour and minute.
4. Press the **MODE** button to confirm and exit.
5. To activate/deactivate the alarm, press the **START** button while in Alarm mode. An alarm icon will appear/disappear.

### 4. Using the Stopwatch

1. Press the **MODE** button until you reach the Stopwatch mode (usually indicated by 'ST' or 'CHRONO').
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to clear the stopwatch to zero.

### 5. Activating the LED Backlight

Press the **LIGHT** button to illuminate the digital display for easy reading in low-light conditions. The backlight will remain active for a few seconds.



Image: The SMAEL 8089 watch with its LED backlight activated, showing clear visibility of the digital display in the dark.

Your browser does not support the video tag.

Video: A short tutorial demonstrating how to wear the SMAEL watch and utilize its various functions.

## OPERATING GUIDELINES

---

### Water Resistance

The SMAEL 8089 watch is rated for 30 meters (3ATM) water resistance. This means it is suitable for daily use, splashes, rain, and brief immersion in water, such as swimming. However, it is **not recommended** for diving, snorkeling, or high-pressure water activities. **Do not press any buttons underwater**, as this can compromise the water seal and cause damage.

Your browser does not support the video tag.

Video: Demonstration of the SMAEL watch's water resistance capabilities, showing it submerged in water.



Image: The SMAEL 8089 watch comfortably worn on a person's wrist, demonstrating its fit and appearance during use.

## MAINTENANCE

---

### Cleaning Your Watch

To maintain the appearance and longevity of your watch, wipe it regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive cleaners.

### Battery Replacement

The SMAEL 8089 watch is powered by a long-lasting battery. When the display dims or functions become erratic, it may be time for a battery replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.

### Storage

When not in use, store your watch in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. This helps preserve the battery life and integrity of the watch components.

## TROUBLESHOOTING

- **Watch not displaying time or functions:** Check if the battery needs replacement. If recently replaced, ensure it was installed correctly.
- **Digital display is dim or blank:** This usually indicates a low battery. Replace the battery.
- **Buttons are unresponsive:** Ensure no debris is lodged around the buttons. If the issue persists, a professional inspection may be required.
- **Water inside the watch:** Immediately stop using the watch and seek professional repair. Do not attempt to open the watch yourself, as this will void the warranty and likely cause further damage.
- **Analog hands not moving:** Check if the crown is pushed in completely. If it is, the watch may require professional service.

## SPECIFICATIONS

Feature	Detail
Model Number	SL-8089
Display Type	Analog-Digital
Movement Type	Quartz
Water Resistance	30M (3ATM)
Case Material	Plastic
Band Material	Rubber (PU)
Case Diameter	52 Millimeters
Band Width	22 Millimeters
Case Thickness	18 Millimeters
Crystal Type	Mineral Glass
Additional Features	Alarm, LED Backlight, Stopwatch, Calendar, Dual Time Display
Clasp Type	Hook Buckle

## WARRANTY AND SUPPORT

The SMAEL 8089 Sport Watch comes with a Lifetime Warranty, as per manufacturer specifications. For warranty claims, technical support, or service inquiries, please refer to the contact information provided with your purchase or visit the official SMAEL website. Please retain your proof of purchase for warranty validation.

