

BLACK+DECKER BXAF5000E

Black+Decker BXAF5000E 5L Air Fryer User Manual

Model: BXAF5000E

1. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.

2. PRODUCT OVERVIEW

The Black+Decker BXAF5000E is a 5-liter oil-free air fryer designed for frying, roasting, baking, reheating, and preparing various types of food. It features a powerful 1450W heating element for fast and even cooking, and a high-speed hot air circulation system that reduces fat content by up to 99% compared to traditional frying.

Key features include:

- **High Power and Large Capacity:** With 1450W of power and a 5-liter capacity, it can cook up to 1200 grams of food quickly and efficiently, ideal for families.
- **99% Fat Reduction:** Utilizes hot air circulation technology for healthier cooking without added oil.
- **Eight Preset Programs:** Enjoy eight automatic programs for various foods like fries, vegetables, meats, fish, and even desserts.
- **Easy to Use and Clean:** Features a non-stick basket that prevents food from sticking, simplifying cleanup. An audible signal indicates when cooking is complete.
- **Compact Design:** Despite its large capacity, the air fryer has compact dimensions (33.8 x 31.7 x 37.4 cm), fitting easily into any kitchen space.



Image 1: Front view of the Black+Decker BXAF5000E Air Fryer, showcasing its digital display and control panel.

3. PRODUCT COMPONENTS

The Black+Decker BXAF5000E Air Fryer consists of the following main components:

- **Main Unit:** Houses the heating element, fan, and control panel.
- **Removable Frying Basket:** The primary cooking container where food is placed.
- **Crisper Plate:** Sits inside the frying basket to allow air circulation around food and drain excess fat.
- **Handle:** For safely pulling out and inserting the frying basket.



Image 2: The Black+Decker BXAF5000E Air Fryer with its non-stick frying basket pulled out, showing the internal crisper plate.

4. SETUP AND BEFORE FIRST USE

1. **Unpacking:** Carefully remove all packaging materials from the air fryer. Ensure all components are present and undamaged.
2. **Cleaning:** Before first use, clean the frying basket and crisper plate with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth. Do not immerse

the main unit in water.

3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space at the back and sides, and 10 cm (4 inches) above the appliance to allow for proper ventilation.
4. **Initial Run (Optional):** For the first use, it is recommended to run the air fryer empty for about 10 minutes at 180°C (350°F) to burn off any manufacturing residues. A slight odor may be present, which is normal. Allow the appliance to cool completely afterward.

5. OPERATING INSTRUCTIONS

Basic Operation

1. **Prepare Food:** Place the crisper plate into the frying basket. Place your ingredients into the frying basket. Do not overfill the basket.
2. **Insert Basket:** Slide the frying basket back into the air fryer until it clicks into place.
3. **Power On:** Plug the appliance into a grounded wall outlet. The power indicator will light up. Press the power button to turn on the display.
4. **Set Temperature and Time:** Use the temperature and time control buttons (usually '+' and '-' symbols or dedicated icons) to adjust the desired cooking temperature and time. The digital display will show the current settings.
5. **Start Cooking:** Press the start button (often the power button again or a dedicated play/pause icon) to begin the cooking process.
6. **Shake Basket (Optional):** For even cooking, especially with smaller items like fries, pull out the basket halfway through the cooking time and shake it gently. Then slide it back in. The air fryer will resume cooking automatically.
7. **Cooking Complete:** The air fryer will beep when the set cooking time has elapsed. Carefully pull out the basket and transfer the cooked food to a plate.

Using Preset Programs

The Black+Decker BXAF5000E features eight preset programs for common dishes. To use a preset program:

1. After turning on the display, press the 'Mode' or 'Program' button (represented by an icon, e.g., a chef's hat or specific food icons) to cycle through the available preset programs.
2. Each program has a pre-set temperature and time optimized for specific foods (e.g., fries, chicken, fish, vegetables, desserts).
3. Once you select a program, you can still manually adjust the temperature and time if desired before pressing the start button.
4. Press the start button to begin cooking.

1450W



Image 3: The Black+Decker BXA5000E Air Fryer positioned in a kitchen, surrounded by various cooked foods, illustrating its use for healthy meal preparation.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Before Cleaning:** Always unplug the air fryer and allow it to cool down completely before cleaning.
2. **Frying Basket and Crisper Plate:** These parts are non-stick and can be cleaned with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak them in hot water for about 10 minutes before cleaning. They may also be dishwasher safe (refer to specific product labeling if available).
3. **Interior of the Appliance:** Wipe the interior with a damp cloth and a mild detergent. Avoid using abrasive cleaners or metal scouring pads.
4. **Exterior of the Appliance:** Wipe the exterior with a damp cloth. Do not use harsh chemicals or abrasive materials.
5. **Heating Element:** If necessary, gently clean the heating element with a cleaning brush to remove any food residue.
6. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.



Image 4: A top-down view of the Black+Decker BXA5000E Air Fryer's non-stick basket and crisper plate, highlighting its easy-to-clean design.

7. TROUBLESHOOTING

If you encounter issues with your air fryer, consult the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet not working; basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push the frying basket completely into the appliance.
Food is not cooked evenly.	Basket is overcrowded; food not shaken during cooking; incorrect temperature/time.	Cook food in smaller batches. Shake the basket halfway through cooking. Adjust temperature and time as needed.

Problem	Possible Cause	Solution
White smoke comes from the appliance.	Fat residue from previous use; cooking fatty food; crisper plate not clean.	Clean the basket and crisper plate thoroughly. Remove excess oil from food before air frying.
Food is not crispy.	Too much moisture in food; insufficient cooking time/temperature.	Pat food dry before cooking. Increase cooking time or temperature. A light coating of oil can help.

8. SPECIFICATIONS

Technical details for the Black+Decker BXAF5000E Air Fryer:

Feature	Detail
Brand	BLACK+DECKER
Model Number	BXAF5000E (ES9730080B)
Color	Black
Capacity	5 Liters
Power	1450 Watts
Material	Plastic
Item Weight	6.9 Kilograms
Dimensions (L x W x H)	33.8 x 31.7 x 37.4 cm
Control Method	Touch



Image 5: The Black+Decker BXA5000E Air Fryer with its length, width, and height dimensions clearly indicated.

9. WARRANTY AND SUPPORT

This Black+Decker appliance comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or to inquire about replacement parts, please contact Black+Decker customer service. Contact information can typically be found in the warranty documentation or on the official Black+Decker website.

Please have your model number (BXA5000E) and proof of purchase ready when contacting support.