

[Manuals.plus](#) /

> [TOSHIBA](#) /

> TOSHIBA Rice Cooker RC-5DSTUS(H) User Manual

TOSHIBA RC-5DSTUS(H)

TOSHIBA Rice Cooker User Manual

Model: RC-5DSTUS(H)

1. PRODUCT OVERVIEW

The TOSHIBA RC-5DSTUS(H) Rice Cooker is a compact and versatile kitchen appliance designed for efficient cooking of various grains and dishes. Featuring an LCD display and 8 programmable functions, it simplifies meal preparation for individuals or small families.



Figure 1.1: The TOSHIBA RC-5DSTUS(H) Rice Cooker, showcasing its sleek grey design, control panel, and included non-stick inner pot with measuring cup and serving utensils.

This 3-cup uncooked capacity rice cooker is equipped with advanced fuzzy logic technology to ensure perfectly cooked rice every time by sensing moisture levels and adjusting cooking parameters. Its non-stick inner pot, infused with Binchotan carbon material, promotes even heating and easy cleaning.

2. COMPONENTS AND ACCESSORIES

Before first use, ensure all components are present and free from damage. The package includes:

- **Rice Cooker Unit:** The main appliance with control panel and lid.
- **Non-Stick Inner Pot:** Removable pot for cooking, featuring measurement markings for various rice types and porridge.
- **Measuring Cup:** Standard rice measuring cup for accurate ingredient proportions.
- **Rice Spatula:** Designed for serving cooked rice without damaging the non-stick surface.
- **Soup Ladle:** For serving soups or porridges.
- **Power Cord:** Detachable power cord for connecting the unit to an electrical outlet.

Even Heating Perfect Rice

The Inner Pot with Binchotan Charcoal
to Provides Even Heating




Figure 2.1: Detailed view of the inner pot's construction, highlighting its non-stick coating with Binchotan charcoal, heat-transmitting aluminum alloy, and durable matte finish for even heating.

3. SETUP

Follow these steps to set up your rice cooker for the first time:

1. **Unpack:** Carefully remove all components and packaging materials from the box.
2. **Clean:** Wash the inner pot, measuring cup, rice spatula, and soup ladle with warm, soapy water. Rinse

thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.

3. **Placement:** Place the rice cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
4. **Insert Inner Pot:** Place the cleaned non-stick inner pot securely into the main rice cooker unit.
5. **Connect Power:** Insert the detachable power cord into the power inlet on the side of the rice cooker, then plug the other end into a standard 100V electrical outlet.

4. OPERATING INSTRUCTIONS

The TOSHIBA Rice Cooker offers 8 cooking functions and convenient timer settings.

4.1. Cooking Functions

To select a cooking function, press the "MENU" button repeatedly until the desired function is highlighted on the LCD display. Then, press "START".

Multi-functionality

8 Functions to Enhance Your Cooking Options



Figure 4.1: The intuitive control panel with its LCD display and clearly labeled buttons for selecting various cooking modes.

Table 4.1: Overview of Cooking Functions

Function	Description	Recommended Capacity (Uncooked)
White Rice	For perfectly fluffy white rice.	0.5 - 3 cups

Function	Description	Recommended Capacity (Uncooked)
Quick Cook	Faster cooking for white rice/oatmeal (approx. 30 minutes).	0.5 - 3 cups
Brown Rice	Optimized for cooking brown rice.	0.5 - 3 cups
Mixed Grain	Ideal for cooking various mixed grains.	0.5 - 3 cups
Slow Cook	For stews, soups, and other slow-cooked dishes.	Varies by recipe
Porridge	Pre-set for creamy porridge.	0.25 - 0.5 cups
Cake	Bake simple cakes directly in the inner pot.	Varies by recipe
Egg	Boil eggs to desired consistency.	Varies by recipe

4.2. Delay Timer

The rice cooker features two delay timers (Timer 1 and Timer 2) allowing you to schedule cooking up to 24 hours in advance. This ensures your meal is ready exactly when you need it.

1. Add ingredients to the inner pot.
2. Press the "TIMER 1/2" button to select either Timer 1 or Timer 2.
3. Use the "+" and "-" buttons to adjust the desired completion time.
4. Press "START" to confirm. The cooker will begin cooking at the appropriate time to finish at your set time.



Programmable Timers

Enjoying the Delicious Dishes at Your Desired Time

TIME 1

7:00 am

Set a timer

7:00 pm

Arrive at your home and enjoy your meal



TIME 2

8:00 pm

Set a timer

8:00 am

Breakfast doesn't have to wait



Figure 4.2: Illustration of the programmable timer feature, enabling users to set cooking completion times up to 24 hours in advance.

4.3. Keep Warm / Reheat Function

After a cooking cycle is complete, the rice cooker automatically switches to the "Keep Warm" mode, maintaining the food at an optimal serving temperature for up to 24 hours. To reheat previously cooked food, press the "KEEP WARM REHEAT" button.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your rice cooker.

- **Inner Pot:** The non-stick inner pot is easy to clean. Wash with warm, soapy water and a soft sponge. Avoid abrasive cleaners or metal scouring pads to prevent damage to the non-stick coating. Rinse and dry thoroughly.
- **Inner Lid:** The inner lid is detachable for easy cleaning. Gently pull it off, wash with warm, soapy water, rinse, and dry. Reattach it securely after cleaning.
- **Anti-Overflow Steam Valve:** This valve can be removed for cleaning. Ensure it is clear of any food debris to prevent blockages.
- **Exterior:** Wipe the exterior of the rice cooker unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
- **Storage:** Ensure the unit is completely dry before storing. Store in a cool, dry place.



Figure 5.1: Key features for easy maintenance, including the detachable inner lid, anti-overflow steam valve, and detachable power cord, contributing to the unit's ease of storage.

6. TROUBLESHOOTING

If you encounter any issues with your rice cooker, refer to the table below for common problems and solutions.

Table 6.1: Common Troubleshooting Guide

Problem	Possible Cause	Solution
Rice is too hard/dry	Insufficient water; incorrect rice-to-water ratio; lid not properly closed.	Add more water according to markings; ensure lid is securely closed.
Rice is too soft/mushy	Too much water; rice not rinsed properly.	Reduce water slightly next time; rinse rice thoroughly before cooking.
Cooker does not turn on	Power cord not properly connected; no power from outlet.	Check power cord connection; test outlet with another appliance.
Steam leaking from lid	Lid not properly closed; inner lid/steam valve not installed correctly or dirty.	Ensure lid is securely latched; clean and re-install inner lid and steam valve.
Unusual odor during cooking	First-time use (normal); food residue on heating plate.	Initial odors will dissipate; clean heating plate thoroughly.

If the problem persists after trying these solutions, please contact TOSHIBA customer support.

7. SPECIFICATIONS

- **Brand:** TOSHIBA
- **Model Name:** TRCS02
- **Model Number:** RC-5DSTUS(H)
- **Capacity:** 3 Cups (Uncooked)
- **Product Dimensions:** 9"D x 11"W x 8"H
- **Item Weight:** 6.6 Pounds
- **Power Source:** Corded Electric
- **Voltage:** 100 Volts
- **Wattage:** 400 watts
- **Material:** Stainless Steel (exterior), Aluminum (Lid Material), Non-Stick (Inner Pot)
- **Special Features:** Advanced Fuzzy Logic, Automatic Keep Warm, Non-Stick, One-Touch Operation, Portable
- **UPC:** 840296506875
- **Manufacture Year:** 2023

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official TOSHIBA Kitchen Appliances website. Keep your purchase receipt as proof of purchase for any warranty claims.

Online Support: [Visit the TOSHIBA Store on Amazon](#)