



Manuals.plus /

› FREEFISH /

› FREEFISH Multi-Function Bluetooth Speaker Alarm Clock - Instruction Manual

FREEFISH Multi-Function Alarm Clock Speaker

FREEFISH Multi-Function Bluetooth Speaker Alarm Clock

Instruction Manual

INTRODUCTION

Thank you for purchasing the FREEFISH Multi-Function Bluetooth Speaker Alarm Clock. This device integrates a Bluetooth speaker, fast wireless charger, FM radio, digital alarm clock, adjustable LED night light, and a phone stand into one compact unit. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your product.

PRODUCT OVERVIEW

The FREEFISH Multi-Function Bluetooth Speaker Alarm Clock is designed to simplify your daily routine by combining essential features in a single device. It offers clear audio, convenient charging, and customizable lighting to enhance your bedroom, office, or living space.

Multi-Functional Speakers



Image Description: A detailed diagram of the FREEFISH Multi-Function Bluetooth Speaker Alarm Clock, highlighting its various components. Labels point to the Mobile Phone Wireless Charging Area, LED Light Bar, Phone Stand, Bluetooth Speaker, FM Radio, Alarm Clock, Adaptor, and Type C Data Cable.

PACKAGE CONTENTS

- FREEFISH Multi-Function Bluetooth Speaker Alarm Clock
- Power Adapter
- USB Type-C Charging Cable
- Instruction Manual (this document)

CONTROLS AND INDICATORS

Familiarize yourself with the device's controls for easy operation.



Image Description: A top-down view of the FREEFISH Multi-Function Bluetooth Speaker Alarm Clock, showing a smartphone placed in the integrated phone holder. The control buttons are visible on the top surface, including 'MODE', 'SWITCH', 'BT', 'FM', and volume/track controls. The digital time display shows '9:00'.

- **MODE Button:** Switches between Bluetooth, FM Radio, and Clock modes.
- **SWITCH Button:** Power on/off, or short press to change display format (e.g., 12/24 hour).
- **BT Button:** Activates Bluetooth pairing mode.
- **FM Button:** Activates FM radio mode.
- **+/- Buttons:** Adjust volume, navigate radio stations, or set time/alarm.
- **SNOOZE / Light Button:** Activates snooze during an alarm, or adjusts night light brightness.
- **Wireless Charging Pad:** Located on the top surface for compatible devices.
- **LED Display:** Shows time, mode, and other relevant information.

SETUP

1. Power Connection

1. Connect the provided USB Type-C cable to the DC input port on the back of the speaker.
2. Plug the other end of the cable into the power adapter.
3. Plug the power adapter into a standard wall outlet. The device will power on automatically, and the LED display will illuminate.

2. Initial Time and Alarm Setting

- **Setting Time:** In clock mode, long press the 'MODE' button until the hour digits flash. Use the '+/-' buttons to adjust the hour. Press 'MODE' again to set minutes, then use '+/-' buttons. Press 'MODE' a third time to confirm.

- **Setting Alarm:** In clock mode, short press the 'ALARM' button (if available, otherwise refer to 'MODE' button for alarm setting). The alarm icon will appear. Long press the 'ALARM' button until the hour digits flash. Use '+'/'-' buttons to set the alarm hour, then minutes. Press 'ALARM' again to confirm.
- **12/24 Hour Format:** Short press the 'SWITCH' button to toggle between 12-hour and 24-hour time display.

OPERATING INSTRUCTIONS

1. Bluetooth Speaker Mode



Image Description: The FREEFISH Multi-Function Bluetooth Speaker Alarm Clock on a wooden table, with a smartphone displaying music playback. The speaker's digital display shows '03:18' and the 'BT' indicator is lit, signifying Bluetooth mode. Text highlights '5.0 Stereo Surround Bluetooth Speaker' and 'Built-in 2500 mAh battery for long playback life'.

1. Press the 'MODE' button until 'BT' appears on the LED display, indicating Bluetooth mode. The device will enter pairing mode.
2. On your smartphone or other Bluetooth-enabled device, search for 'FREEFISH Speaker' in the Bluetooth settings.
3. Select the device to pair. A confirmation sound will indicate successful pairing.

4. You can now play audio from your device through the speaker. Use the '+/-' buttons on the speaker or your connected device to adjust volume.

2. FM Radio Mode



Image Description: A woman is shown relaxing on a sofa, listening to the FM radio function of the FREEFISH Multi-Function Bluetooth Speaker Alarm Clock. The speaker's display shows '15:38' and the 'FM' indicator. Visual cues indicate various FM frequencies and volume levels.

1. Press the 'MODE' button until 'FM' appears on the LED display.
2. Long press the 'FM' button to automatically scan and save available radio stations.
3. Short press the '+/-' buttons to switch between saved stations.
4. Use the volume controls to adjust the audio level.

3. Wireless Charging

Fast Charge Your Phone



Image Description: A smartphone is shown wirelessly charging on the top surface of the FREEFISH Multi-Function Bluetooth Speaker Alarm Clock. The phone's screen displays a charging animation, and the speaker's digital display shows '09:41'. Text highlights '15W Fast Charge Your Phone' and lists compatible iPhone, Samsung, and AirPods models.

1. Ensure the speaker is connected to power.
2. Place your Qi-compatible smartphone or other device (e.g., AirPods) on the wireless charging pad located on the top surface of the speaker.
3. Ensure the device is centered on the charging pad for optimal connection. The charging indicator on the speaker's display will illuminate, and your device will show a charging status.
4. The speaker supports 15W fast wireless charging for compatible devices.

4. Alarm Clock and Snooze Function

Alarm Clock Wakes You Up Every Morning



Image Description: A man is shown waking up in bed, reaching for the FREEFISH Multi-Function Bluetooth Speaker Alarm Clock. The speaker's digital display shows '08:30' and an alarm icon. Text indicates 'Snooze for 5 min up to 4 times' and '12/24 hour time display switchable'.

1. **Setting Alarm:** Follow the instructions in the 'Initial Time and Alarm Setting' section.
2. **Activating Snooze:** When the alarm sounds, short press the 'SNOOZE / Light' button to activate the snooze function. The alarm will pause for 5 minutes and then sound again. This can be repeated up to 4 times.
3. **Disabling Alarm:** To turn off the alarm completely, press any other button (e.g., 'MODE', 'BT', 'FM') during the alarm or snooze period.

5. Night Light Function

Night Light

Adjustable nightlight and time brightness




Image Description: A woman is shown sleeping peacefully in a bedroom, with the FREEFISH Multi-Function Bluetooth Speaker Alarm Clock on her nightstand. The image illustrates the adjustable night light feature, showing four different brightness levels (0%, 30%, 70%, 100%) of the integrated LED light bar.

1. The night light is integrated into the handle/light bar of the speaker.
2. Touch the 'SNOOZE / Light' button (or the designated touch area on the light bar) to cycle through the brightness levels: 30%, 70%, 100%, and Off.
3. Select the desired brightness for reading, ambient lighting, or sleeping.

6. Phone Holder

The integrated phone holder allows you to conveniently place your smartphone upright while charging or watching content. Simply place your phone into the groove on the top surface of the speaker.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight and extreme temperatures.

- **Avoid Water:** This device is not waterproof. Keep it away from water and high humidity.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Not connected to power, or power adapter/cable faulty.	Ensure the power adapter is securely plugged into the wall outlet and the speaker. Try a different outlet or cable if available.
Bluetooth not connecting.	Speaker not in pairing mode, or device too far.	Ensure the speaker is in Bluetooth mode ('BT' displayed). Move your device closer to the speaker. Forget the device in your phone's Bluetooth settings and try pairing again.
Wireless charging not working.	Device not Qi-compatible, not properly aligned, or foreign objects present.	Ensure your device supports Qi wireless charging. Re-position your device on the charging pad, ensuring it is centered. Remove any metal objects or thick cases.
FM radio static or poor reception.	Weak signal, interference.	Try repositioning the speaker. Perform an auto-scan for stations again. Avoid placing near other electronic devices that may cause interference.
Alarm does not sound.	Alarm not set or volume too low.	Verify the alarm time is correctly set and activated. Ensure the speaker volume is not set to zero.

SPECIFICATIONS

- **Brand:** FREEFISH
- **Model:** Multi-Function Alarm Clock Speaker
- **Display Type:** Digital
- **Bluetooth Version:** 5.0
- **Wireless Charging Output:** 15W (Max)
- **Power Source:** DC, Battery Powered (Built-in 2500 mAh battery)
- **Product Dimensions:** Approximately 9"W x 3"H
- **Special Features:** 15W Fast Wireless Charger, Bluetooth Speaker, Alarm Clock with Snooze, FM Radio, Touch Adjustable Night Light, Phone Holder.

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact FREEFISH customer support. If you encounter any issues not covered in this manual, please reach out to our support team for assistance.

Customer Support: Please visit the FREEFISH Store on Amazon for contact information and further product details.

