

## COMHOMA HS107-BL

# COMHOMA HS107-BL Electric Power Lift Massage Recliner Chair

## USER MANUAL

### Introduction

---

Thank you for choosing the COMHOMA HS107-BL Electric Power Lift Massage Recliner Chair. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new recliner. Please read all instructions carefully before use and retain this manual for future reference.

### Important Safety Information

---

**WARNING: Failure to follow these safety instructions could result in injury or damage to the product.**

- Do not exceed the maximum weight capacity of 103.87 pounds (approximately 47 kg). Overloading can cause instability and damage.
- This product is for indoor use only. Do not use outdoors or in wet environments.
- This recliner is intended for personal use only and is not designed for medical purposes.
- Keep children and pets away from the chair's moving parts, especially during operation, to prevent pinching or injury.
- Ensure the power cord is not pinched or damaged. Do not operate the chair with a damaged cord or plug.
- Unplug the chair from the power outlet before cleaning or performing any maintenance.
- Do not place hands or feet under the chair while it is in motion.
- Always sit fully in the chair before operating the recline or lift functions.

## Package Contents

---

Before assembly, please ensure all components are present and undamaged. If any parts are missing or damaged, contact customer support immediately.

- Recliner Base
- Backrest
- Armrests (Left and Right)
- Power Adapter and Cord
- Remote Control
- User Manual (this document)

## Setup and Assembly

---

The COMHOMA HS107-BL recliner is designed for easy assembly with detachable parts. Follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and place them on a soft, clean surface to prevent scratches.
2. **Attach Backrest:** Slide the backrest onto the base until it clicks securely into place. Ensure it is fully seated.
3. **Attach Armrests:** Connect the left and right armrests to the corresponding sides of the chair base. Ensure all connections are firm.
4. **Connect Power:** Plug the power adapter into the chair's power input, then plug the adapter into a wall outlet.
5. **Initial Check:** Before sitting, test the power lift and recline functions using the remote control to ensure proper operation.



**Image Description:** This image displays the COMHOMA HS107-BL recliner with its backrest detached, revealing the intricate internal SL-track massage mechanism. The mechanism features multiple rollers designed to follow the natural curve of the spine. The chair is upholstered in blue and light blue fabric, positioned in a modern living room setting.



**Image Description:** A multi-panel diagram illustrating the dimensions of the COMHOMA HS107-BL recliner. It shows the chair in its upright position with height, width, and depth measurements, as well as in a fully reclined position with extended length and height. A side view also indicates the lift function's maximum height. Key dimensions like seat depth and armrest height are clearly marked.

## Operating Instructions

Your COMHOMA recliner offers multiple functions controlled by a user-friendly remote.


### Power Lift and Recline Function

The electric power lift and recline functions are operated via the remote control. This feature is particularly beneficial for individuals with mobility challenges, assisting them in standing up or sitting down with ease.

- **To Recline:** Press and hold the 'Recline' button on the remote. The backrest will smoothly move backward, and the footrest will extend. Release the button when you reach your desired position.
- **To Lift/Stand:** Press and hold the 'Lift' button. The chair will gently tilt forward and upward, assisting you to a standing position. Release the button when you are ready to stand.
- **To Return to Upright:** Press and hold the 'Upright' button. The chair will return to its standard sitting position.

# 5-IN-1 POWER LIFT RECLINER CHAIR

Adjust the backrest and sofa to your desired position, complete all your daily tasks in one go.



**Image Description:** This image shows a woman standing next to the COMHOMA HS107-BL recliner, which is in its power lift position. The chair is tilted forward at approximately a 45-degree angle, demonstrating how it assists users in transitioning from sitting to standing. A remote control with wireless signal icons is visible in the foreground.



**Image Description:** A visual guide showcasing five distinct positions of the COMHOMA HS107-BL recliner: 'Reading' (upright with slight recline), 'Working' (slightly reclined), 'Watching' (more reclined with footrest extended), 'Resting' (further reclined), and 'Sleeping' (fully reclined). A person is seated in the chair in the 'Watching' position, demonstrating its versatility.

### SL Massage Function

The recliner features an SL-track massage system that provides a comprehensive massage experience from your neck down to your glutes, following the natural curve of your spine.

- **Activate Massage:** Use the dedicated buttons on the remote control to turn on the massage function.
- **Adjust Intensity:** The remote allows you to select different massage modes and adjust the intensity.
- **Enhanced Massage:** For a more intense lumbar massage, the upper layer of the lumbar backrest can be removed. Refer to the internal mechanism image for guidance.

# S-TRACK MASSAGE CHAIR PRECISE ROLLER MOTION

The S-track rollers massage up and down your spine curvature, targeting all pressure points on your back.



**Image Description:** A detailed close-up image highlighting the internal massage rollers and mechanical components located within the backrest of the COMHOMA HS107-BL recliner. The rollers are visible, suggesting the precise movement along the spine for massage therapy.

# COMFORTABLE & CONVENIENT



**Image Description:** An illustrative diagram depicting the S-track massage roller motion within the COMHOMA HS107-BL recliner. The image shows rollers moving along the natural curvature of a person's spine, emphasizing the precise and targeted pressure points on the back.

## USB Port and Side Pockets

The remote control is equipped with a USB port for convenient charging of your electronic devices. The chair also features side pockets for storing the remote, phones, or other small items.

# POWER LIFT RECLINER CHAIR

Helps all individuals with difficulty in mobility



**Image Description:** A close-up photograph of the remote control for the COMHOMA HS107-BL recliner. The image clearly shows the top of the remote with an integrated USB charging port, indicating its functionality for charging external devices.

## Maintenance

Regular maintenance will help prolong the life and performance of your recliner.

- **Cleaning Fabric:** For general cleaning, use a soft, damp cloth with mild soap. Avoid harsh chemicals or abrasive cleaners that could damage the fabric. Spot clean spills immediately.
- **Cleaning Mechanism:** Periodically inspect the moving parts and ensure they are free from dust and debris. Do not lubricate the mechanism unless specifically instructed by customer support.
- **Power Cord:** Regularly check the power cord for any signs of damage. If damaged, discontinue use and contact customer support for a replacement.
- **Tighten Connections:** Occasionally check and tighten any visible screws or bolts to ensure stability.

## Troubleshooting

If you encounter issues with your recliner, refer to the following common problems and solutions:

- **Chair Not Responding:**

- Ensure the power cord is securely plugged into both the chair and a working wall outlet.
- Check if the wall outlet is functional by plugging in another device.
- Verify that the remote control cable is properly connected to the chair.

- **Massage Function Not Working:**

- Confirm the chair has power and the main massage function is activated via the remote.
- Ensure no obstructions are preventing the massage rollers from moving.

- **Unusual Noises:**

- Check for any loose components or foreign objects caught in the mechanism.
- If noises persist, discontinue use and contact customer support.

For issues not listed here, or if troubleshooting steps do not resolve the problem, please contact COMHOMA customer support.

## Specifications

Feature	Detail
Brand	COMHOMA
Model Number	HS107-BL
Color	Blue
Product Dimensions (D x W x H)	19.6"D x 32.5"W x 39.3"H
Item Weight	103.9 pounds
UPC	810154192588
Fill Material	Foam
Reclining Position Count	2 (Upright, Reclined)
Assembly Required	Yes
Special Features	Power Lift, SL-Track Massage, USB Port, Side Pockets

## Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact COMHOMA customer service directly. If you require assistance, have questions, or need to report an issue, please visit the official COMHOMA store or contact their support team.

[Visit the COMHOMA Store on Amazon](#)