

[Manuals.plus](#) /

› [KitchenAid](#) /

› KitchenAid Go Cordless Personal Blender KSBR256 Instruction Manual

KitchenAid KSBR256

KitchenAid Go™ Cordless Personal Blender

MODEL: KSBR256

Introduction

This manual provides essential information for the safe and efficient use of your KitchenAid Go™ Cordless Personal Blender. Please read all instructions carefully before operating the appliance and retain this manual for future reference.



Image: The KitchenAid Go Cordless Personal Blender, fully assembled and ready for use.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not immerse the motor base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter.

- Do not let cord contact hot surfaces.
- Always operate blender with cover in place.
- Blades are sharp. Handle carefully.

What's Included

Your KitchenAid Go™ Cordless Personal Blender package includes the following components:

- (1) 16 oz BPA-Free Blending Jar
- (1) Cordless Personal Blender Motor Base
- (1) Travel Lid
- (1) Wall Adapter
- (1) USB-C Cable
- (1) 12v MAX Removable Battery



Image: All components included with the KitchenAid Go Cordless Personal Blender: blending jar, motor base, travel lid, wall adapter, USB-C cable, and removable battery.

Setup

1. Charging the Battery

Before first use, fully charge the 12v MAX removable battery. Connect the USB-C cable to the battery and the wall adapter, then plug into a power outlet. The battery indicator lights will show charging progress.



Image: The 12V MAX removable battery on its charging dock, indicating charging status.

2. Assembling the Blender

1. Ensure the battery is securely inserted into the motor base.
2. Place the blending jar onto the motor base, aligning the tabs. Twist clockwise until it locks into place.

Powerful, cord-free blending



Image: The blender showing its 16-oz capacity jar and asymmetric blade design, with the motor base and optional travel lid.

Operating Instructions

1. Adding Ingredients

For optimal blending, add ingredients in the following order:

1. Liquids (water, milk, juice)
2. Soft ingredients (yogurt, powders, seeds)
3. Frozen fruits or ice
4. Harder ingredients (nuts, large chunks of fruit)

Do not overfill the blending jar beyond the MAX fill line. For frozen ingredients, allow them to sit for 15 minutes before blending, or use crushed ice instead of large cubes for smoother results.



Easily blend ice
for frozen creations

Image: A person blending ice and fruit in the KitchenAid Go Cordless Personal Blender to create a frozen drink.

2. Blending

Once ingredients are added and the jar is securely attached, press the power button to begin blending. The blender is designed to create a powerful blending vortex for smooth results. The 12v MAX battery provides up to 20 minutes of continuous runtime, depending on the ingredients and usage.

Your browser does not support the video tag.

Video: Official product video demonstrating the KitchenAid Go Cordless Personal Blender in use, showcasing its blending capabilities for various ingredients.

3. Using the Travel Lid

After blending, remove the blending jar from the motor base. Replace the blade assembly with the included travel lid for convenient on-the-go consumption. Ensure the travel lid is tightened securely to prevent leaks.



Image: The travel lid for the KitchenAid Go Cordless Personal Blender, designed for portability.

Maintenance and Cleaning

Proper cleaning ensures the longevity and hygiene of your blender.

- **Motor Base:** Wipe clean with a damp cloth. Do not immerse in water.
- **Blending Jar and Travel Lid:** These parts are dishwasher-safe (top rack only) or can be hand-washed with warm, soapy water. Handle the blade assembly with care due to sharp edges.
- **Battery:** Keep the battery and charging port dry.

Troubleshooting

- **Blender not turning on:** Ensure the battery is fully charged and securely inserted. Check that the blending jar is correctly aligned and locked onto the motor base.
- **Ingredients not blending smoothly:** Add more liquid. Ensure ingredients are cut into smaller pieces. For frozen items, allow them to thaw slightly or use crushed ice.
- **Lid leaking:** Ensure the blending jar and travel lid are tightened securely.
- **Blender stops during operation:** This may indicate overheating or an overload. Turn off the blender, remove the jar, and allow the motor to cool for a few minutes before attempting to blend again. Reduce the amount of ingredients or add more liquid.

Specifications

Feature	Detail
Brand	KitchenAid
Model Number	KSBR256BM
Color	Black Matte
Capacity	16 ounces
Product Dimensions	4.81"D x 5.15"W x 11.84"H

Item Weight	3.3 pounds
Power Source	Battery Powered (12v MAX)
Number of Speeds	2
Blade Material	Stainless Steel
Included Components	(1) 16 oz BPA-Free Blending Jar, (1) Cordless Personal Blender, (1) Travel Lid, (1) wall adapter, (1) USB-C cable, (1) 12v MAX removable battery

Warranty and Support

This KitchenAid Go™ Cordless Personal Blender comes with a **1 Year Limited Warranty**. For detailed warranty information, product registration, or customer support, please visit the official KitchenAid website or contact their customer service.

You can also visit the [KitchenAid Store on Amazon](#) for additional product information and accessories.