

HONITURE V8 Pro

HONITURE V8 Pro Robot Vacuum Cleaner User Manual

Model: V8 Pro | Brand: HONITURE

1. INTRODUCTION

This manual provides essential information for the safe operation, maintenance, and troubleshooting of your HONITURE V8 Pro Robot Vacuum Cleaner. Please read this manual thoroughly before using the product and retain it for future reference.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before use.
- Do not operate the robot in wet environments or near water.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not use to pick up large objects, sharp objects, or burning/smoking materials.
- Ensure the charging dock is placed against a wall on a level surface.
- Supervise children and pets when the robot is operating.
- Only use the original power adapter and charging dock provided by the manufacturer.

3. PACKAGE CONTENTS

Verify that all components are present in the box upon unpacking.



Image: Components included in the HONITURE V8 Pro package.

1. V8 Pro Robot Vacuum Cleaner x 1
2. Charging Station x 1
3. 2-in-1 Dustbin and Water Tank x 1
4. Side Brush x 1
5. Main Brush x 1
6. Mop Holder x 1
7. High-Efficiency Filter x 1
8. Cleaning Tool x 1
9. User Manual x 1
10. Quick Start Guide x 1
11. Mop Cloth x 1

4. SETUP

4.1 Charging Station Placement

Place the charging station against a wall in an open area, ensuring there are no obstacles within 1 meter (3 feet) to the sides and 1.5 meters (5 feet) in front. Connect the power adapter to the charging station and plug it into a power outlet.

4.2 Initial Charging

Place the robot onto the charging station. Ensure the charging contacts on the robot align with those on the station. The robot will begin charging automatically. For first-time use, fully charge the robot before operation (approximately 4-5 hours).

4.3 App Connection (2.4 GHz Wi-Fi only)

Download the HONITURE app from your smartphone's app store. Follow the in-app instructions to connect your robot to your home Wi-Fi network. Note that the V8 Pro only supports 2.4 GHz Wi-Fi networks.



Flexibilité dans la mise en place de zones interdites

Si vous avez une zone que vous ne voulez pas nettoyer, vous pouvez facilement le faire via l'application.

Image: Smart app and voice control features.

5. OPERATING INSTRUCTIONS

5.1 Starting a Cleaning Cycle

Press the power button on the robot or use the app to start a cleaning cycle. The robot will automatically map your home using its LDS radar and SLAM algorithm, identifying furniture and obstacles for efficient cleaning paths.



Image: 360-degree Lidar Navigation in action.

5.2 Cleaning Modes and Settings

The V8 Pro offers multiple cleaning modes and adjustable settings via the app:

- **Auto Cleaning:** The robot intelligently plans the best route.
- **Spot Cleaning:** Focuses on a specific dirty area.
- **Edge Cleaning:** Cleans along walls and furniture edges.
- **Zigzag Cleaning:** Efficient, systematic cleaning pattern.
- **Suction Power:** Adjustable to 4 levels (Gentle, Standard, Powerful, Max 5000 PA).
- **Water Flow:** Adjustable to 3 levels for mopping.



Image: 5000 PA Super Suction Power.



Image: Multiple cleaning modes for enhanced efficiency.

5.3 3-in-1 Vacuum, Mop, and Sweep Function

The V8 Pro features a combined dustbin and water tank, allowing it to vacuum, sweep, and mop simultaneously. This is ideal for various floor types including ceramic tiles, wood floors, and marble.



Image: 3-in-1 vacuum, mop, and sweep functionality.

5.4 Smart Features

- **Multi-Floor Mapping:** The robot can store up to 5 maps, allowing it to operate efficiently in multi-story homes.
- **Customized Cleaning:** Use the app to name different zones, set specific suction/water levels, and define no-go zones or virtual walls.
- **Automatic Recharge & Resume:** The robot returns to its charging station when the battery is low and resumes cleaning from where it left off once recharged.
- **Carpet Boost:** Automatically increases suction power to maximum when detecting carpets for deeper cleaning.
- **Obstacle Avoidance:** Equipped with multiple sensor groups to intelligently identify furniture, stairs, and other obstacles.



Image: Customized cleaning via the mobile app.



Image: Multi-layer map creation for multi-story homes.



Image: Automatic recharge and resume function.



Image: Advanced navigation features including anti-drop, anti-collision, and climbing capability.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your robot vacuum.

6.1 Emptying the Dustbin and Water Tank

After each cleaning cycle, remove the 2-in-1 dustbin and water tank. Empty the dustbin and rinse the water tank. Clean the mop cloth if used.

6.2 Cleaning Brushes and Filter

- **Main Brush:** Remove the main brush and use the provided cleaning tool to cut and remove any tangled hair or debris. Clean weekly.
- **Side Brushes:** Check side brushes for wear or damage. Clean any tangled hair. Replace if worn. Clean monthly.
- **High-Efficiency Filter:** Tap the filter to remove dust. Do not wash with water. Replace every 3-6 months depending on usage.

6.3 Cleaning Sensors and Charging Contacts

Wipe all sensors (LDS sensor, cliff sensors, wall sensors) and charging contacts on both the robot and the

charging station with a clean, dry cloth monthly.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Robot does not turn on.	Low battery; power switch off.	Charge the robot; ensure power switch is on.
Robot cannot connect to Wi-Fi.	Incorrect Wi-Fi band (only 2.4 GHz supported); incorrect password.	Ensure your router is set to 2.4 GHz; re-enter Wi-Fi password.
Robot gets stuck frequently.	Obstacles on the floor; dirty sensors.	Clear obstacles; clean all sensors.
Poor cleaning performance.	Full dustbin; clogged brushes; dirty filter.	Empty dustbin; clean brushes; clean/replace filter.
Robot does not return to charging station.	Charging station obstructed; dirty charging contacts.	Ensure clear path to station; clean charging contacts.

8. SPECIFICATIONS

Feature	Detail
Brand	HONITURE
Model Name	V8 Pro
Suction Power	Up to 5000 PA
Battery Life	Up to 180 minutes
Navigation Type	Lidar (LDS) and SLAM algorithm
Mapping Capability	Stores up to 5 maps
Cleaning Functions	Vacuum, Sweep, Mop (3-in-1)
Water Flow Levels	3 adjustable levels
Suction Power Levels	4 adjustable levels
Compatible Surfaces	Marble, laminate, linoleum, upholstery, glass, tile, carpet (low pile), wood, vinyl, bamboo, concrete, engineered wood

Feature	Detail
Special Features	Cordless, App Control, Voice Control (Alexa, Google Assistant compatible), Multi-floor mapping, No-go zones, Carpet boost, Anti-drop, Anti-collision, 20mm climbing ability
Dimensions (L x W x H)	35L x 35W x 9.6H centimeters
Filter Type	Cartridge (High-Efficiency Filter)
Power Source	Battery Powered
Wi-Fi Compatibility	2.4 GHz only

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official HONITURE website or contact their customer service directly. The user manual included in the package may also contain specific warranty details. For further assistance, please visit: [HONITURE Official Store](#)