



Manuals.plus /

› GreenLife /

› GreenLife 4.5QT Air Fryer User Manual

GreenLife CC009064-001

GreenLife 4.5QT Air Fryer User Manual

Model: CC009064-001

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your GreenLife 4.5QT Air Fryer. Designed for healthy, oil-less cooking, this appliance features a spacious 4.5-quart capacity, user-friendly mechanical dial controls for temperature and time, and a PFAS-free ceramic nonstick drawer for easy cleanup. Please read all instructions carefully before first use and retain this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Ensure the air fryer is placed on a stable, heat-resistant surface, away from walls or other appliances to allow for proper air circulation.
- Do not block any ventilation openings.

PRODUCT OVERVIEW

The GreenLife 4.5QT Air Fryer is designed for ease of use and healthy cooking. Below are the key components and features of your appliance.



EASY CONTROL

The safe & secure grip makes transferring a breeze

This image illustrates the main features of the GreenLife 4.5QT Air Fryer, including the healthy ceramic nonstick interior, 4.5QT capacity, easy slide drawer, LED indicator lights, adjustable time and temperature dials, stay-cool handle, and dishwasher-safe drawer and tray.

Key Features:

- **PFAS-Free Ceramic Nonstick:** The drawer and tray feature a healthy ceramic nonstick coating, free of PFAS, PFOA, lead, and cadmium.
- **4.5QT Capacity:** Provides ample space for cooking family-sized meals.
- **Mechanical Dial Controls:** Simple and intuitive dials for adjusting time and temperature.

- **Stay-Cool Handle:** Ensures safe and easy handling of the cooking drawer.
- **LED Indicator Lights:** Clearly indicate when the air fryer is heating and when cooking is complete.
- **Dishwasher Safe Drawer & Tray:** Designed for effortless cleanup.
- **Automatic Shut-Off:** For enhanced safety and convenience.

SETUP

Follow these steps to prepare your air fryer for its first use:

1. **Unpack:** Carefully remove the air fryer and all packaging materials. Ensure all components are present and undamaged.
2. **Initial Cleaning:** Before first use, wash the air fryer drawer and tray with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the air fryer on a stable, flat, heat-resistant surface. Ensure there is at least 6 inches (15 cm) of clear space around the back and sides of the appliance for proper ventilation. Do not place it directly under cabinets.
4. **First Use (Burn-Off):** It is normal for a slight odor or smoke to be emitted during the first few uses as manufacturing residues burn off. To minimize this, operate the air fryer empty for about 10-15 minutes at 350°F (175°C) before cooking food. Ensure the area is well-ventilated.

OPERATING INSTRUCTIONS

Operating your GreenLife Air Fryer is straightforward with its mechanical dial controls.

Basic Operation:

1. **Plug In:** Ensure the air fryer is plugged into a grounded electrical outlet.
2. **Preheat (Optional but Recommended):** For best results, preheat the air fryer. Turn the temperature dial to your desired cooking temperature (e.g., 375°F) and the timer dial to 3-5 minutes. The red indicator light will illuminate, indicating heating.
3. **Prepare Food:** Place your food in the air fryer drawer. Do not overfill the basket to allow for proper air circulation and even cooking.
4. **Set Temperature:** Turn the temperature dial to the desired cooking temperature, ranging up to 400°F (200°C).

DISHWASHER SAFE DRAWER & TRAY



EFFORTLESS CLEANUP

Wipe drawer & tray clean or place in the dishwasher

This image shows a close-up of the mechanical dials for setting temperature and time on the GreenLife Air Fryer, along with the LED indicator lights.

- 5. Set Timer:** Turn the timer dial to the required cooking time, up to 60 minutes. The red indicator light will turn on, and the green indicator light will illuminate when the set time begins. The air fryer will automatically shut off when the timer reaches zero, and a bell will sound.
- 6. Monitor Cooking:** For even cooking, especially with larger quantities or certain foods, pull out the drawer using the stay-cool handle and shake or flip the food halfway through the cooking time. The air fryer will pause when the drawer is removed and resume when it is reinserted.



HEALTHY CERAMIC NONSTICK

EZ AIR FRYER

Nonstick makes cleanup easy and GreenLife makes nonstick clean.
We work hard to make easy cooking better for everyone.



**FREE OF PFAS
& PFOA**



**60% FEWER CO2
EMISSIONS***



**DERIVED FROM
SAND**

*60% less CO2 emissions than traditional nonstick in the nonstick coating curing process

This image highlights the ergonomic, stay-cool handle of the GreenLife Air Fryer, designed for safe and easy removal of the cooking drawer.

- 7. Remove Food:** Once cooking is complete, carefully pull out the drawer using the stay-cool handle. Use tongs or other heat-resistant utensils to remove the cooked food.
- 8. Cool Down:** Allow the appliance to cool down completely before cleaning or storing.

Cooking Tips:

- Smaller items usually require a slightly shorter cooking time than larger items.
- Shaking smaller items halfway through the cooking process optimizes the end result and can help prevent unevenly fried items.
- Add a little oil to fresh potatoes for a crispy result. Fry your items in the air fryer within a few minutes after adding the oil.
- Snacks that can be cooked in an oven can also be cooked in the air fryer.
- The air fryer is suitable for baking, defrosting, dehydrating, reheating, and roasting a variety of foods.

CLEANING AND MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your GreenLife Air

Fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Dishwasher Safe Parts:** The air fryer drawer and tray are dishwasher safe. For best results and to preserve the PFAS-free ceramic nonstick coating, place them on the top rack of your dishwasher. Alternatively, wash them by hand with warm, soapy water and a non-abrasive sponge.



This image demonstrates the dishwasher-safe feature of the GreenLife Air Fryer's drawer and tray, making cleanup convenient.

3. **Clean the Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scourers, as they can damage the surface.
4. **Clean the Interior:** If necessary, wipe the interior of the appliance with a damp cloth. For stubborn food residue, a small amount of mild detergent can be used. Ensure the interior is completely dry before storage.
5. **Storage:** Store the cleaned and dried air fryer in a cool, dry place.

TROUBLESHOOTING

If you encounter any issues with your GreenLife Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Timer is not set.	Ensure the power cord is securely plugged into a grounded outlet. Turn the timer dial to the desired cooking time.
Food is not cooked evenly.	Basket is overfilled. Food was not shaken/flipped.	Reduce the amount of food in the basket. Cook in batches if necessary. Shake or flip food halfway through cooking.
White smoke comes from the appliance.	Fatty ingredients are being cooked. Residue from previous use.	This is normal for fatty foods. Ensure the drawer and tray are clean. Clean the drawer and tray thoroughly after each use.
Food is not crispy.	Too much moisture in food. Not enough oil (for fresh items).	Pat food dry before air frying. Lightly coat fresh items with oil for crispier results.

If the problem persists after checking these solutions, please contact GreenLife Customer Support.

SPECIFICATIONS

- **Model Number:** CC009064-001
- **Capacity:** 4.5 Quarts
- **Color:** Graphite
- **Material:** Ceramic (Nonstick Coating)
- **Product Dimensions:** 13.7"D x 13.7"W x 13.4"H
- **Item Weight:** 11.08 pounds (5.04 Kilograms)
- **Wattage:** 1500 watts
- **Control Type:** Mechanical Knob (Temperature and Timer)
- **Special Features:** Automatic Shut-Off, Temperature Control, Timer, PFAS-Free Ceramic Nonstick, Dishwasher Safe Drawer & Tray
- **UPC:** 885837047295

WARRANTY AND SUPPORT

GreenLife products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official GreenLife website. If you require assistance, have questions about your product, or need to report an issue, please contact GreenLife Customer Support. For the most up-to-date support information, please visit the GreenLife Store on Amazon or their official brand website.