

## Mesqool CR1027

# Mesqool Vibrating Alarm Clock User Manual

Model: CR1027

For Heavy Sleepers, Hearing-Impaired, and Travel Use

## 1. INTRODUCTION

Thank you for choosing the Mesqool Vibrating Alarm Clock. This device is designed to provide a reliable and customizable wake-up experience, particularly beneficial for heavy sleepers, individuals with hearing impairments, or those who prefer a silent alarm. Featuring a powerful vibration, dual alarm settings, and a long-lasting rechargeable battery, this cordless alarm clock is suitable for both home and travel use.

## 2. PACKAGE CONTENTS

- Mesqool Vibrating Alarm Clock (Purple)
- USB-C Charging Cable
- Wrist Strap
- User Manual



Image: Contents of the Mesqool Vibrating Alarm Clock package, showing the purple alarm clock, a USB-C charging cable, a purple wrist strap, and the user manual.

## 3. PRODUCT OVERVIEW



Image: Front view of the Mesqool Vibrating Alarm Clock, showcasing its digital display with time, AM indicator, battery level, and alarm icons.

## Key Features:

- **Cordless Operation:** Enjoy freedom of placement without being tethered by cables.
- **Rechargeable Battery:** Equipped with a 3000mAh high-capacity battery, providing up to six months of use on a single charge.
- **Adjustable Vibration:** Three vibration levels (Low, Medium, High) to suit individual preferences.
- **Dual Alarms:** Set two independent alarms for different schedules, with options for weekday, weekend, or all 7 days.
- **Multiple Alarm Modes:** Choose between Vibration Only, Alarm Only (audible), or both Vibration and Alarm.
- **Adjustable Alarm Volume:** Audible alarm volume ranges from 56db to 105db.
- **Compact & Portable:** Mini size (3.35"W x 3.35"H x 1.06"D) makes it ideal for travel.
- **9-Minute Snooze:** Allows for a brief delay before the alarm reactivates.
- **Time Format Options:** Switch between 12-hour and 24-hour time display.
- **DST Function:** Daylight Saving Time adjustment.
- **Lock Function:** Prevents accidental button presses during sleep or travel.

## 4. SETUP

### 4.1 Initial Charging

Before first use, fully charge the alarm clock. Connect the provided USB-C cable to the charging port on

the side of the device and plug the other end into a standard USB power adapter (not included) or a computer USB port. The battery indicator on the display will show charging status and full charge.

## Equipped with a 3000mAh Rechargeable High-Capacity Battery

Ensuring Extended Battery Life – A Single Full Charge Offers at Least Six Months of Usage.



Image: The Mesqool alarm clock being charged via its USB-C port, with the charging cable connected to a power source.

### Cordless Alarm Clock with 3000mAh Rechargeable Battery



Image: A close-up diagram highlighting the battery indicator on the display and the Type-C charging port on the side of the alarm clock.

### 4.2 Attaching the Wrist Strap

Thread the provided wrist strap through the small loop hole on the side of the alarm clock. This can help

prevent losing the clock, especially when used under a pillow.

## 5. OPERATING INSTRUCTIONS

### 5.1 Button Functions

Familiarize yourself with the buttons located on the top and side of the alarm clock:

- **TIME/SNOOZE Button:** Press to enter time setting mode; press during alarm to activate snooze.
- **ALARM 1 Button:** Press to set Alarm 1.
- **ALARM 2 Button:** Press to set Alarm 2.
- **'+' Button:** Increase value during setting; adjust volume/vibration level.
- **'-' Button:** Decrease value during setting; adjust volume/vibration level.
- **LOCK Switch:** Slide to lock/unlock buttons.
- **VIBRATION/ALARM Mode Switch:** Select alarm mode (Vibration Only, Alarm Only, Both).
- **12/24H & DST Switch:** Toggle between 12-hour and 24-hour time format, and activate/deactivate DST.



Image: A detailed view of the top control panel of the alarm clock, indicating the functions of the TIME/SNOOZE, ALARM 1, ALARM 2, '+' and '-' buttons.




Image: A side view of the alarm clock, illustrating the position and function of the lock switch, vibration/alarm mode switch, and 12/24H & DST switch.

### 5.2 Setting the Time

1. Ensure the LOCK switch is in the unlocked position.

2. Press and hold the **TIME/SNOOZE** button for 3 seconds. The hour digits will flash.
3. Use the '+' or '-' buttons to adjust the hour.
4. Press the **TIME/SNOOZE** button again to confirm the hour and move to minute setting. The minute digits will flash.
5. Use the '+' or '-' buttons to adjust the minute.
6. Press the **TIME/SNOOZE** button again to confirm the minute and move to day setting. The day indicator will flash.
7. Use the '+' or '-' buttons to select the current day (MON, TUE, WED, THU, FRI, SAT, SUN).
8. Press the **TIME/SNOOZE** button one last time to save all settings and exit time setting mode.

### 5.3 Setting Alarms (Alarm 1 & Alarm 2)

The clock supports two independent alarms. The setting process is identical for both.

1. Ensure the **LOCK** switch is in the unlocked position.
2. Press and hold the **ALARM 1** or **ALARM 2** button for 3 seconds. The alarm hour digits will flash.
3. Use the '+' or '-' buttons to adjust the alarm hour.
4. Press the corresponding **ALARM** button again to confirm the hour and move to minute setting. The alarm minute digits will flash.
5. Use the '+' or '-' buttons to adjust the alarm minute.
6. Press the corresponding **ALARM** button again to confirm the minute and move to alarm frequency setting. The day indicators will flash.
7. Use the '+' or '-' buttons to select the alarm frequency:
  - **MON-FRI:** Weekday alarm.
  - **SAT-SUN:** Weekend alarm.
  - **MON-SUN:** Everyday alarm.
8. Press the corresponding **ALARM** button one last time to save all settings and exit alarm setting mode.

# Set Dual Alarms for Weekdays and Weekends

Customized Wake-Up Schedules to Suit Your Lifestyle.



Image: The alarm clock positioned on a bedside table, showing the digital display with two alarm icons activated, indicating the dual alarm functionality.



## Wakes up the Deepest Sleeper

3-Levels of Vibration Strength



Image: A visual representation of the dual alarm feature, demonstrating how to set alarms for weekdays, weekends, or all seven days.

### 5.4 Adjusting Vibration Levels

The alarm clock offers three vibration intensity levels: Low, Medium, and High. To adjust:

1. Locate the **VIBRATION/ALARM Mode Switch** on the side of the device.
2. Slide the switch to the desired vibration level (L, M, H).

# 3-Levels Vibration Adjustable

Personalize your wake-up experience for ultimate comfort.



LOW



MIDDLE



HIGH



Image: A person sleeping with the alarm clock placed under their pillow, demonstrating its use for silent, vibrating wake-up. The image also shows icons for Low, Middle, and High vibration settings.

## Dual Alarms for Weekday

## & Weekend

Set two separate alarms for different schedules  
Each alarm can be programmed for different alarm modes



Image: A graphic representation of the three adjustable vibration levels: Low, Middle, and High, indicating increasing intensity.

## 5.5 Adjusting Alarm Volume and Mode

The audible alarm volume can be adjusted, and you can select the alarm mode.

1. To adjust volume: While the alarm is sounding, press the '+' or '-' buttons to increase or decrease the

volume (56db to 105db).

2. To select alarm mode: Use the **VIBRATION/ALARM Mode Switch** on the side of the device to choose between:


- **VIB:** Vibration Only
- **BUZZ:** Audible Alarm Only
- **VIB+BUZZ:** Both Vibration and Audible Alarm

## Helps Child Wake Unassisted

Buzzer Only, Vibrate Only, Buzzer with Vibrate.



VIB



VIB+BUZZ



BUZZ



Image: A child sleeping peacefully with the alarm clock placed near their head, illustrating the various alarm modes available: Vibration Only, Vibration with Buzzer, and Buzzer Only.




Image: A graphic illustrating the three alarm modes (Vibration, Vibration + Buzzer, Buzzer) and the adjustable volume range for the audible alarm, from 56db to 105db.

## 5.6 Snooze Function

When an alarm sounds, press the **TIME/SNOOZE** button to activate the 9-minute snooze function. The alarm will temporarily stop and sound again after 9 minutes. To cancel snooze and turn off the alarm, press any other button.

## 5.7 12/24H Time Format and DST

Use the **12/24H & DST Switch** on the side of the device to toggle between 12-hour (with AM/PM indicator) and 24-hour time formats. This switch also allows you to activate or deactivate Daylight Saving Time (DST) if needed.

## 5.8 Lock Function

To prevent accidental changes to settings or unintended alarm deactivation, slide the **LOCK** switch on the side of the device to the locked position. This will disable all buttons except for the snooze function (if an alarm is active). Slide it back to the unlocked position to adjust settings.




Image: A close-up of the side of the alarm clock, highlighting the lock switch and its function to prevent accidental operations.

## 6. CHARGING AND BATTERY

The Mesqool Vibrating Alarm Clock is equipped with a 3000mAh rechargeable battery. A full charge can provide up to six months of operation, depending on usage frequency and vibration intensity. When the battery is low, a battery indicator will appear on the display. Connect the USB-C cable to recharge the

device.

## 7. MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the alarm clock to extreme temperatures, direct sunlight, or moisture.
- Do not attempt to disassemble the device, as this will void the warranty.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Alarm not sounding/vibrating.	Alarm is not set, alarm mode is incorrect, or battery is low.	Ensure alarm is set correctly (Section 5.3). Check the VIBRATION/ALARM Mode Switch (Section 5.5). Charge the device (Section 6).
Buttons are unresponsive.	LOCK switch is engaged.	Slide the LOCK switch to the unlocked position (Section 5.8).
Display is dim or blank.	Battery is low or depleted.	Charge the device (Section 6).
Incorrect time displayed.	Time was not set correctly or DST is active/inactive incorrectly.	Reset the time (Section 5.2). Check the DST setting (Section 5.7).

## 9. SPECIFICATIONS

Feature	Detail
Brand	Mesqool
Model Number	CR1027
Color	Purple
Display Type	Digital
Product Dimensions	3.35"W x 3.35"H x 1.06"D
Item Weight	6.7 ounces
Power Source	Battery Powered (Rechargeable)
Battery Capacity	3000mAh
Material	Acrylonitrile Butadiene Styrene (ABS Plastic)
Alarm Volume Range	56db - 105db

Feature	Detail
Special Features	Adjustable Vibration, Battery Indicator, Cordless, Dual Alarms, Snooze, 12/24H, DST, Lock Function

## 10. WARRANTY AND SUPPORT

### 10.1 Warranty Information




This Mesqool Vibrating Alarm Clock comes with an extended warranty. Please refer to the warranty card included in your package or contact Mesqool customer support for specific details regarding warranty coverage and duration.




### 10.2 Customer Support

For any questions, technical assistance, or support needs, please contact Mesqool customer service. Contact information can typically be found on the product packaging, the official Mesqool website, or the warranty card.

© 2025 Mesqool. All rights reserved.

## Related Documents - CR1027

	<p><a href="#">Mesqool CR1001EM Pro Alarm Clock User Manual</a></p> <p>User manual for the Mesqool CR1001EM Pro alarm clock, detailing setup, time setting, alarm configuration, dimmer, USB charging, and troubleshooting.</p>
	<p><a href="#">Mesqool CR1001eM Alarm Clock with Vibrator User Manual</a></p> <p>User manual for the Mesqool CR1001eM Alarm Clock with Vibrator, detailing its features, controls, alarm settings, dimmer, DST, USB charging, and vibrator functions. Perfect for heavy sleepers.</p>
	<p><a href="#">Mesqool CR1024 Projection Alarm Clock User Manual</a></p> <p>User guide for the Mesqool CR1024 Projection Alarm Clock, detailing time setting, date setting, DST function, alarm settings, brightness control, temperature/humidity display, night light, projection mode, and device charging.</p>

	<p><b><a href="#">Mesqool CR1025 Digital Alarm Clock Radio with Bluetooth and FM</a></b></p> <p>User manual for the Mesqool CR1025 digital alarm clock radio. Features include Bluetooth 5.0 speaker, FM radio, night light, USB/Type-C charging, adjustable dimmer, snooze function, and battery backup. Learn how to set alarms, use Bluetooth, tune FM radio, and adjust settings.</p>
	<p><b><a href="#">Mesqool CR1001F Projection Alarm Clock User Manual</a></b></p> <p>User manual for the Mesqool CR1001F Projection Alarm Clock, detailing its features, controls, time setting, alarm setting, projection mode, dimmer, DST, and USB charging.</p>
	<p><b><a href="#">CR1024 Projection Alarm Clock User Manual</a></b></p> <p>User manual for the CR1024 Projection Alarm Clock, detailing setup, time and date settings, alarm functions, projection features, brightness control, temperature/humidity display, and device charging capabilities.</p>