

[manuals.plus](#) /› [GreenLife](#) /› [GreenLife Rice Cooker \(Model CC008704-001\) Instruction Manual](#)**GreenLife CC008704-001**

GreenLife Rice Cooker (Model CC008704-001) Instruction Manual

Your guide to effortless rice cooking.

1. INTRODUCTION

Thank you for choosing the GreenLife Rice Cooker. This appliance is designed to simplify your cooking process, delivering perfectly cooked rice with minimal effort. Its PFAS-free ceramic nonstick coating ensures healthier meals and easy cleanup. This manual provides essential information for safe and efficient use of your new rice cooker.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. WHAT'S INCLUDED

Your GreenLife Rice Cooker package includes the following components:

- GreenLife Rice Cooker Base
- Removable Inner Pot with PFAS-Free Ceramic Nonstick Coating
- Glass Lid with Wood-Print Knob
- Measuring Cup
- Rice Paddle

RICE CHART				
CUPS REFERENCED ARE WITH THE INCLUDED MEASURING CUP				
UNCOOKED RICE	VOLUME	WATER LINE	COOK TIME	YIELD
White Rice	1 cup	Line 1	21-22min	2.8 cups
	2 cups	Line 2	23-24min	5.4 cups
	3 cups	Line 3	30-31min	9 cups
Brown Rice	1 cup	Line 1	30-31min	2.4 cups
	2 cups	Line 2	46-47min	5.5 cups
	3 cups	Line 3	53-54min	8.3 cups

1 Rice Measuring Cup = 3/4 U.S Cup

Image: The GreenLife Rice Cooker with its removable inner pot, a measuring cup, and a rice paddle, illustrating the complete set of included accessories.

4. SETUP

1. Unpack all components and remove any packaging materials.
2. Wash the removable inner pot, glass lid, measuring cup, and rice paddle with warm, soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the rice cooker base with a damp cloth. Do not immerse the base in water.
4. Place the rice cooker on a stable, heat-resistant, and dry surface.

5. OPERATING INSTRUCTIONS

5.1 Cooking Rice

1. Measure the desired amount of rice using the included measuring cup.
2. Rinse the rice thoroughly under cold water until the water runs clear.
3. Place the rinsed rice into the removable inner pot.
4. Add the appropriate amount of water according to the Rice Cooking Chart below. The inner pot also has measurement lines for convenience.

5. Place the inner pot into the rice cooker base and cover with the glass lid.
6. Plug the power cord into a 120V AC electrical outlet. The 'Warm' indicator light will illuminate.
7. Press the one-touch switch down to the 'Cook' position. The 'Cook' indicator light will illuminate, and cooking will begin.
8. Once cooking is complete, the rice cooker will automatically switch to the 'Keep Warm' function. The 'Cook' light will turn off, and the 'Warm' light will remain on.
9. For best results, allow the rice to rest on 'Keep Warm' for 5-10 minutes before serving. Fluff the rice with the rice paddle before serving.



Image: A hand pressing the simple one-touch switch on the GreenLife Rice Cooker to initiate the cooking cycle.

5.2 Auto Keep Warm Function

The GreenLife Rice Cooker features an automatic 'Keep Warm' function. After the cooking cycle is finished, the appliance will automatically switch to 'Keep Warm' mode, indicated by the illuminated 'Warm' light. This function maintains the rice at an optimal serving temperature without overcooking, ensuring your rice is ready when you are.



Image: The GreenLife Rice Cooker with its lid on, indicating the 'Keep Warm' function is active, keeping the rice at an ideal temperature.

6. RICE COOKING CHART

The following chart provides recommended rice and water ratios. Cups referenced are with the included measuring cup (approximately 3/4 U.S. Cup).



Image: A detailed chart showing recommended quantities of uncooked rice, water lines, cooking times, and yield for both white and brown rice.

Uncooked Rice Type	Volume (Included Cup)	Water Line (Inner Pot)	Cook Time (Approx.)	Yield (Approx.)
	1 cup	Line 1	21-22 min	2.8 cups
	2 cups	Line 2	23-24 min	5.4 cups

White Rice Uncooked Rice Type	Volume (Included Cup)	Water Line (Inner Pot)	Cook Time (Approx.)	Yield (Approx.)
	3 cups	Line 3	30-31 min	9 cups
Brown Rice	1 cup	Line 1	30-31 min	2.4 cups
	2 cups	Line 2	46-47 min	5.5 cups
	3 cups	Line 3	53-54 min	8.3 cups

7. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will ensure the longevity and performance of your rice cooker.

1. Always unplug the rice cooker from the power outlet and allow it to cool completely before cleaning.
2. **Removable Inner Pot, Glass Lid, Measuring Cup, and Rice Paddle:** These parts are dishwasher safe for easy cleaning. Alternatively, wash them by hand with warm, soapy water, rinse thoroughly, and dry completely.
3. **Rice Cooker Base:** Wipe the exterior of the base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the rice cooker base in water or any other liquid.
4. Ensure all parts are dry before reassembling and storing the appliance.



Image: A hand cleaning the removable inner pot under running water, demonstrating the ease of cleanup for the ceramic nonstick surface.

8. TROUBLESHOOTING

- **Rice is too hard/undercooked:** Ensure the correct rice-to-water ratio was used. Make sure the lid was securely closed during cooking. Allow rice to rest on 'Keep Warm' for 5-10 minutes after cooking.

- **Rice is too soft/mushy:** Reduce the amount of water slightly for the next batch. Ensure the rice was not over-soaked.
- **Rice sticks to the bottom:** While the pot is nonstick, ensure it is clean and free of residue. A very small amount of cooking oil can be added to the water before cooking if sticking persists.
- **Rice cooker does not turn on:** Check if the power cord is securely plugged into both the appliance and a working electrical outlet.
- **'Cook' light does not illuminate:** Ensure the one-touch switch is fully pressed down to the 'Cook' position.


9. SPECIFICATIONS

- **Brand:** GreenLife
- **Model Name:** GreenLife Electric 1.5 QT Rice Cooker
- **Model Number:** CC008704-001
- **Capacity:** 3 Cups Uncooked / 6 Cups Cooked
- **Product Dimensions:** 9.61"D x 18.7"W x 15.75"H
- **Item Weight:** 3.19 pounds (1.45 Kilograms)
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts
- **Wattage:** 300 watts
- **Material:** Ceramic (Inner Pot), Glass (Lid)
- **Special Features:** Lightweight, Non-Stick, One-Touch Operation, Removable Bowl, Auto Keep Warm Function
- **Product Care:** Dishwasher Safe (removable parts), Hand Wash
- **UPC:** 885837044669

10. WARRANTY AND SUPPORT


For warranty information or technical support, please refer to the documentation included with your product or visit the official GreenLife website. Keep your proof of purchase for any warranty claims.

Related Documents - CC008704-001



[GreenLife Healthy Power 5-in-1 Electric Skillet Instruction Manual](#)

Comprehensive guide for the GreenLife Healthy Power 5-in-1 Electric Skillet, covering safety precautions, parts, features, operation, cooking tips, and warranty information. Learn how to use and maintain your electric skillet for healthy and delicious meals.

 <p>1.5QT RICE COOKER INSTRUCTION BOOKLET CUSTOMER SERVICE 1-877-949-4263</p>	<p><u>GreenLife 1.5-Quart Rice Cooker: Instruction Manual & User Guide</u> Comprehensive instruction booklet for the GreenLife 1.5-Quart Rice Cooker. Learn about important safeguards, parts, operation, cleaning, warranty, and terms of sale for your GreenLife appliance.</p>
 <p>GO GRAINS! RICE & GRAINS COOKER INSTRUCTION BOOKLET CUSTOMER SERVICE 1-877-949-4263</p>	<p><u>GreenLife Go Grains Rice & Grains Cooker Instruction Manual</u> Official instruction booklet for the GreenLife Go Grains Rice & Grains Cooker. Learn about important safeguards, parts, control panel operation, cleaning, troubleshooting, and warranty information.</p>
 <p>3-IN-1 BREAKFAST MAKER INSTRUCTION BOOKLET CUSTOMER SERVICE 1-877-949-4263</p>	<p><u>GreenLife 3-in-1 Breakfast Maker Instruction Booklet - User Guide</u> Official instruction booklet for the GreenLife 3-in-1 Breakfast Maker. Includes important safety precautions, parts identification, operating instructions, cleaning guide, warranty information, and terms of sale.</p>
 <p>SLOW COOKER INSTRUCTION BOOKLET CUSTOMER SERVICE 1-877-949-4263</p>	<p><u>GreenLife 3.5QT Slow Cooker Instruction Booklet User Manual</u> Official instruction booklet for the GreenLife 3.5QT Slow Cooker. Includes safety precautions, operating instructions, cleaning, troubleshooting, and warranty information.</p>
 <p>green life™ SANDWICH PRO INSTRUCTION BOOKLET</p>	<p><u>GreenLife Sandwich Pro Instruction Booklet: User Guide and Tips</u> Comprehensive instruction booklet for the GreenLife Sandwich Pro, covering important safeguards, usage instructions, tips, cleaning, maintenance, storage, warranty, and terms of sale. Learn how to make sandwiches, omelets, quesadillas, and more.</p>