

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Peakeep](#) /

› [Peakeep Large Display Digital Alarm Clock User Manual \(Model MHP6060\)](#)

Peakeep MHP6060

Peakeep Large Display Digital Alarm Clock

Model: MHP6060

Brand: Peakeep

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Peakeep Large Display Digital Alarm Clock, Model MHP6060. This clock is designed to offer clear time display, reliable alarm functions, and convenient features for various environments such as bedrooms, living rooms, and offices. Key features include a large, dimmable display, adjustable alarm volume, automatic Daylight Saving Time (DST) adjustment, a USB charging port, and battery backup for settings and alarm functionality during power outages.

WHAT'S IN THE Box

- Peakeep Large Display Digital Alarm Clock (Model MHP6060)
- Type C Power Adapter
- User Manual

Note: 4 AAA batteries are required for battery backup functionality and are not included.

SETUP

1. Power Connection

Connect the included Type C power adapter to the "Type C 5V IN" port on the back of the clock and plug it into a standard wall outlet. The clock display will illuminate.

Easy to Set

Power Source (included)



Image: Rear view of the alarm clock with power input and USB output ports highlighted. The included Type C adapter is shown connected to the power input.

2. Battery Backup Installation

For battery backup, insert 4 AAA batteries (not included) into the battery compartment on the back of the clock. This ensures that time settings and alarm functions are retained during a power outage. The display will not remain continuously lit on battery power alone; pressing the top of the clock will temporarily illuminate the display for 20 seconds.

Electric Alarm Clock with USB Charger



Battery Backup: Alarm Still Works When Power Outages

4 AAA Batteries
Required (not included)



Image: Illustration of the clock's power source (Type C adapter) and battery backup feature. It shows that with battery backup, the alarm still functions during a power outage, and the display can be temporarily lit by pressing the top.

3. Initial Time Setting

Upon first power-up, the clock may display a default time. Refer to the "Operating Instructions" section for detailed steps on setting the current time and date.

OPERATING INSTRUCTIONS

Time and Date Display

The clock features a large digital display showing the time, day of the week, and date. The time can be displayed in 12-hour (with AM/PM indicator) or 24-hour (military) format.



Image: The main product image of the Peakeep digital alarm clock, showing a large display with time (12:59 AM), day of the week (WED), and date (12.24), along with an 'AUTO DST' indicator.

Digital Alarm Clock Large Display

(Plug in, Not Battery Operated)



day of the week



DST



date



Plug in

Image: The digital alarm clock's large display showing time, day of the week, and date. Icons below indicate its features: day of the week, Daylight Saving Time (DST), date, and plug-in operation.

Setting Time and Date

1. Press the **TIME SET** button on the back of the clock.
2. Use the **+** and **-** buttons to adjust the hour. Press **TIME SET** again to confirm.
3. Repeat the process for minutes, year, month, and day.
4. Press **TIME SET** one last time to exit time setting mode.

Alarm Setting

1. Press the **ALARM SET** button on the back.
2. Use the **+** and **-** buttons to set the desired alarm hour. Press **ALARM SET** to confirm.
3. Repeat for alarm minutes.
4. Press **ALARM SET** again to exit alarm setting mode.
5. To activate/deactivate the alarm, press the **ON/OFF** button (often combined with **DIMMER**). An alarm icon will appear/disappear on the display.

Alarm Volume Adjustment

The alarm features 5 adjustable volume levels, from gentle to very loud, suitable for light to heavy sleepers.

1. While the alarm is sounding, or in alarm setting mode, press the **VOLUME** button.
2. Use the **+** and **-** buttons to cycle through the 5 volume levels (U01 to U05).
3. The selected volume will be indicated on the display.



Image: Visual representation of the alarm volume settings, showing sound intensity from 60dB (light sleepers) to 103dB (heavy sleepers). The clock display indicates the current volume level (U01-U05).

Snooze Function

When the alarm sounds, press the large **SNOOZE/LIGHT** button on the top of the clock to activate the 9-minute snooze function. The alarm will sound again after 9 minutes.

Display Brightness Adjustment (Dimmer)

The clock offers 6 brightness levels, including an option to turn the display completely off, to suit various lighting conditions and personal preferences.

1. Press the **DIMMER** button (often combined with ON/OFF) on the back of the clock to cycle through the

brightness levels (L5, L4, L3, L2, L1, OFF).

2. Select the desired brightness for day or night viewing.



Image: A visual guide demonstrating the six adjustable brightness levels (L5 to OFF) of the clock's display, allowing users to customize visibility for various ambient light conditions.

Automatic Daylight Saving Time (DST)

The clock features an automatic DST function, eliminating the need for manual adjustments during seasonal time changes.

1. Press the **DST ON/OFF** button on the back of the clock to enable or disable this feature.
2. When enabled, the clock will automatically adjust for "Spring Forward" and "Fall Back" time changes.

Eliminate the Hassle of Changing Time Twice A Year

Daylight Saving Time



Spring Forward



Fall Back

Image: Diagrams illustrating the automatic adjustment for Daylight Saving Time, showing how the clock transitions during "Spring Forward" (advancing one hour) and "Fall Back" (reverting one hour).

USB Charging Port

A USB-A charging port is located on the back of the clock, allowing you to charge your mobile devices while you sleep, saving outlet space.

- Connect your device's USB charging cable to the **USB OUT** port on the back of the clock.
- Ensure the clock is powered via the Type C adapter for charging functionality.

MAINTENANCE

- **Cleaning:** Wipe the clock's surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- **Power:** Always use the provided Type C power adapter. If replacing batteries for backup, ensure they are

new AAA alkaline batteries and inserted with correct polarity.

- **Placement:** Place the clock on a stable, flat surface away from direct sunlight, excessive heat, or moisture.

TROUBLESHOOTING

Clock Display is Blank or Not Working

- Ensure the Type C power adapter is securely plugged into both the clock and a working wall outlet.
- Check if the display brightness is set to "OFF". Press the **DIMMER** button to adjust.
- If using battery backup, the display will only light up for 20 seconds when the top **SNOOZE/LIGHT** button is pressed. This is normal operation for battery-only mode.

Alarm Does Not Sound

- Verify that the alarm is activated (alarm icon visible on display). If not, press the **ON/OFF** button to enable it.
- Check the alarm volume setting. Ensure it is not set to U00 or a very low level. Adjust using the **VOLUME** button.
- Confirm the alarm time is set correctly.
- If a power outage occurred and batteries are not installed or are depleted, the alarm may not sound.

Time is Incorrect

- Manually reset the time and date as described in the "Operating Instructions" section.
- If DST is enabled, ensure it is functioning correctly during time changes. If issues persist, try toggling the **DST ON/OFF** button.
- If the clock loses time frequently, ensure a stable power connection and fresh AAA batteries for backup.

USB Charging Not Working

- Ensure the clock is powered by the Type C adapter, not just battery backup. The USB charging port requires external power.
- Check the USB cable and the device being charged for proper connection and functionality.

SPECIFICATIONS

Brand	Peakeep
Model Number	MHP6060
Color	White and Blue
Display Type	Digital
Style	Modern

Special Features	Corded Electric, Large Display with Date Day of Week, Auto DST, 6 Dimmer, Loud Alarm (5 levels of Volume), 1 USB Port, Battery Backup
Product Dimensions	9"W x 2.6"H
Power Source	Corded Type C Adapter (included)
Battery Requirement	4 AAA batteries (not included) for backup
Room Type	Bedroom, Living Room, Classroom, Dining Room, Home Office, Kid's Room, Kitchen, Study Room
Material	Plastic
Mounting Type	Tabletop
Item Weight	9.6 ounces (0.6 Pounds)
UPC	850004383858

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase documentation or visit the official Peakeep website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2025 Peakeep. All rights reserved.

For further assistance, please contact Peakeep Customer Service.


Related Documents - MHP6060

 <p>PEAKEEP Digital Clock, Alarm Clock (Model MHP6010-DC)</p> <p>QUESTIONS? Contact: sales@us.myhome.com</p>	<p>Peakeep MHP6010-DC Digital Alarm Clock User Manual</p> <p>User manual for the Peakeep MHP6010-DC digital alarm clock. Covers setup, time/alarm setting, snooze, dimmer, USB port, troubleshooting, and warranty information. Features include a large display, adjustable alarm volume, and battery backup.</p>
--	--



[Peakeep MHP6010-B Battery Operated Digital Alarm Clock User Manual](#)

This manual provides instructions for setting up and using the Peakeep MHP6010-B Battery Operated Digital Alarm Clock, including features like voice activation, adjustable brightness, and alarm volume.



PEAKEEP Night Light Digital Alarm Clock User Manual MHP3235

Comprehensive user manual for the PEAKEEP MHP3235 Night Light Digital Alarm Clock, covering setup, time/date setting, alarm functions, snooze, volume, DST, display dimmer, night light, USB charging, time format conversion, safety, maintenance, and troubleshooting.