

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [JAGJOG](#) /

› [JAGJOG Walking Pad with Incline \(Model JT51\) User Manual](#)

JAGJOG JT51

JAGJOG Walking Pad with Incline (Model JT51) User Manual

Your guide to safe and effective use of your JAGJOG Walking Pad.

1. INTRODUCTION

Thank you for choosing the JAGJOG Walking Pad with Incline, Model JT51. This portable under-desk treadmill is designed to integrate fitness into your daily routine, whether at home or in the office. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and retain it for future reference.



Image: The JAGJOG Walking Pad in light pink, demonstrating its use for both running and as an under-desk treadmill.

2. SAFETY INFORMATION

To ensure safe operation and prevent injury, please observe the following safety precautions:

- Always place the walking pad on a flat, stable surface.
- Ensure adequate clear space around the walking pad (at least 2 feet on all sides) during operation.
- Do not allow children or pets near the walking pad while it is in use.
- Consult a physician before starting any new exercise program.
- Stop exercising immediately if you feel faint, dizzy, or experience pain.
- Keep hands and feet clear of all moving parts.
- Only one person should use the walking pad at a time.
- The maximum user weight capacity is 265 lbs (120 kg).
- Always wear appropriate athletic footwear.
- Unplug the walking pad from the power outlet when not in use or before cleaning/maintenance.

3. PRODUCT OVERVIEW

Key Features:

- **2.5 HP Powerful Motor:** Provides consistent performance with low noise operation (below 45 dB).
- **Adjustable Incline:** Manual 15° incline adjustment for varied workout intensity.
- **Automatic Belt Centering:** Innovative technology keeps the running belt aligned during use.
- **Multi-Layer Running Belt:** 40" x 15.3" anti-slip surface with shock absorption for joint protection.
- **4-in-1 Smart Modes:** Working, Walking, Jogging, and Climb modes.
- **LED Display:** Tracks time, distance, speed, and calories burned.
- **Remote Control:** For easy adjustment of speed and stopping the treadmill.
- **Portable Design:** Lightweight (17 kg) with built-in wheels for easy movement and storage.

2.5HP Powerful Yet Quiet Motor



Low Noise
<45 dB



Weight Capacity
265LBS



0.6-3.8MPH



Image: Illustration highlighting the 2.5 HP motor, low noise operation, 265 lbs weight capacity, and speed range of the walking pad.

Anti-slip & Shock Absorption Design



8 Silicone Shock-Absorbers



Shock absorption running board



5-Layer Non-Slip Running Belt



Knee Protection



Image: Visual representation of the walking pad's anti-slip and shock absorption features, designed for user comfort and safety.

4. SETUP

4.1 Unpacking

1. Carefully remove the walking pad from its packaging.
2. Remove all packing materials and inspect the unit for any damage. If damaged, do not use and contact customer support.

4.2 Placement

- Place the walking pad on a firm, level surface.
- Ensure there is at least 2 feet of clear space behind and on both sides of the walking pad.

4.3 Incline Adjustment

The walking pad features a manual 15° incline adjustment. To activate the incline, locate the incline feet at the rear of the unit and extend them into position. Ensure they are securely locked before use. To return to a flat position, retract the incline feet.

4.4 Power Connection

- Connect the power cord to the walking pad's power input.
- Plug the power cord into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- To power on, press the main power switch located on the unit. The LED display will illuminate.
- To power off, press the main power switch again.

5.2 Remote Control Usage

The included remote control allows you to start, stop, and adjust the speed of the walking pad. Ensure the remote has working batteries.

Clear LED Display & Remote Control

Always keep track of your exercise status



Time



Distance



Speed



Calories



Image: The LED display and remote control, illustrating how to track exercise status including time, distance, speed, and calories.

5.3 LED Display Functions

The LED display provides real-time feedback on your workout:

- **Time:** Duration of your workout.
- **Distance:** Total distance covered.
- **Speed:** Current speed in MPH.
- **Calories:** Estimated calories burned.

5.4 Operating Modes and Speed Adjustment

The walking pad offers four distinct modes:



Image: Visual guide to the adjustable speed and multiple modes available on the walking pad.

- **Working Mode:** Speed range 0.6-1.5 MPH. Ideal for light activity while working at a standing desk.
- **Walking Mode:** Speed range 0.6-1.8 MPH. Suitable for a casual walk or warm-up.
- **Jogging Mode:** Speed range 2.5-3.8 MPH. For increased cardiovascular intensity.
- **Climb Mode:** Utilizes the 15° incline for a more challenging workout, engaging different muscle groups.

Use the speed adjustment buttons on the remote control to increase or decrease the speed within the

specified ranges for each mode.

6. MAINTENANCE

6.1 Cleaning

- Always unplug the walking pad before cleaning.
- Wipe down the unit with a damp cloth. Do not use abrasive cleaners or solvents.
- Keep the display panel dry.

6.2 Belt Alignment

The JAGJOG Walking Pad features automatic belt centering technology. If you notice any persistent belt misalignment, ensure the unit is on a level surface. If issues persist, refer to the troubleshooting section or contact customer support.



Image: Detail of the walking pad's running belt, emphasizing its dimensions and the auto-alignment capability.

6.3 Storage

Due to its compact and lightweight design, the walking pad can be easily stored. It features wheels for convenient movement. Simply slide it under a bed or sofa, or stand it upright in a corner when not in use.

7. TROUBLESHOOTING

If you encounter any issues with your JAGJOG Walking Pad, please refer to the following common solutions:

- **No Power:** Ensure the power cord is securely plugged into both the unit and a working electrical outlet.

Check the main power switch is in the 'ON' position.

- **Remote Control Not Responding:** Check the batteries in the remote control and replace if necessary. Ensure there are no obstructions between the remote and the walking pad's receiver.
- **Belt Slipping or Sticking:** Ensure the walking pad is on a level surface. The automatic belt centering should correct minor issues. If slipping persists, the belt may require lubrication (refer to specific instructions if provided with your unit, or contact support).
- **Unusual Noise:** Stop using the walking pad immediately. Check for any foreign objects caught in the belt or motor area. If the noise persists, contact customer support.
- **Display Not Working:** Ensure the unit is powered on. If the display remains blank or shows errors, try powering off and on again. If the problem continues, contact customer support.

8. SPECIFICATIONS

Feature	Specification
Model Number	JT51
Motor Power	2.5 HP
Speed Range	0.6 - 3.8 MPH
Weight Capacity	265 lbs (120 kg)
Product Dimensions (L x W x H)	106 x 48.5 x 10.6 cm
Item Weight	17 kg
Running Belt Dimensions	40" x 15.3" (approx. 101.6 x 38.8 cm)
Incline Adjustment	Manual 15°
Display Type	LED
Frame Material	Alloy Steel
Power Source	Corded Electric
Included Components	User Manual, Remote Control

9. WARRANTY AND SUPPORT

Your JAGJOG Walking Pad includes a user manual. For specific warranty details, please refer to the documentation provided with your purchase or contact the retailer. For technical support or replacement parts, please contact JAGJOG customer service through the official channels provided at the time of purchase.