

## SANAG B60SPromax

# Sanag B60SPromax Bone Conduction Headphones User Manual

Model: B60SPromax | Brand: SANAG

## 1. INTRODUCTION

Thank you for choosing the Sanag B60SPromax Bone Conduction Headphones. This manual provides essential information for setting up, operating, and maintaining your new headphones. Please read it carefully to ensure optimal performance and longevity of your device.

The B60SPromax features an open-ear design, bone conduction technology, Bluetooth 5.3 connectivity, 64GB of internal memory for standalone music playback, IP68 waterproof and dustproof rating, and up to 10 hours of playback time with magnetic fast charging.

## 2. PRODUCT OVERVIEW AND FEATURES

The Sanag B60SPromax headphones utilize advanced bone conduction technology to deliver audio through your cheekbones, leaving your ears open to ambient sounds. This design enhances situational awareness, making them ideal for outdoor activities and sports.

- **Bone Conduction Technology:** Delivers sound directly to the inner ear through vibrations, ensuring comfort and awareness of surroundings.
- **Open-Ear Design:** Allows you to hear both your audio and the environment, crucial for safety during activities like running or cycling.
- **64GB Internal Memory:** Store up to approximately 10,000 songs directly on the headphones for music playback without needing a connected device.
- **IP68 Waterproof & Dustproof:** Fully submersible up to 2 meters, making them suitable for swimming, showering, and intense workouts.
- **Bluetooth 5.3:** Provides a stable, fast, and efficient wireless connection to your devices.
- **Long Battery Life & Fast Charging:** Enjoy up to 10 hours of continuous playback on a single charge, with quick magnetic charging.



Image: The Sanag B60SPromax headphones are designed for use during swimming, featuring an open-ear design for comfort and situational awareness.

骨伝導イヤフォン  
軽量で快適な着け心地



Image: Easily transfer audio files from your computer to the headphones' 64GB internal memory for offline listening.

## 3. SETUP

### 3.1 Charging the Headphones

Before first use, fully charge your headphones. Use the provided magnetic charging cable. Connect the magnetic end to the charging port on the headphones and the USB-A end to a power adapter (not included) or a computer's USB port.

- **Charging Time:** Approximately 1.5 hours for a full charge.
- **Charging Indicator:** The LED indicator will show charging status (e.g., red for charging, blue for fully charged).

## Free match スタイリッシュなデザイン

マットな質感で、手触りも快適、  
4つのカラーオプション、  
どれもスタイリッシュで目を引く



Image: The magnetic charging port ensures easy and secure connection for rapid charging.

### 3.2 Power On/Off

- **Power On:** Press and hold the Power/Multi-function button for 3 seconds until the LED indicator flashes and you hear a voice prompt.
- **Power Off:** Press and hold the Power/Multi-function button for 3 seconds until the LED indicator turns off and you hear a voice prompt.

### 3.3 Bluetooth Pairing

To connect your headphones to a Bluetooth-enabled device:

1. Ensure the headphones are powered off.
2. Press and hold the Power/Multi-function button for 5-7 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Sanag B60SPromax" from the list of found devices.
5. Once connected, the LED indicator will flash blue slowly, and you will hear a confirmation voice prompt.

### 3.4 MP3 Mode (Internal Memory)

To use the internal 64GB memory for music playback:

1. **Transferring Files:** Connect the headphones to your computer using the magnetic charging cable. The headphones will appear as a removable disk. Drag and drop your audio files (MP3, WAV, FLAC, etc.) into the headphone's storage folder. Safely eject the device from your computer after transfer.
2. **Switching to MP3 Mode:** While the headphones are on, double-press the Power/Multi-function button to switch between Bluetooth mode and MP3 mode. A voice prompt will confirm the mode change.

## 4. OPERATING INSTRUCTIONS

### 4.1 Wearing the Headphones

Place the headphones over your ears with the transducers resting on your cheekbones, just in front of your ears. The neckband should rest comfortably behind your head. Adjust for a snug but comfortable fit to optimize sound quality and prevent movement during activity.

## 曲線型イヤーフिटで 運動中でも外れにくい

三角減震デザインで、しっかりフィット





Image: Proper placement of the headphones on the cheekbones ensures optimal sound transmission and comfort.

## 4.2 Button Functions

The headphones feature intuitive physical buttons for easy control:



Image: Detailed view of the headphone controls, showing button locations and their corresponding functions.

Button	Action	Function
Volume Down (-)	Short Press	Decrease Volume
Volume Down (-)	Long Press (Incoming Call)	Reject Call
Volume Down (-)	Double Press	Previous Track
Power/Multi-function	3-second Long Press	Power On/Off
Power/Multi-function	Short Press	Play/Pause Music, Answer/End Call
Power/Multi-function	Double Press	Switch to MP3 Mode / Bluetooth Mode
Volume Up (+)	Short Press	Increase Volume
Volume Up (+)	Double Press	Next Track
Volume Up (+)	1-second Long Press	Activate Voice Assistant (Siri, Google Assistant)

## 5. MAINTENANCE



Proper care will extend the life of your Sanag B60SPromax headphones.

- **Cleaning:** After use, especially after swimming or heavy sweating, rinse the headphones with fresh water and wipe them dry with a soft cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** While IP68 rated, prolonged exposure to saltwater or chlorinated water without rinsing can cause corrosion. Always rinse thoroughly with fresh water after such exposure. Ensure the charging port is dry before charging.
- **Charging Port:** Keep the magnetic charging contacts clean and free of debris.

## 6. TROUBLESHOOTING

If you encounter issues with your headphones, refer to the following common solutions:

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
No sound.	Volume too low; not connected; wrong mode.	Increase volume. Ensure Bluetooth is connected or MP3 mode is active.
Cannot pair with device.	Headphones not in pairing mode; device Bluetooth off.	Ensure headphones are in pairing mode (flashing red/blue). Turn device Bluetooth off and on. Forget device and re-pair.
Poor sound quality.	Improper fit; dirty transducers.	Adjust headphones for a snug fit on cheekbones. Clean transducers.
Files not transferring to internal memory.	Incorrect connection; unsupported file format.	Ensure headphones are properly connected to PC. Check file formats (MP3, WAV, FLAC are supported).

If the problem persists, please contact customer support.

## 7. SPECIFICATIONS

Feature	Detail
Model	B60SPromax
Brand	SANAG
Bluetooth Version	5.3
Internal Memory	64GB
Waterproof Rating	IP68 (up to 2 meters)
Playback Time	Up to 10 hours
Charging Time	Approx. 1.5 hours

Feature	Detail
Battery Capacity	140mAh
Approximate Product Weight	190 g (including packaging)
Manufacturer Model Number	AMZ-B60SPromax64G-FU-JP-CBY

## 8. WARRANTY AND SUPPORT

SANAG is committed to providing high-quality products and customer satisfaction.

- **Warranty:** Your Sanag B60SPromax headphones come with a 360-day warranty from the date of purchase, covering manufacturing defects.
- **Returns:** We offer a 7-day unconditional return policy from the date of receipt.
- **Customer Support:** For any inquiries or support needs, our customer service team aims to respond within 24 hours. Please refer to the contact information provided with your purchase or visit the official SANAG website for support details.



Image: SANAG Care commitment includes a 360-day warranty, 24-hour support response, and 7-day unconditional returns.