

[Manuals.plus](#) /

> [SUNSEEKER](#) /

> SUNSEEKER Replacement Blades for Robot Lawn Mowers (V3, S4, X7, X3 Plus) - Instruction Manual

## SUNSEEKER SK-L-BLADES

# SUNSEEKER Replacement Blades for Robot Lawn Mowers (Models V3, S4, X7, X3 Plus)

Instruction Manual

## PRODUCT OVERVIEW

---

This document provides instructions for the installation and maintenance of SUNSEEKER replacement blades, designed for optimal performance with SUNSEEKER V3, S4, X7, and X3 Plus robotic lawn mowers. These blades are crafted from high-quality stainless steel to ensure precise cutting and durability.

### Key Features

- **Custom Fit:** Compatible with SUNSEEKER V3, S4, L22, Orion X7, and X3 Plus robotic mowers.
- **Complete Set:** Includes 12 blades and 12 screws to support multiple replacements.
- **Sharp & Durable:** Made from high-quality stainless steel for precise cutting and long-lasting use.
- **Easy Installation:** Designed for straightforward DIY blade replacement.

## PACKAGE CONTENTS

---

The package contains the following items:

- 12 x Replacement Blades
- 12 x Mounting Screws




Image: Complete set of SUNSEEKER replacement blades and screws.

## IMPORTANT SAFETY WARNINGS

---

Adhere to the following safety guidelines when handling or replacing blades:

- **WARNING:** Disable the robotic lawn mower before working on or lifting the machine.
- **WARNING:** Never touch the rotating blade.
- **WARNING:** Do not ride on the machine.
- Always wear appropriate protective gloves when handling blades to prevent cuts.
- Ensure the mower is stable and cannot move unexpectedly during blade replacement.

## INSTALLATION INSTRUCTIONS

---

### Blade Replacement Procedure

Follow these steps to safely replace the blades on your SUNSEEKER robotic lawn mower:

1. **Power Off:** Ensure the robotic lawn mower is completely powered off and all safety switches are disengaged before beginning any maintenance.
2. **Wear Protection:** Always wear protective gloves to prevent injury from sharp blades.

3. **Access Blades:** Carefully turn the mower over to access the blade assembly located on the underside.
4. **Remove Old Blade:** Using an appropriate screwdriver, carefully remove the screw securing the old blade.
5. **Dispose Safely:** Remove the old blade and dispose of it safely in a designated container.
6. **Position New Blade:** Place a new SUNSEEKER blade onto the mower's blade disc, aligning the hole with the screw mounting point.
7. **Secure New Blade:** Secure the new blade with a new mounting screw. Tighten firmly, but avoid overtightening to allow the blade to pivot freely as designed.
8. **Repeat:** Repeat steps 4-7 for all blades requiring replacement.
9. **Resume Operation:** Once all blades are replaced, return the mower to its upright position and ensure all safety mechanisms are re-engaged before resuming operation.



Image: A single SUNSEEKER replacement blade.

## MAINTENANCE AND REPLACEMENT

---

### Blade Maintenance Schedule

Regular inspection and replacement of blades are crucial for maintaining optimal cutting performance and ensuring the longevity of your robotic lawn mower. Blades should be inspected weekly during active mowing seasons.

Replace blades when they show signs of wear, dullness, chipping, or damage. Dull blades can tear grass, leading to an unhealthy lawn and increased power consumption for the mower. The included set of 12 blades and 12 screws is designed to support multiple replacement cycles, providing a practical and cost-effective solution for ongoing maintenance.

## PRODUCT SPECIFICATIONS

---

### Technical Specifications

Specification	Detail
Brand	SUNSEEKER
Model Number	SK-L-BLADES
Material	Alloy Steel
Color	Silvery
Item Weight (package)	1.6 ounces

## WARRANTY AND SUPPORT

---

### Warranty Information

SUNSEEKER products are covered by a 2-year warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

### Customer Support

For technical assistance, product inquiries, or warranty support, please contact SUNSEEKER customer support:

- **Email:** [support@sunseekertech.com](mailto:support@sunseekertech.com)
- **Phone:** 1-(833) 822-0146
- **Working Hours:** Monday - Friday, 8 AM - 5 PM EST



Image: SUNSEEKER customer support representative.