

[manuals.plus](#) /› [Vexilar](#) /› **Vexilar Robot Vacuum T6 User Manual**

Vexilar T6

Vexilar Robot Vacuum T6 User Manual

Model: T6

Brand: Vexilar

INTRODUCTION

Thank you for choosing the Vexilar Robot Vacuum T6. This robotic vacuum cleaner is designed to provide an effortless and efficient cleaning experience for your home. Featuring powerful suction, smart navigation, and multiple cleaning modes, the T6 is ideal for both hard floors and low-pile carpets. Please read this manual thoroughly before operating the device to ensure proper use and maintenance.



Image: The Vexilar Robot Vacuum T6, showcasing its sleek black design, accompanied by its remote control and a smartphone displaying the control app interface.

SAFETY INSTRUCTIONS

To reduce the risk of injury or damage, read these safety instructions carefully and keep them handy for future reference.

- The robot vacuum is for indoor use only. Do not use it outdoors or on wet surfaces.
- Do not allow children to operate the vacuum. Supervise children and pets when the vacuum is operating.
- Remove power cords, small objects, and fragile items from the floor before cleaning to prevent entanglement or damage.
- Do not use the vacuum to pick up large debris, liquids, burning or smoking materials, or sharp objects.
- Ensure the charging base is placed against a wall with sufficient clear space around it (1 meter to the left/right, 2 meters in front).
- Do not block the vacuum's air vents or openings.

- Use only the original charging adapter and battery pack provided by the manufacturer.
- Avoid operating the vacuum on high-pile carpets or very dark-colored floors, as this may affect sensor performance.

SETUP

Package Contents

Before setup, verify that all components are present:

- 1 x Vexilar Robot Vacuum Cleaner
- 1 x Charging Dock
- 1 x AC Power Adapter
- 1 x Remote Control
- 2 x HEPA Filters
- 1 x Cleaning Tool
- 4 x Side Brushes
- 1 x User Manual

Powerful Pick Up With Roller Brush



Image: An illustration showing all items included in the Vexilar Robot Vacuum T6 package, such as the robot, charging dock, remote, and various accessories.

Charging Base Placement

Place the charging base on a hard, level surface against a wall. Ensure there is at least 1 meter (3.3 feet) of clear space to the left and right, and 2 meters (6.6 feet) in front of the charging base. This allows the robot to easily dock and undock.




Image: A diagram illustrating the recommended clear space around the charging base for optimal robot vacuum operation.

Initial Charging

Connect the AC power adapter to the charging dock and plug it into a wall outlet. Place the robot vacuum onto the charging dock. The indicator light on the robot will show its charging status. For first-time use, fully charge the robot for at least 6 hours.



Image: The Vexilar Robot Vacuum T6 automatically returning to its charging dock, illustrating its self-charging capability and long runtime.

App and Voice Control Setup

The Vexilar Robot Vacuum T6 can be controlled via the Vactidy app, remote control, or voice commands through Alexa/Siri/Google Assistant. The app only supports 2.4GHz WiFi.

1. Download the Vactidy app from your app market.
2. Add your T6 robot vacuum to the app.
3. Ensure the T6 is on and charging in the charging dock.
4. Press and hold the start button on the robot for 5 seconds.
5. Connect to your 2.4GHz WiFi network.
6. Select and connect to the WiFi network named "SL-V**tidy-XXXX".
7. Wait for the robot to pair successfully.





Image: A visual guide detailing the step-by-step process for connecting the Vexilar Robot Vacuum T6 to its mobile application.

OPERATING

Cleaning Modes

The Vexilar Robot Vacuum T6 offers versatile cleaning modes to suit different needs:

- **Auto Cleaning:** The robot intelligently navigates and cleans the entire area.
- **Spot Cleaning:** Focuses on a specific dirty area, cleaning in a spiral pattern.
- **Edge Cleaning:** Cleans along walls and furniture edges.
- **Room Clean:** Cleans a designated room.



Versatile Cleaning Modes

Image: Visual representation of the Vexilar Robot Vacuum T6's various cleaning modes, including Zigzag, Random, Spot, and Edge cleaning patterns.

Scheduling and Control

You can set cleaning schedules, change cleaning modes, and adjust suction power via the Vactidy App. The robot also supports voice commands through Amazon Alexa, Siri, and Google Assistant for convenient control.



Image: A composite image demonstrating control options for the Vexilar Robot Vacuum T6, including remote control, voice control via smart assistants, and app-based scheduling.

Carpet Boost Technology

The T6 features Carpet Boost technology, allowing it to climb up to 15° and effectively transition between hard floors and low-pile carpets, adjusting suction as needed for optimal cleaning.



Auto Carpet Boost

Image: The Vexilar Robot Vacuum T6 demonstrating its auto carpet boost feature, seamlessly transitioning from a hard floor to a carpeted surface.


Powerful Suction

Equipped with a brushless motor, the T6 delivers up to 2000Pa max suction, efficiently picking up debris, pet hair, and food scraps. The roller brush design ensures high cleaning efficiency.



2000Pa Powerful Suction

Image: The Vexilar Robot Vacuum T6 on a wooden floor, surrounded by colorful debris, with an overlay highlighting its 2000Pa powerful suction capability.



Powerful Pick Up With Roller Brush

Image: A comparison showing the Vexilar Robot Vacuum T6's roller brush effectiveness versus a suction-only port, emphasizing its superior debris pickup.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Vexilar Robot Vacuum T6.

Dustbin and Filter Cleaning

1. Press the dustbin release button and pull out the dustbin.

2. Empty the dustbin contents into a trash can.
3. Remove the HEPA filter and sponge filter. Tap them gently to remove dust. Do not wash HEPA filters with water.
4. Rinse the dustbin with water if necessary, ensuring it is completely dry before reinserting.
5. Reinstall the filters and dustbin.

Brush Cleaning

- **Roller Brush:** Remove the main brush cover and lift out the roller brush. Use the cleaning tool to cut and remove any hair or debris wrapped around the brush.
- **Side Brushes:** Periodically check side brushes for wear or damage. If necessary, remove and clean them. Replace if bristles are bent or missing.

Sensor Cleaning

Wipe the anti-drop sensors, anti-collision sensors, and charging contacts on the robot and charging base with a clean, dry cloth. This ensures proper navigation and docking.



Image: Top and bottom views of the Vexilar Robot Vacuum T6, highlighting its compact design and the location of its brushes and sensors for maintenance.

TROUBLESHOOTING

If you encounter issues with your Vexilar Robot Vacuum T6, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Robot does not turn on or respond.	Low battery; power switch off; charging issue.	Ensure robot is fully charged. Check if the main power switch is ON. Verify charging contacts are clean and connected.
Robot gets stuck frequently.	Obstacles; high-pile carpet; dirty sensors.	Clear obstacles (cords, small items). Avoid using on high-pile carpets. Clean anti-collision and anti-drop sensors.
Poor cleaning performance.	Full dustbin; clogged filter; worn brushes.	Empty dustbin. Clean or replace filters. Clean or replace main and side brushes.

Problem	Possible Cause	Solution
Cannot connect to Wi-Fi/App.	Incorrect Wi-Fi band; wrong password; app error.	Ensure your Wi-Fi is 2.4GHz. Double-check Wi-Fi password. Restart robot and router. Reinstall app if necessary.
Unusual noise during operation.	Debris in brushes; foreign object.	Check and clean main brush and side brushes for tangled hair or debris. Remove any foreign objects.

SPECIFICATIONS

Feature	Detail
Brand	Vexilar
Model Name	Nimble
Item Model Number	T6
Special Feature	Ultra-Quiet Cleaning, Suitable for Hardwood Floor & Low Pile Carpet
Color	Black
Product Dimensions	16"L x 13"W x 4.5"H
Item Weight	7 pounds
Filter Type	Sponge
Battery Life	100 minutes
Voltage	12 Volts
Dustbin Capacity	0.5 Liters
Compatible Devices	Amazon Echo, Google Home, Smartphones

WARRANTY AND SUPPORT

Vexilar provides a standard warranty for the Robot Vacuum T6 against defects in materials and workmanship under normal use. Please refer to the warranty card included in your package for specific terms and conditions, including warranty period and coverage details.

For technical support, troubleshooting assistance, or warranty claims, please contact Vexilar customer service through the contact information provided on the official Vexilar website or your purchase platform. When contacting support, please have your model number (T6) and purchase details ready.