

TOKIT 1.5 L Mini Rice Cooker

TOKIT 1.5L Mini Rice Cooker Instruction Manual

Model: 1.5 L Mini Rice Cooker

1. INTRODUCTION

Thank you for purchasing the TOKIT 1.5L Mini Rice Cooker. This appliance is designed to simplify your cooking experience with its versatile functions and user-friendly design. Please read this manual thoroughly before use to ensure safe and optimal performance.



Image 1.1: Front view of the TOKIT 1.5L Mini Rice Cooker.

2. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.

- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for household use only.

3. PRODUCT COMPONENTS

The TOKIT 1.5L Mini Rice Cooker comes with the following components:

- Rice Cooker Main Unit
- Non-stick Ceramic Coated Inner Pot
- Rice Spatula
- Measuring Cup
- Power Cord

Tiny Powerhouse, Big Convenience



Included Accessories



Rice Paddle



Measuring Cup



Inner Pot

Image 3.1: The rice cooker main unit, rice paddle, measuring cup, and inner pot.



Image 3.2: The ceramic-coated non-stick inner pot.

4. BEFORE FIRST USE

1. Remove all packaging materials and labels.
2. Wash the inner pot, rice spatula, and measuring cup with warm, soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the rice cooker main unit with a damp cloth. Do not immerse the main unit in water.
4. Ensure all parts are completely dry before assembly and use.

5. OPERATION INSTRUCTIONS

General Cooking Steps

1. **Prepare Ingredients:** Measure the desired amount of rice using the provided measuring cup. Rinse rice thoroughly under cold water until the water runs clear.
2. **Add to Inner Pot:** Place the rinsed rice into the ceramic-coated inner pot. Add the appropriate amount of water according to the cooking guide below.
3. **Place Inner Pot:** Insert the inner pot into the rice cooker main unit, ensuring it sits correctly.
4. **Close Lid:** Close the lid securely.
5. **Connect Power:** Plug the power cord into the rice cooker and then into a wall outlet.
6. **Start Cooking:** After plugging in, wait approximately 7 seconds. Then, gently press down on the center of the lid. The display will illuminate, and the cooking process will begin. If the lid is pressed within 7 seconds, it may open automatically.
7. **Automatic Keep Warm:** Once cooking is complete, the rice cooker will automatically switch to the Keep Warm function.

Image 5.1: Initiating cooking by pressing the lid.



Image 5.2: Digital display showing cooking functions.

Cooking Functions

The TOKIT Mini Rice Cooker offers 8 cooking functions:

- **White Rice:** Standard cooking for white rice.
- **Quick Cook:** Faster cooking cycle for white rice, ideal for 1 cup.
- **Brown Rice:** Optimized cooking for brown rice.
- **Congee:** For preparing rice porridge.
- **Stew Soup:** For cooking soups and stews.
- **Hot Pot:** For hot pot preparations.
- **Steaming:** For steaming vegetables or other foods.
- **Keep Warm:** Automatically activates after cooking to maintain food temperature.

One Cooker, Countless Dishes

Multiple cooking options to suit different needs



Image 5.3: Examples of dishes prepared using the rice cooker's various functions.

Cooking Process Flow

Set It & Savor – Smart Tech Does the Work

From undercooked to overachiever:
Perfect rice, zero effort

TOKIT



Image 5.4: Overview of the cooking process.

6. COOKING GUIDE (RICE & WATER RATIOS)

The following table provides general guidelines for rice and water ratios. Adjust according to personal preference and rice type.

Rice Type	Rice (Measuring Cups)	Water (Measuring Cups)	Approx. Cook Time
White Rice	1	1.2 - 1.5	45-60 min
White Rice (Quick Cook)	1	1.2 - 1.5	30 min
Brown Rice	1	1.5 - 2	60-90 min
Congee	0.5	4 - 5	60-90 min

Note: The provided measuring cup is typically 180ml. The capacity of this cooker is 3 cups uncooked / 6 cups cooked rice.

7. CARE AND CLEANING

Proper cleaning ensures the longevity and hygiene of your rice cooker.

Cleaning the Inner Pot and Accessories

- Always unplug the rice cooker and allow it to cool completely before cleaning.
- Remove the inner pot, rice spatula, and measuring cup.
- Wash these parts with warm, soapy water using a soft sponge or cloth. Do not use abrasive cleaners or metal scouring pads, as this can damage the non-stick ceramic coating.
- Rinse thoroughly and dry completely before storing or next use.

Cleaning the Main Unit

- Wipe the exterior of the main unit with a damp cloth.
- Do not immerse the main unit in water or any other liquid.
- Ensure no water enters the electrical components.
- Clean the steam vent area with a small brush if necessary to prevent blockages.

8. TROUBLESHOOTING

If you encounter issues with your rice cooker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice is undercooked/hard	Insufficient water; lid not properly closed; power interruption.	Add more water next time; ensure lid is sealed; check power connection.
Rice is overcooked/mushy	Too much water; incorrect rice type setting.	Reduce water next time; select appropriate cooking function.
Cooker does not start	Not plugged in; lid not pressed correctly; inner pot not seated.	Check power cord; ensure 7-second wait then press center of lid; verify inner pot placement.
Water overflows during cooking	Too much water; too much rice; steam vent blocked.	Reduce water/rice quantity; clean steam vent.
Display not working	Power issue; internal malfunction.	Check power connection. If issue persists, contact customer support.

9. SPECIFICATIONS

Feature	Specification
Brand	TOKIT
Model Name	1.5 L Mini Rice Cooker
Capacity	1.5 Liters (3 cups uncooked / 6 cups cooked)
Product Dimensions	8.4"D x 8.4"W x 7.7"H
Power Source	Corded Electric

Feature	Specification
Wattage	400 watts
Voltage	120 Volts
Material	Plastic (Exterior), Ceramic Coated (Inner Pot)
Special Feature	Non-Stick Inner Pot
Item Weight	4.8 Pounds

10. WARRANTY AND SUPPORT

For warranty information or technical support, please contact TOKIT customer service. Refer to the product packaging or the official TOKIT website for contact details. Please have your model name and purchase date available when contacting support.