

kaitol 1800W Air Fryer B0DNJVLLT3

Kaitol 1800W Air Fryer User Manual

Model: 1800W Air Fryer with Glass Basket and Viewing Window

1. INTRODUCTION

Thank you for choosing the Kaitol 1800W Air Fryer. This appliance uses rapid hot air circulation technology to cook your favorite foods with little to no oil, resulting in crispy and delicious meals. This manual provides important information on how to safely and effectively use, maintain, and troubleshoot your air fryer.

The Kaitol Air Fryer features a transparent glass basket, allowing you to monitor your food's cooking progress without opening the drawer, ensuring consistent heat and energy efficiency. It offers convenient handling with an intuitive LED touch screen and pre-programmed settings for various dishes.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
 - Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
 - Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
 - Do not use appliance for other than intended use.
 - Ensure the glass basket is properly inserted before operating.
 - The appliance has an automatic shut-off feature for safety.
-

3. PRODUCT COMPONENTS

Your Kaito Air Fryer comes with the following main components:

- Main Air Fryer Unit with Control Panel
- Removable Glass Cooking Basket
- Removable Grill Plate (Crisping Plate)
- User Manual



Glas-Frittierbehälter für optimale Kochergebnisse

Klare Sichtfenster zur Überwachung des Fortschritts

Image: The main Kaitol Air Fryer unit, showcasing its sleek design and the transparent glass basket.

4. INITIAL SETUP

1. **Unpack the Appliance:** Carefully remove the air fryer and all its components from the packaging.
2. **Remove Packaging Materials:** Ensure all packaging materials, stickers, and labels are removed from the appliance.
3. **Clean Components:** Wash the glass cooking basket and the grill plate thoroughly with warm soapy water. Rinse and dry them completely. The basket and grill plate are also dishwasher safe.
4. **Wipe Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
5. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface, away from walls or other appliances to allow for proper air circulation.
6. **Power Connection:** Plug the power cord into a grounded wall outlet.

5. OPERATING INSTRUCTIONS

5.1 Control Panel Overview

The Kaitol Air Fryer features an intuitive LED touch screen for easy operation. The control panel allows you to select pre-set programs, adjust temperature, and set the cooking timer.



Image: Illustration of the air fryer's LED touch control panel, highlighting its user-friendly interface.

5.2 Basic Operation

1. **Prepare Food:** Place your ingredients into the glass cooking basket, ensuring not to overfill. For best results, do not exceed the MAX fill line.
2. **Insert Basket:** Slide the glass basket firmly into the main unit.
3. **Power On:** Press the power button to turn on the appliance. The LED display will illuminate.
4. **Select Program or Manual Settings:**
 - **Pre-set Programs:** Choose from 5 pre-programmed menus: Fries, Chicken, Steak, Pizza, and Nuts. Simply touch the corresponding icon. The appliance will automatically set the optimal temperature and

time.

- **Manual Settings:** To manually adjust, use the temperature control buttons (60°C to 200°C) and the timer control buttons (1 to 70 minutes).

5. **Start Cooking:** Press the start button to begin the cooking process.
6. **Monitor Cooking:** Utilize the transparent glass basket and internal illumination to monitor your food without interrupting the cooking cycle.
7. **Keep Warm Function:** After cooking, you can activate the unique 'Keep Warm' mode to maintain your food at an ideal serving temperature until ready.
8. **Automatic Shut-off:** The air fryer will automatically shut off and emit an audible signal when the cooking cycle is complete.
9. **Remove Food:** Carefully pull out the glass basket using the handle. Use heat-resistant tongs to remove the cooked food.

5.3 Tips for Best Results

- For even cooking, shake the basket halfway through the cooking time, especially for smaller items like fries or nuggets.
- Preheating the air fryer for 3-5 minutes can improve cooking results for some foods.
- Lightly spray or brush food with oil for extra crispiness, though it's often not necessary.
- The 'Nuts' mode is specifically designed for drying foods like fruits or other dry snacks, not for roasting nuts.

Schnelles Kochen, knuspriger Geschmack



360°-Heißluftzirkulation



Temperaturbereich von
60°C bis 200°C



1800W für effizientes Garen



Image: The Kaitol Air Fryer shown preparing a variety of dishes, demonstrating its versatility.

360°-Heißluftzirkulation

Gleichmäßige Knusprigkeit und goldbraune Farbe



Image: Diagram illustrating the 360-degree hot air circulation technology for even cooking and crispiness.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer. Always unplug the appliance and allow it to cool completely before cleaning.

- **Glass Basket and Grill Plate:** The glass cooking basket and grill plate are dishwasher safe. Alternatively, they can be washed by hand with warm soapy water and a non-abrasive sponge. The non-stick coating ensures easy cleaning.
- **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads, as these can damage the surface. Never immerse the main unit in water or any other liquid.
- **Interior:** For the interior of the appliance, wipe with a damp cloth. If necessary, use a mild detergent.
- **Heating Element:** Clean the heating element with a cleaning brush to remove any food residue.
- **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.



Image: Visual guide demonstrating the easy cleaning process for the air fryer's components, highlighting dishwasher compatibility and BPA-free materials.

LEICHT ZU REINIGEN

Maschinenwäsche & Handan Washi



Hinweis: Der Antihftkorb und die Crisping-Platte sind mit einer Antihftbeschichtung versehen. Verwenden Sie zum Schrubben der Antihftbeschichtung keine rauen Tücher oder harten Gegenstände.

Image: Close-up of the air fryer basket being cleaned under running water, emphasizing its non-stick properties and ease of maintenance.

7. TROUBLESHOOTING GUIDE

If you encounter any issues with your Kaitol Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
The air fryer does not turn on.	The appliance is not plugged in. The power outlet is not working.	Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker.
Food is not cooked evenly.	Basket is overloaded. Food pieces are too large. Not shaking the basket.	Do not overload the basket. Cut food into smaller, more uniform pieces. Shake the basket halfway through cooking.

Problem	Possible Cause	Solution
Food is not crispy.	Not enough oil (if desired). Temperature too low or cooking time too short.	Lightly brush or spray food with a small amount of oil. Increase temperature or cooking time as needed.
White smoke comes from the appliance.	Grease residue from previous use. Excess oil on food.	Clean the basket and grill plate thoroughly after each use. Remove excess oil from food before air frying.
The basket does not slide into the appliance properly.	Basket is not aligned correctly.	Ensure the basket is empty and aligned properly before pushing it into the main unit. Do not force it.

8. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	kaitol
Model	1800W Air Fryer (ASIN: B0DNJVLLT3)
Power	1800 W
Voltage	220-240 V
Frequency	50 Hz
Capacity	6 Liters
Temperature Range	60°C - 200°C
Timer Range	1 - 70 minutes
Inner Pot Material	Non-stick coating
Shell Material	Polypropylene and Stainless Steel
Heating Method	Three-dimensional ambient heating (360° Hot Air Circulation)
Dimensions (L x W x H)	31 x 27 x 27 cm
Weight	4.72 kg
Special Features	Automatic Shut-off, Viewing Window, 5 Pre-set Menus, Keep Warm Function



Image: The 6-liter capacity glass basket filled with fries, illustrating the generous cooking volume.

9. WARRANTY AND CUSTOMER SUPPORT

Kaitol is committed to providing high-quality home appliances and excellent customer service. While specific warranty details are not provided in this manual, we offer 24/7 customer support to assist you with any questions or concerns regarding your air fryer.

For assistance, please refer to the contact information provided with your purchase or visit the official Kaitol website. Our dedicated team is always available to provide prompt and satisfactory responses.

