



Manuals.plus /

› Netzu /

› Netzu KID28B Digital Alarm Clock with Night Light User Manual

Netzu KID28B

Netzu KID28B Digital Alarm Clock with Night Light User Manual

Model: KID28B

INTRODUCTION

Thank you for purchasing the Netzu KID28B Digital Alarm Clock with Night Light. This manual provides detailed instructions for setting up, operating, and maintaining your new alarm clock. Please read this manual thoroughly before use to ensure proper function and longevity of the product.

PRODUCT OVERVIEW

The Netzu KID28B is a versatile digital alarm clock designed for bedrooms, featuring a dimmable display, a soft night light, multiple alarm tones, a snooze function, and a nap timer. It also includes a child lock feature for added security.



Image: Front view of the Netzu KID28B Digital Alarm Clock, showing the time display and the toast-shaped night light illuminated.

PACKAGE CONTENTS

- Netzu KID28B Digital Alarm Clock
- Power Adapter
- USB Power Cable
- User Manual (this document)
- CR2025 Battery (pre-installed for memory function)

MAINS POWERED ALARM CLOCK

Reliable power supply and emergency
battery memory function



Plug-in Use

- ◀ Comes with a plug and power cable



Battery Memory

- ◀ Included 1*CR2025 cell battery

Image: The Netzu KID28B alarm clock alongside its power adapter, USB cable, and user manual, illustrating the product's dimensions.

SETUP

1. Power Connection

1. Connect the USB power cable to the alarm clock.
2. Plug the power adapter into a standard electrical outlet.
3. The clock display will illuminate, indicating it is powered on.

The alarm clock operates primarily via mains power. A pre-installed CR2025 battery provides memory backup for settings during power outages.

KIDS ALARM CLOCK

Ideal gifts for your loved ones



ALARM CLOCK



NIGHT LIGHT



NAP TIMER



CHILD LOCK

Image: The alarm clock connected to a wall outlet via its power cable, demonstrating its mains power operation and highlighting the internal battery for memory backup.

2. Initial Time Setting

Upon first power-up or after a prolonged power loss without battery backup, you may need to set the current time. Refer to the "Setting Time and Date" section under Operating Instructions for detailed steps.

OPERATING INSTRUCTIONS

1. Setting Time and Date

(Specific button names are not provided in the input, so using generic terms)

1. Press and hold the **"SET"** button (or equivalent) to enter time setting mode.
2. Use the **"+"** and **"-"** buttons (or equivalent) to adjust the hour.
3. Press **"SET"** again to move to minute adjustment, then adjust with **"+"** and **"-"**.
4. Repeat for year, month, and day settings if available.

5. Press **"SET"** one last time or wait a few seconds for the settings to save automatically.

2. Adjusting Display Brightness

The clock display has 5 levels of brightness. To adjust:

- Locate the **"BRIGHTNESS"** button (or equivalent).
- Press the button repeatedly to cycle through the 5 brightness levels (100%, 75%, 50%, 25%, 0%).



Image: Illustration showing the 5 adjustable brightness levels for both the night light and the digital clock display, from 100% to 0% (off).

3. Night Light Operation

The integrated night light also features 5 brightness levels.

- To turn the night light on/off, press the dedicated **"LIGHT"** button (or equivalent).
- While the night light is on, press the **"LIGHT"** button repeatedly to cycle through its 5 brightness levels.

4. Setting the Alarm

The alarm clock offers 10 unique alarm tones and 10 volume levels.

1. Press the **"ALARM"** button (or equivalent) to enter alarm setting mode.
2. Use **"+"** and **"-"** buttons to set the desired alarm hour.
3. Press **"ALARM"** again to set the alarm minute.
4. Press **"ALARM"** a third time to select an alarm tone. Use **"+"** and **"-"** to cycle through the 10 available tones (e.g., Piano, Beep, Ring, Music, Chime, Lullaby).
5. Press **"ALARM"** a fourth time to adjust the alarm volume (L1-L10).
6. Press **"ALARM"** one last time or wait for the settings to save.
7. To activate/deactivate the alarm, press the **"ALARM ON/OFF"** button (or equivalent). An alarm icon will appear on the display when active.




Image: Visual representation of the 10 distinct alarm tones available, including Piano, Beep, Ring, Music, Chime, and Lullaby, along with the 10-level volume adjustment.

5. Snooze Function

When the alarm sounds, you can activate the snooze function for an additional 9 minutes of sleep.

- Press the **"SNOOZE"** button (often a prominent button on top, like the "toast" part or a dedicated button) when the alarm is ringing.
- The alarm will pause for 9 minutes and then sound again.
- You can repeat the snooze function multiple times.
- To turn off the alarm completely, press any other button (e.g., **"ALARM ON/OFF"** or **"SET"**).



Image: A child sleeping next to the alarm clock, with an inset showing a finger pressing the "toast" part of the clock, indicating its function as the snooze button for a 9-minute delay.

6. Nap Timer

The nap timer allows you to set a countdown for various activities, ranging from 15 to 120 minutes.

1. Press the **"NAP TIMER"** button (or equivalent).
2. Use "+" and "-" buttons to select the desired duration: 15, 30, 60, 90, or 120 minutes.
3. The timer will begin counting down.
4. When the timer reaches zero, an alert will sound.

5. To turn off the nap timer alert, press any button. To cancel the timer before it finishes, press the **"NAP TIMER"** button until "OFF" is displayed.

NAP TIMER

Better manage fragmented schedules.



The image features a collage of three panels illustrating children's activities: a toddler playing with toys, a child drawing on a large sheet of paper, and a child sleeping in a bed. Below the collage is a pink nap timer device with a digital display showing '14:00'. To the left of the timer, a horizontal timeline displays timer options: 15 min, 30 min, 60 min, 90 min, 120 min, and OFF.

Image: Three panels showing children engaged in different activities (playing, drawing, sleeping), illustrating the versatility of the nap timer. Below, the timer options (15, 30, 60, 90, 120 minutes, and OFF) are displayed.

7. Child Lock Function

The child lock feature prevents accidental changes to settings while allowing access to the night light and display brightness adjustments.

- To activate the child lock, press and hold the **"LOCK"** button (or equivalent) for 3 seconds. A lock icon will appear on the display.
- In child lock mode, all functions except night light and display brightness adjustments are disabled.
- To deactivate the child lock, press and hold the **"LOCK"** button again for 3 seconds. The lock icon will disappear.

MAINTENANCE

Cleaning

- Ensure the device is unplugged before cleaning.
- Wipe the surface with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.
- Avoid getting moisture into any openings.

Battery Replacement (Memory Backup)

The CR2025 battery is for memory backup only. If settings are lost frequently during power outages, the battery may need replacement.

1. Unplug the alarm clock from the power source.
2. Locate the battery compartment on the underside of the unit.
3. Open the compartment and replace the old CR2025 battery with a new one, ensuring correct polarity.
4. Close the compartment securely.
5. Dispose of the old battery responsibly according to local regulations.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------------------------------------|--|--|
| Clock display is off or not working. | No power supply; power adapter faulty; display brightness set to 0%. | Check power connection. Ensure adapter is working. Increase display brightness. |
| Alarm does not sound. | Alarm not activated; alarm volume set to L0; incorrect alarm time set. | Ensure alarm is active (icon visible). Increase alarm volume. Verify alarm time. |
| Settings are lost after power outage. | CR2025 memory battery is depleted or missing. | Replace the CR2025 battery. |
| Buttons are unresponsive. | Child lock is activated. | Deactivate the child lock by pressing and holding the "LOCK" button for 3 seconds. |

SPECIFICATIONS

- **Brand:** Netzu
- **Model:** KID28B
- **Color:** Pink
- **Display Type:** Digital
- **Power Source:** Corded Electric (AC adapter included)
- **Memory Backup:** 1x CR2025 battery (included)
- **Product Dimensions:** 16 cm (Width) x 3.81 cm (Depth) x 11 cm (Height)
- **Product Weight:** 310 g
- **Special Features:** Dimmable Display (5 levels), Dimmable Night Light (5 levels), 10 Alarm Tones, 10 Volume Levels, 9-minute Snooze, Nap Timer (15-120 min), Child Lock.
- **Material:** Plastic
- **Room Type:** Kids' Room

WARRANTY INFORMATION

Please refer to the warranty card included with your purchase or contact the retailer/manufacturer for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

SUPPORT

For technical assistance, troubleshooting not covered in this manual, or general inquiries, please contact Netzu customer support through the retailer's platform or the contact information provided with your product packaging.

