

DreamSky DS2208

DreamSky DS2208 Wooden Digital Alarm Clock User Manual

Brand: DreamSky | Model: DS2208

INTRODUCTION

Thank you for choosing the DreamSky DS2208 Wooden Digital Alarm Clock. This manual provides detailed instructions to help you set up and operate your new clock effectively. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- Ensure the clock is placed on a stable, flat surface.
- Keep away from water or high humidity environments.
- Do not expose to direct sunlight or extreme temperatures.
- Use only the provided power adapter.
- Keep out of reach of children.

PRODUCT OVERVIEW

The DreamSky DS2208 is a modern digital alarm clock featuring a wooden design, large LED numbers, adjustable brightness, and volume control. It is designed for ease of use and aesthetic appeal in various room settings.

Key Features:

- **Large 1.8-inch LED Numbers:** Easy to read from across the room.
- **6 Dimmable Brightness Levels:** Adjust display intensity for day or night.
- **5 Adjustable Alarm Volume Levels:** Ranging from 70dB to 105dB, suitable for all sleepers.

- **Snooze Function:** Provides an extra 9 minutes of rest.
- **Battery Backup:** Maintains time and alarm settings during power outages (batteries not included).
- **DST (Daylight Saving Time) Button:** One-click adjustment for daylight saving.
- **12/24 Hour Format:** Easily switch between civilian and military time.
- **Plug-in Operation:** Powered by an included adapter for continuous display.



Image: DreamSky DS2208 Wooden Digital Alarm Clock displayed on a nightstand, showing large white LED numbers against a light wooden finish.

SETUP

1. Power Connection:


Connect the included 5V/1.2A power adapter to the DC 5V port on the back of the clock and plug it into a wall outlet. The display will light up.



Image: The DreamSky DS2208 clock on a side table, with its power adapter plugged into a wall socket, illustrating its plug-in operation.

2. Battery Backup (Optional):

For battery backup functionality, insert 3 AAA batteries (not included) into the battery compartment on the back. This ensures that time and alarm settings are saved during a power outage, and the alarm will still function (without display).



OPERATING INSTRUCTIONS

1. Setting the Time:

- Press the **TIME SET** button on the back.
- Use the **HOURL** and **MIN** buttons to adjust the time.
- Press **TIME SET** again to confirm.

2. Setting the Alarm:

The clock supports two independent alarms (AL1, AL2).

- Press the **ALARM SET** button (AL1 SET or AL2 SET).
- Use the **HOURL** and **MIN** buttons to set your desired alarm time.
- Press the corresponding **ALARM SET** button again to confirm.
- To activate/deactivate an alarm, press the **AL1 ON/OFF** or **AL2 ON/OFF** button. An alarm icon will appear/disappear on the display.

3. Adjusting Display Brightness:

The clock offers 6 dimmable brightness levels (L0-L5).

- Use the **DIMMER** button on the back to cycle through brightness levels.
- Alternatively, press the **SNOOZE** button on top to temporarily light up the screen for 10 seconds if the display is off or at a low setting.

Battery backup, no worry for power cut




Image: The DreamSky DS2208 clock illustrating its six adjustable brightness levels, from off to L5, suitable for various lighting conditions.

4. Adjusting Alarm Volume:

The alarm volume can be set to 5 different levels (V1-V5).

- Press the **VOL+** or **VOL-** buttons on the back to adjust the alarm volume.



Image: A person waking up next to the DreamSky DS2208 clock, with an overlay showing the 5 adjustable alarm volume levels (V1-V5).

5. DST (Daylight Saving Time) Adjustment:

- Press the **DST ON/OFF** button on the back to quickly enable or disable Daylight Saving Time.

6. 12/24 Hour Format:

- Press the **12/24HR** button on the back to switch between 12-hour (AM/PM) and 24-hour (military) time formats.

6 different brightness level for different environment



Image: The DreamSky DS2208 clock demonstrating the manual DST adjustment and the switch between 12-hour and 24-hour time formats.

7. Snooze Function:

- When the alarm sounds, press the large **SNOOZE** button on top to pause the alarm for 9 minutes.
- To turn off the alarm completely, press any other button on the back.

8. USB Port:

The USB port on the back is for power input to the clock only. It cannot be used to charge other devices.

MAINTENANCE

- Clean the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping the clock or subjecting it to strong impacts.
- If the clock is not in use for an extended period, remove the backup batteries.

TROUBLESHOOTING

- **Display not lighting up:** Ensure the power adapter is securely plugged into both the clock and a working wall outlet. The display only lights when plugged in.
- **Alarm not sounding:** Check if the alarm is activated (alarm icon visible) and if the volume is set to an audible level. Ensure backup batteries are fresh if relying on battery power during an outage.
- **Incorrect time:** Follow the 'Setting the Time' instructions to reset the time. If using battery backup, ensure batteries are not depleted.

SPECIFICATIONS

Brand	DreamSky
Model Number	DS2208
Color	Bamboo-white
Display Type	Digital

Material	Wood
Product Dimensions	6.1"W x 2.8"H
Power Source	Corded Electric
Battery Backup	Requires 3 AAA batteries (not included)

WARRANTY & SUPPORT

This DreamSky product comes with a **1-year replacement warranty**. For any questions, technical support, or warranty claims, please contact DreamSky customer support at info@dreamsky4u.com.

OFFICIAL PRODUCT VIDEOS

DreamSky Wooden Alarm Clock Big Numbers

Your browser does not support the video tag.

Video: An official product video from DreamSky Direct showcasing the large numbers and overall design of the wooden digital alarm clock.

Easy to Set; Adjustable Brightness

Your browser does not support the video tag.

Video: A short demonstration of how to easily set the clock and adjust its brightness levels.