

Manuals.plus /

› DreamSky /

› DreamSky Wooden Digital Alarm Clock Instruction Manual

## DreamSky DS2208

# DreamSky Wooden Digital Alarm Clock

## INSTRUCTION MANUAL

Model: DS2208 | Brand: DreamSky

### Introduction

---

Thank you for purchasing the DreamSky Wooden Digital Alarm Clock. This modern and elegant clock is designed to provide clear time display, reliable alarm functions, and convenient features for your bedroom, living room, or office. Please read this manual carefully to ensure proper setup and operation.



The DreamSky Wooden Digital Alarm Clock, featuring a clear blue LED display.

## Setup

### Powering the Clock

The DreamSky alarm clock is primarily powered by the included 5V/1.2A power adapter. For continuous time display, ensure the clock is plugged into a power outlet.



The clock requires continuous power via the adapter for display.

### Battery Backup (Not Included)

The clock features a battery backup function that requires 2 AAA batteries (not included). These batteries are for alarm functionality during a power outage and will not power the display. The display will only light up when the clock is plugged in.

## Battery backup, no worry for power cut



Battery backup ensures the alarm works even without power, though the display will be off.

## Operating Instructions

---

### Setting Time and 12/24 Hour Format

Refer to the controls on the back of the clock. Use the designated buttons to set the current time. You can easily switch between 12-hour (AM/PM) and 24-hour (military) time formats with a single step, suiting your preference.



Adjusting time format and Daylight Saving Time (DST).

### Setting the Alarm and Snooze Function

The clock features a loud alarm suitable for heavy sleepers, with an adjustable volume range from 70 to 105dB. Set your desired alarm time using the control buttons. When the alarm sounds, press the 'SNOOZE' button on top of the clock to activate a 9-minute snooze period.

## 5 Level Alarm Volume

No worry to be shocked by the loud alarm or sound too low to hear.



Adjustable alarm volume and snooze feature for extra rest.

### Adjusting Display Brightness

The clock offers 6 dimmable brightness levels (L1-L5 and OFF) to suit various lighting conditions and personal preferences. Adjust the brightness using the dimmer button to ensure it's dark enough for sleep and bright enough for daytime viewing.

# Adjustable Display Brightness

Sleep well at night and see clear at day.



OFF



L1



L2



L3



L4



L5

The display will light up when touch the snooze pad or press the dimmer button once.



Choose from 6 brightness levels for optimal visibility day or night.

## Daylight Saving Time (DST)

A dedicated DST button allows for quick and easy adjustment of the time for Daylight Saving. Simply press the button to toggle DST on or off.

## USB Charging Port

The clock includes a USB port on the back, which can be used as a convenient charging station for your devices.



The back of the clock features a USB charging port.

## Maintenance

---

To maintain the appearance and functionality of your DreamSky Wooden Digital Alarm Clock, follow these simple guidelines:

- **Cleaning:** Wipe the clock with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as they may damage the wood finish or display.
- **Placement:** Place the clock on a stable, flat surface away from direct sunlight, excessive heat, or moisture.
- **Handling:** Handle the clock with care to prevent drops or impacts that could damage internal components.

## Troubleshooting

---

| Problem                             | Possible Cause   | Solution  |
|-------------------------------------|--|---|
| Display is off.                     | Clock is not plugged in or power outage.                                       | Ensure the clock is properly plugged into a working power outlet. During a power outage, the display will be off, but the alarm function will still work if backup batteries are installed. |
| Alarm does not sound.               | Alarm is not set or volume is too low.<br>Batteries are dead or not installed. | Verify the alarm is activated and set to the correct time. Increase the alarm volume. Check and replace AAA backup batteries if necessary.  |
| Time is incorrect after power loss. | No backup batteries or batteries are dead.                                     | Install fresh AAA batteries for time setting backup during power outages. Reset the time manually if batteries were not present or dead.  |
| Display is too bright/dim.          | Brightness level needs adjustment.   | Use the dimmer button to cycle through the 6 brightness levels until the desired illumination is achieved.  |

## Specifications

---

- **Brand:** DreamSky
- **Model Number:** DS2208
- **Color:** Blue
- **Display Type:** Digital
- **Product Dimensions:** 6.1"W x 2.8"H
- **Power Source:** Corded Electric (Adapter Powered)
- **Battery Backup:** Requires 2 AAA batteries (not included) for alarm during power outage.
- **Alarm Volume:** Adjustable from 70dB to 105dB
- **Display Brightness:** 6 dimmable levels (L1-L5, OFF)
- **Time Format:** 12-hour (AM/PM) / 24-hour selectable
- **Special Features:** Large 1.8-inch numbers, Snooze function, DST (Daylight Saving Time) button, USB charging port.
- **Frame Material:** Wood
- **Item Weight:** 9.6 ounces

## Warranty and Support

---

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official DreamSky website. If you encounter any issues not covered in this manual, please contact DreamSky customer service for assistance.