Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- **HEX BOTS** /
- > HEX BOTS Glow-in-The-Dark Gecko Wall Climber Robot Instruction Manual

HEX BOTS 6075822

HEX BOTS Glow-in-The-Dark Gecko Wall Climber Robot Instruction Manual

Model: 6075822

1. Introduction

The HEX BOTS Glow-in-The-Dark Gecko is a remote-controlled robot toy designed to mimic the movement of a real gecko, capable of crawling across floors and scaling smooth vertical surfaces. This model features a glow-in-the-dark design and LED light eyes for enhanced play in low-light conditions. The full-function remote control provides intuitive operation within a range of up to 25 feet (8 meters).

2. WHAT'S IN THE BOX

- 1 HEX BOTS Glow-in-the-Dark Gecko
- 1 Remote Control
- 1 USB Charging Cable
- 1 Instruction Guide



Image: The HEX BOTS Glow-in-the-Dark Gecko, its remote control, and the USB charging cable are displayed on a white background.

3. SETUP

3.1 Remote Control Battery Installation

- 1. Locate the battery compartment on the back of the remote control.
- 2. Using a small Phillips head screwdriver (not included), open the battery compartment.
- 3. Insert 2 AAA batteries (not included), ensuring correct polarity (+/-).
- 4. Securely close the battery compartment with the screw.

3.2 Gecko Charging

- 1. Locate the USB charging port on the underside of the Gecko.
- 2. Connect the included USB charging cable to the Gecko's charging port.
- 3. Connect the other end of the USB cable to a powered USB port (e.g., computer, USB wall adapter).
- 4. The Gecko's LED eyes will indicate charging status (refer to the instruction guide for specific light indicators). Charging typically takes approximately 30 minutes for a full charge.

Your browser does not support the video tag.

Video: An official product video demonstrating the HEX BOTS Glow-in-the-Dark Gecko in action, showcasing its wall-climbing capabilities and glowing features.

4. OPERATING INSTRUCTIONS

4.1 Powering On

- 1. Turn on the Gecko by sliding the power switch located on its underside. The LED eyes will illuminate.
- 2. Turn on the remote control.

4.2 Movement Modes

The Gecko features two primary movement modes: **Floor Mode** and **Wall Mode**. A switch on the Gecko's underside allows you to select the desired mode. For wall climbing, ensure the switch is set to Wall Mode, which activates the suction mechanism.

4.3 Remote Control Functions

Use the directional buttons on the remote control to maneuver the Gecko. It can move forward, backward, left, and right. The remote has a range of approximately 25 feet (8 meters).



Image: The HEX BOTS Gecko, with its purple body and glowing green limbs, is shown alongside its matching remote control.

4.4 Wall Climbing

For optimal wall climbing performance, ensure the surface is smooth and clean. Textured surfaces, such as

certain types of drywall, may reduce the Gecko's ability to maintain suction and climb effectively.



Image: A child uses the remote control to guide the HEX BOTS Gecko as it climbs a light-colored wall, demonstrating its wall-crawling feature.

4.5 Glow-in-the-Dark Feature

The Gecko's green limbs and tail are made of silicone that glows in the dark after exposure to light. The LED eyes also provide illumination, making the toy visible and engaging in dimly lit environments.



Image: The HEX BOTS Gecko is shown on a floor in a dark room, with its green limbs and tail visibly glowing, highlighting its glow-in-the-dark capability.

5. MAINTENANCE

- **Cleaning:** Wipe the Gecko and remote control with a dry, soft cloth. Do not immerse in water or use harsh chemicals.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight when not in use. Remove batteries from the remote control if storing for extended periods.
- Surface Care: Ensure the Gecko's suction pads are clean and free of dust or debris for optimal wall-climbing performance.

6. TROUBLESHOOTING

- **Gecko not moving:** Ensure the Gecko is fully charged and the power switch is in the ON position. Check that the remote control batteries are fresh and correctly installed.
- **Gecko not sticking to walls:** Verify that the Gecko is in Wall Mode. Ensure the wall surface is smooth, clean, and free of texture or dust. The suction mechanism requires a flat, non-porous surface.

• **Reduced remote control range:** Replace the AAA batteries in the remote control. Ensure there are no obstructions between the remote and the Gecko.

7. Specifications

Product Dimensions	12.13 x 2.13 x 8.13 inches
Item Weight	11.2 ounces
Item Model Number	6075822
Manufacturer Recommended Age	4 years and up
Batteries (Remote)	2 AAA batteries required (not included)
Batteries (Gecko)	Rechargeable via USB (cable included)
Manufacturer	Spin Master

8. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the contact details provided on the product packaging or visit the official HEX BOTS website. Keep your purchase receipt as proof of purchase.

Related Documents - 6075822



SAM Your Robotic Friend: Assembly and Instruction Manual

Comprehensive instruction and assembly manual for the SAM Your Robotic Friend robot toy by XTREM BOTS. Includes safety warnings, maintenance tips, parts list, and step-by-step building instructions.



Xtrem Bots Robbie Instruction Manual

Learn how to set up, operate, and enjoy the Xtrem Bots Robbie robot toy with this comprehensive instruction manual. Discover its functions, modes, and smart controls.



Lynxmotion T-HEX Robot Body Assembly Guide

Detailed, step-by-step assembly instructions for the Lynxmotion T-HEX robot body, applicable to both 3DOF and 4DOF models. This guide covers chassis construction, electronic component installation, and basic wiring.



Moose Mountain Walkin' N' Talkin' Big Bots Super Sized User Manual & Operating Guide

Comprehensive user manual for the Moose Mountain Walkin' N' Talkin' Big Bots Super Sized remote control toy, covering operation, battery installation, charging, safety rules, and FCC compliance.



Lakeshore Snap-Bots PP838: Educational Building Toy Guide

A guide to Lakeshore's Snap-Bots (PP838), an educational toy designed to develop motor skills, imagination, and shape recognition through building fun snap-together robots.



RO1 Collaborative Robot User Manual - Standard Bots

This user manual provides comprehensive guidance for the Standard Bots RO1 Collaborative Robot. It covers essential topics including hardware overview, assembly, setup, safety protocols, software operation, and maintenance procedures for industrial automation.