

Netzu K028B

Netzu K028B Digital Alarm Clock User Manual

Model: K028B

INTRODUCTION

Thank you for choosing the Netzu K028B Digital Alarm Clock. This manual provides detailed instructions for setting up, operating, and maintaining your new alarm clock. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.

KEY FEATURES

- Digital Time Display with 5 Brightness Levels
- Integrated Night Light with 5 Brightness Levels
- 10 Selectable Ringtones with 10 Volume Settings
- 9-Minute Snooze Function
- Adjustable Nap Timer (15 to 120 minutes)
- Child Lock Feature to prevent accidental setting changes
- Plug-in Use with CR2025 Battery for Power-Off Memory

SETUP

1. Power Connection

The Netzu K028B Digital Alarm Clock is designed for plug-in use. Connect the provided USB cable to the clock's power port and plug the adapter into a standard electrical outlet. The clock will power on automatically.

MAINS POWERED ALARM CLOCK

Reliable power supply and emergency battery memory function



Plug-in Use

- ◀ Comes with a plug and power cable



Battery Memory

- ◀ Use 2*AAA Batteries (Not included)

Image: The Netzu K028B Digital Alarm Clock connected to a wall outlet via its power cable, illustrating its plug-in operation.

2. Battery Memory Function

A built-in CR2025 battery (not included for initial setup, but typically pre-installed for memory) preserves your time and alarm settings during power outages or when the clock is unplugged. This battery is for memory backup only and does not power the main display or night light.

Battery Memory

Comes with a CR2025 button cell battery

⚠ Note: Batteries are only used to memorise the clock settings.




Image: The underside of the alarm clock, highlighting the CR2025 battery compartment for memory backup.

3. Initial Time Setting

Upon first power-on or after a prolonged power loss without battery backup, the display may show a default time. Refer to the 'Operating Instructions' section for detailed steps on setting the current time.

OPERATING INSTRUCTIONS

The control buttons are located on the back of the alarm clock. Familiarize yourself with their functions:

Icon	Function
SET	Enter/Confirm settings mode
▲ / ▼	Adjust values (Up/Down)
ON/OFF	Turn alarm on/off
12/24	Switch between 12-hour and 24-hour time format
♪	Select alarm ringtone
Zz	Activate Nap Timer
	Activate/Deactivate Child Lock
	Adjust display brightness
	Adjust night light brightness

1. Setting the Time

1. Press and hold the **SET** button until the hour digits flash.
2. Use the ▲ or ▼ buttons to adjust the hour.
3. Press **SET** again to move to minute adjustment. Use ▲ or ▼ to adjust minutes.
4. Press **SET** to confirm and exit time setting.
5. To switch between 12-hour and 24-hour format, press the **12/24** button.

2. Setting the Alarm

1. Press the **SET** button once (do not hold) to enter alarm setting mode. The alarm time will flash.
2. Use ▲ or ▼ to adjust the alarm hour. Press **SET** to confirm.
3. Use ▲ or ▼ to adjust the alarm minute. Press **SET** to confirm.
4. Press the ♪ button to cycle through 10 different alarm ringtones.
5. Use ▲ or ▼ to adjust the alarm volume (10 levels).
6. Press **SET** to save and exit alarm setting.
7. To turn the alarm on or off, press the **ON/OFF** button. An alarm icon will appear/disappear on the display.

10 SOOTHING ALARM TONES WITH 10 VOLUMES

Effectively wakes you up to a refreshed day

Volume adjustable from L1-L10



Image: The alarm clock's display showing different ringtone options and volume settings, indicating customization features.

3. Snooze Function

When the alarm sounds, press the top 'toast' part of the clock or the dedicated snooze button (if available, otherwise the main button used for light/snooze) to activate the 9-minute snooze function. The alarm will temporarily stop and sound again after 9 minutes.



LOVELY SNOOZE BUTTON

Snooze for an extra 9 minutes and wake up refreshed



Image: The alarm clock on a bedside table, with the snooze function indicated by a hand pressing the top 'toast' part.

4. Night Light Operation

The night light is integrated into the 'toast' part of the clock. Press the button to turn the night light on/off. Continue pressing the button to cycle through 5 brightness levels.

DIMMABLE NIGHTLIGHT ALARM CLOCK

Find your most comfortable brightness



Image: The alarm clock functioning as a night light, illustrating its 5 adjustable brightness levels for both the light and the clock display.

5. Display Brightness Adjustment

To adjust the brightness of the digital time display, press the **☀** button. There are 5 brightness levels to choose from, allowing you to find a comfortable setting for day or night.

6. Nap Timer

The nap timer allows you to set a countdown for short periods. Press the **Zz** button to activate the nap timer. Repeatedly press **Zz** to cycle through preset durations: 15, 30, 60, 90, or 120 minutes. The timer will count down and sound an alarm when finished.

NAP TIMER

Better manage fragmented schedules.




Image: The alarm clock displaying various nap timer options, from 15 to 120 minutes, for managing fragmented schedules.

7. Child Lock

To prevent accidental changes to settings, activate the child lock. Press and hold the button until the lock icon appears on the display. In child lock mode, only the night light and screen brightness adjustments are functional. To deactivate, press and hold the button again until the lock icon disappears.

KIDS ALARM CLOCK

Ideal gifts for your loved ones



ALARM CLOCK



NIGHT LIGHT



NAP TIMER



CHILD LOCK

Image: The alarm clock with its various features including child lock, shown alongside its dimensions and accessories.

MAINTENANCE

1. Cleaning

To clean the alarm clock, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the device in water.

Battery Replacement (Memory)

If the clock loses its time and alarm settings immediately after a power outage, the internal CR2025 memory battery may need replacement. Carefully open the battery compartment on the underside of the clock and replace the battery with a new CR2025 cell, ensuring correct polarity.

TROUBLESHOOTING

- **Clock not turning on:** Ensure the power adapter is securely plugged into both the clock and a working electrical outlet.
- **Alarm not sounding:** Verify that the alarm is turned ON (alarm icon visible on display) and the volume is set to an audible level.
- **Settings changing unexpectedly:** Check if the Child Lock feature is deactivated. Activate it to

prevent unintended adjustments.

- **Time/settings reset after unplugging:** The CR2025 memory battery may be depleted or missing. Replace it if necessary.

SPECIFICATIONS

Feature	Detail
Brand	Netzu
Model Number	K028B
Color	Blue
Display Type	Digital
Special Features	Adjustable Brightness, Illuminated Night Light, Nap Timer, Snooze, Child Lock
Product Dimensions	5.51"W x 4.13"H
Power Source	Corded Electric
Memory Battery	CR2025 (for settings backup)
Material	Plastic
Room Type	Bedroom

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Netzu customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.