

Dekala SAC

Dekala Arches Sunrise Alarm Clock User Manual

Model: SAC | Brand: Dekala

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Dekala Arches Sunrise Alarm Clock. Please read this manual thoroughly before using the product to ensure proper function and to maximize your experience with its features.

2. SAFETY INFORMATION

- Ensure the device is placed on a stable, flat surface.
- Do not expose the device to water or excessive moisture.
- Use only the provided power adapter.
- Keep out of reach of children and pets.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.

3. PRODUCT OVERVIEW

The Dekala Arches Sunrise Alarm Clock is a multi-functional device designed to enhance your sleep and wake-up experience. It combines a sunrise alarm, sunset sleep timer, white noise sound machine, ambient lamp, 15W wireless charger, and Bluetooth speaker, all controllable via touch or a dedicated app.



Figure 3.1: Front view of the Dekala Arches Sunrise Alarm Clock, showcasing its design and wireless charging pad.

Key Features:

- **Customizable Sunrise Alarm:** Wake up naturally with simulated sunrise and various natural sounds (bird songs, ocean waves, campfire). Adjustable duration (5-120 minutes) and 120dB alarm volume.
- **White Noise Sound Machine & Sleep Timer:** Offers white, pink, brown noise, and natural sounds (birds, ocean, rain). Sleep timer from 5 minutes to all night with sunset or breathing light effects.
- **Dual-Band WiFi & App Control:** Seamless setup with 2.4G & 5G WiFi compatibility for app control.
- **Touch Controls & Audible Feedback:** Intuitive buttons and touch-sensitive controls for light, snooze, and power with audible feedback.
- **15W Wireless Charging:** Integrated wireless charging for smartphones (15W) and earphones (5W).
- **Multi-Color Ambient Light:** Customizable multi-color light options for ambiance or as a desktop lamp.
- **Bluetooth Speaker:** Play your own music through the device.




Figure 3.2: Visual representation of the core functionalities: Sunrise Alarm, Sleep Aid, Ambient Lamp, Wireless Charging, and Bluetooth Speaker.

4. SETUP

4.1 Unboxing and Placement

- Carefully remove all components from the packaging.
- Place the alarm clock on a stable, flat surface near a power outlet and your bed.

4.2 Power Connection

Connect the provided power adapter to the device's power input port and then plug it into a wall outlet. The display will illuminate, indicating the device is powered on.

4.3 App Installation and WiFi Connection

For full functionality and smart control, download the companion app from your smartphone's app store. The device supports both 2.4G and 5G WiFi networks for seamless connectivity.

1. Scan the QR code in the quick start guide or search for the 'Dekala' app in your app store.
2. Install and open the app.
3. Follow the in-app instructions to connect your alarm clock to your home WiFi network. Ensure your phone is connected to the same network during setup.

5G WiFi/Touch/App Seamless connectivity Effortless Control

Button-Controlled Functions with Audio Feedback and Touch Interface | Dual-Band WiFi Support for 2.4G & 5G Networks



Figure 4.1: Controlling the alarm clock via the mobile application, highlighting 2.4G/5G WiFi support.

4.4 Initial Time and Date Setting

Upon first power-up or after a power outage, you may need to set the correct time and date. This can typically be done through the app or using the physical controls on the device as described in the Operating section.

5. OPERATING INSTRUCTIONS

5.1 Basic Controls

The device features intuitive buttons and touch-sensitive areas. Refer to the quick start guide for a diagram of specific button locations. Most functions can be adjusted via the app or directly on the device.

5.2 Setting the Sunrise Alarm

The sunrise alarm simulates a natural dawn, gradually increasing light intensity before your set alarm time.

1. Access the alarm settings via the app or dedicated alarm buttons on the device.

2. Set your desired wake-up time.
3. Choose a sunrise duration (e.g., 30 minutes, 60 minutes). The light will begin to brighten gradually before your alarm time.
4. Select your preferred alarm sound (e.g., bird songs, ocean waves, or a traditional alarm). The alarm volume can reach up to 120dB.
5. Confirm your settings.



Figure 5.1: Gentle touch interaction for starting your day with the sunrise alarm.

5.3 Sleep Timer and White Noise

The sleep timer and white noise functions help create a calming environment for falling asleep.

1. Activate the sleep timer function via the app or device controls.
2. Set the desired duration for the sleep timer (from 5 minutes to all night).
3. Choose a sunset light effect, where the light gradually dims, or a breathing light effect.
4. Select a white noise sound (white, pink, brown noise) or natural sound (birds, ocean, rain) to play during the sleep timer.

5. The light and sound will gradually fade out as the timer concludes.




Figure 5.2: The alarm clock providing a serene environment for sleep with its light and sound features.

5.4 Wireless Charging

The device includes a wireless charging pad for compatible smartphones and earphones.

- Place your Qi-compatible smartphone on the designated charging area (15W).
- Place your Qi-compatible earphones on the smaller designated charging area (5W).
- Ensure the device is centered on the charging pad for optimal charging. A charging indicator may appear on the device's display or your phone.

Declutter Your Space, Recharge Your Life



Figure 5.3: Wireless charging functionality for both smartphones and earphones.

5.5 Ambient and Multi-Color Light

Customize the device's lighting to suit your mood or decor.

- Use the touch controls or app to cycle through various static colors or dynamic light modes.
- Adjust the brightness level to your preference.



Figure 5.4: Examples of the multi-color ambient lighting options available.

5.6 Bluetooth Speaker Functionality

Connect your smartphone or other Bluetooth-enabled device to play audio through the alarm clock's speaker.

1. Enable Bluetooth on your smartphone.
2. Put the alarm clock into Bluetooth pairing mode (refer to device controls or app).
3. Select 'Dekala SAC' (or similar name) from your phone's Bluetooth device list.
4. Once paired, audio from your phone will play through the alarm clock.

5.7 Snooze Function

When the alarm sounds, gently touch the device or press the designated snooze button to temporarily pause the alarm. The snooze duration can be customized via the app or device settings.



Figure 5.5: The one-touch snooze feature for convenient temporary alarm deactivation.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the device. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the device for an extended period, unplug it and keep it in a cool, dry place.
- **Avoid Obstructions:** Ensure the wireless charging pad and speaker grilles are free from dust and debris.

7. TROUBLESHOOTING

If you encounter issues with your Dekala Arches Sunrise Alarm Clock, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on.	Power adapter not connected or faulty outlet.	Ensure the power adapter is securely connected and the outlet is functional. Try a different outlet.
Wireless charging not working.	Device not Qi-compatible, not centered, or foreign object on pad.	Ensure your device supports Qi wireless charging. Reposition the device on the pad. Remove any metal objects or thick cases.
Alarm sound is too quiet/loud.	Volume setting is incorrect.	Adjust the alarm volume via the app or device controls.
Cannot connect to WiFi/App.	Incorrect WiFi password, network issues, or app pairing error.	Verify WiFi password. Ensure your router is functioning. Restart the alarm clock and your phone. Re-attempt pairing in the app. Ensure you are on a 2.4G or 5G network.
Light is not brightening/dimming as expected.	Sunrise/sunset duration or light effect not set correctly.	Check the settings for your sunrise alarm or sleep timer in the app or on the device.

8. SPECIFICATIONS

Feature	Detail
Brand	Dekala
Model Number	SAC
Color	Black
Display Type	Analog (Digital Time Display)
Special Feature	Adjustable Brightness, Sunrise Simulation, Sunset Simulation, White Noise, Wireless Charging, App Control
Product Dimensions	6.5"W x 6.5"H
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor
Material	Acrylonitrile Butadiene Styrene (ABS)
Frame Material	Plastic
Are Batteries Included	No
Mounting Type	Tabletop
Alarm Clock	Yes
Operation Mode	Manual, App Control
Item Weight	2.2 pounds

9. WARRANTY AND SUPPORT

Dekala stands by the quality of its products and offers a**365-day limited warranty** for this device. For warranty claims, technical support, or any questions regarding your Dekala Arches Sunrise Alarm Clock, please contact Dekala customer service through the official website or the contact information provided in your product packaging.

