

[Manuals.plus](#) /

> [FlareMore](#) /

> FlareMore Cordless Shoulder Heating Pad with Vibration (Black) Instruction Manual

FlareMore B0F26CK635

FlareMore Cordless Shoulder Heating Pad with Vibration (Black) Instruction Manual

Model: B0F26CK635

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your FlareMore Cordless Shoulder Heating Pad with Vibration. Please read these instructions thoroughly before first use and retain for future reference.



Image: The FlareMore Cordless Shoulder Heating Pad in black, demonstrating its application on the shoulder with visual cues for heat and vibration.

2. SAFETY INFORMATION

- Always unplug the device before use.
- Avoid using while charging to prevent electrical hazards.
- Do not leave the heated pad in contact with skin for extended periods to prevent burns.
- Keep out of reach of children and pets.
- Do not use if you have a pacemaker or other medical device that may be affected by electromagnetic interference.
- Avoid prolonged use or falling asleep with the pad on.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x FlareMore Cordless Shoulder Heating Pad with Vibration

- 1 x Charging Cable (Type-C)
- 1 x Extension Strap
- 1 x User Manual (this document)

4. PRODUCT FEATURES

- **Adjustable Fit:** Designed to fit comfortably on both left and right shoulders. Adjustable straps ensure a secure fit for various body types (27–55 inch chest, 9–16 inch arms). An extension strap is included for customized tension.
- **Customizable Heat Settings:** Features three adjustable heat levels ranging from 40°C/104°F to 75°C/167°F.
- **Customizable Vibration Modes:** Offers three vibration modes for targeted massage.
- **Cordless & Portable:** Equipped with a built-in 5000mAh battery for use anywhere. The intuitive touchscreen allows for easy setting adjustments.
- **Breathable Material:** Made with breathable materials to prevent slipping and ensure comfort during use.




Image: The control panel displaying the three heating levels (Low: 40-50°C/104-122°F, Mid: 50-60°C/122-140°F, High: 60-75°C/140-167°F) and three vibration modes (Low, Mid, High).

Shoulder Dimensions



Fits Chest
27"-55"



Arm
9"-16"




Image: A diagram illustrating the shoulder dimensions the pad is designed to fit, including chest circumference (27-55 inches) and arm circumference (9-16 inches), and highlighting the included extension strap.

5. SETUP

1. Connect the main strap to the buckle on the shoulder pad.
2. Place the shoulder pad onto the desired shoulder (left or right).
3. Adjust the strap to a proper position, ensuring the pad covers the target area.
4. Pull the long strap down and secure it around your torso.
5. If needed, attach the extension strap to the main strap for a more comfortable fit.

Suitable For Left & Right Shoulder

Switch between °C and °F by holding the 🔥 + 🌀 for 3 seconds.



Easy To Use



01
Connect the strap to the buckle.



02
Put the shoulder brace on, and adjust it to a proper position.



03
Pull the long strap down and secure it.



04
Adjust the settings and massage.

Image: A visual guide demonstrating the four steps to correctly wear the shoulder heating pad, from connecting straps to adjusting its position.

6. OPERATING INSTRUCTIONS

1. **Power On/Off:** Press and hold the power button on the control panel to turn the device on or off.
2. **Adjust Heat Settings:** Press the heat button to cycle through the three heat levels (Low, Mid, High). The current temperature will be displayed.
3. **Adjust Vibration Modes:** Press the vibration button to cycle through the three vibration modes (Low, Mid, High).
4. **Switch Temperature Units:** To quickly switch between Celsius (°C) and Fahrenheit (°F), hold the Heat and Vibration buttons together for three seconds.

Image: A detailed view of the control panel, highlighting buttons for power, vibration, heat, and the battery display, along with instructions for temperature unit conversion.

7. CHARGING INSTRUCTIONS

- Use an adapter (not included) with 5V 2A output or higher.
- Connect the provided original charging cable (Type-C) to the device and the power adapter.
- Ensure proper charging by using the recommended power specifications.
- Do not use the shoulder massager while charging to avoid damage and potential electrical hazards.



Image: The shoulder pad's control unit, emphasizing its 5000mAh battery for extended use and its Type-C charging port.

8. CARE AND MAINTENANCE

- To clean, unplug the device and allow the pad to cool completely.
- Wipe the pad with a damp cloth. Do not submerge the device in water.
- Store the device in a cool, dry place when not in use.

9. SPECIFICATIONS

Feature	Detail
Model Number	B0F26CK635

Brand	FlareMore
Color	Black
Material Type	Neoprene
Number of Heat Settings	3
Number of Vibration Modes	3
Battery Capacity	5000mAh (Built-in)
Charging Input	5V 2A or higher (Adapter not included)
Package Dimensions	8.15 x 6.1 x 2.48 inches
Item Weight	1.12 Pounds

10. TROUBLESHOOTING

No specific troubleshooting steps are provided in the product information. If you encounter any issues, please ensure the device is fully charged and that all connections are secure. Refer to the operating instructions for correct usage. If problems persist, contact customer support.

11. OFFICIAL PRODUCT VIDEO

Video: An official product video from FlareMore demonstrating the features and use of the Heated Shoulder Massager.

12. WARRANTY AND SUPPORT

Specific warranty and support details are not provided in the product information. Please refer to the product packaging or the manufacturer's official website for warranty claims and customer support contact information.