

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOPUTURE](#) /

› [TOPUTURE 4 in 1 Walking Pad Treadmill with Incline and Handle - Instruction Manual](#)

TOPUTURE TP4

TOPUTURE 4 in 1 Walking Pad Treadmill with Incline and Handle - Instruction Manual

Model: TP4

Brand: TOPUTURE

INTRODUCTION

The TOPUTURE 4 in 1 Walking Pad Treadmill is designed to provide a versatile and efficient exercise experience for home or office use. This portable unit features a 9% manual incline, a powerful yet quiet 2.5HP motor, and dual LED displays for real-time tracking of your workout data. Its foldable design allows for easy storage, making it suitable for small spaces. Connectivity to sports apps via Bluetooth enhances your fitness tracking capabilities.

SETUP

The TOPUTURE 4 in 1 Walking Pad Treadmill features an installation-free design, meaning it comes largely pre-assembled and ready for quick setup.

1. Unfolding the Handlebar

Upon unboxing, the handlebar will be folded down. To raise it, locate the knobs on both sides of the base where the handlebar connects. Turn these knobs counter-clockwise to loosen them, then carefully lift the handlebar into the upright position. Once upright, tighten the knobs by turning them clockwise to secure the handlebar firmly in place.

2. Power Connection

Connect the power cord to the designated port at the front of the treadmill base. Plug the other end into a standard electrical outlet. Locate the master power switch, typically a red button, near the power cord port and flip it to the 'ON' position. The display screens will illuminate.

3. Attaching the Safety Key

The treadmill requires the safety key to be attached for operation. Clip the red safety key onto the designated yellow magnetic area on the control panel. Attach the other end of the safety clip to your clothing. If the safety key is detached during operation, the treadmill will automatically stop.

Dual LED Screen Display

Clear display of data



Image: The TOPUTURE treadmill with its handlebar in the upright position, showing the control panel and the attached safety key. The power cord is plugged into the base.

Your browser does not support the video tag.

Video: An official seller video demonstrating the quick setup process of the TOPUTURE treadmill, including raising the handlebar and connecting the power.

OPERATING INSTRUCTIONS

1. Dual Display & Controls

The treadmill features dual LED displays: one on the handlebar and another on the base. These displays show real-time workout data including time, speed, distance, and calories burned. The control panel on the handlebar includes buttons for starting/pausing, stopping, adjusting speed (+/-), and selecting modes (M) or preset programs (P).



Image: A close-up of the dual LED screens displaying speed, distance, time, and calories. The upper screen is on the handlebar, and the lower screen is on the treadmill base.

2. Speed Adjustment

The treadmill offers a speed range from 0.6 to 7.6 MPH. You can adjust the speed using the '+' and '-' buttons on the control panel or via the magnetic remote control. The remote also features quick-speed buttons (e.g., 2, 4, 6 MPH) for rapid adjustments.

3. Mute Control

The remote control includes a mute button to silence operational beeps, allowing for a quieter workout experience. The 2.5HP motor is designed for low noise operation (below 45dB).



Image: The magnetic remote control with a mute button, highlighting the quiet operation of the treadmill for an undisturbed work environment.

4. App Connectivity

The treadmill supports Bluetooth connectivity to sports apps like Fitshow. This allows you to record and track your exercise data, set goals, and share your activities. A device holder is integrated into the handlebar to securely place your phone or tablet.

Double Your Running Pleasure with Apps



Image: A user exercising on the TOPUTURE treadmill while viewing a fitness app on a tablet placed in the device holder, demonstrating Bluetooth connectivity.

5. Operating Modes

The treadmill offers multiple modes to suit your workout needs:

- **Working Mode:** 0.6-1.5 MPH (handlebar folded down, ideal for under-desk use).
- **Walking Mode:** 1.5-3 MPH (handlebar up or down).
- **Climbing Mode:** 0.6-3 MPH (with incline activated).
- **Running Mode:** 3-7.6 MPH (handlebar up).

Comfortable Running Area



Image: Visual representation of the four operating modes: Running, Climbing, Walking, and Working, with corresponding speed ranges and user postures.

INCLINE ADJUSTMENT

The TOPUTURE treadmill features a manual 9% incline to simulate climbing and enhance calorie burning. This incline is adjusted manually, not electronically.

Steps to Adjust Incline:

- 1. Unfold the Footpad:** Locate the foldable footpads at the rear of the treadmill base. Unfold them to extend the support.
- 2. Insert the Pin:** Secure the unfolded footpads by inserting the provided pin into the designated hole on each side.
- 3. Adjust the Middle Footpad:** Ensure the middle footpad is adjusted to match the height of the inclined rear section, providing stable support across the entire base.

To return to a flat surface, reverse these steps, folding the footpads back into their original position.



Image: A visual guide showing the three steps to manually adjust the treadmill's incline: unfolding the footpad, inserting the pin, and adjusting the middle footpad.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your TOPUTURE treadmill.

1. Lubrication

The treadmill features a convenient drip tube design for easy lubrication. Periodically add lubricating oil to the designated port to keep the running belt smooth and reduce friction. Refer to the user manual for recommended lubrication frequency and type of oil.

2. Belt Adjustment

If the running belt feels loose or misaligned, it may need adjustment. Use the provided L-wrench to adjust the tension screws at the rear of the treadmill base. Adjust gradually, ensuring the belt remains centered and taut. Consult the user manual for detailed instructions on belt tensioning and alignment.



Image: Close-up views illustrating the lubrication port for adding oil and the adjustment screws for maintaining proper running belt tension.

STORAGE

The TOPUTURE treadmill is designed for compact storage, making it ideal for small living spaces.

1. Folding for Storage

To fold the treadmill, loosen the handlebar knobs and gently lower the handlebar until it rests flat against the running deck. This transforms the unit into an under-desk walking pad or a compact form for vertical storage.

2. Moving and Placement

Weighing 47 pounds and equipped with 2 transport wheels, the treadmill can be easily moved. Simply tilt the folded unit and roll it to your desired storage location, such as under a bed, sofa, or against a wall. Its folded dimensions are approximately 50 x 23 x 4.5 inches.



Under Desk Treadmill

One-click mute, immerse in work

Image: The treadmill shown in its folded state, highlighting its compact dimensions and transport wheels for easy storage and mobility.

TROUBLESHOOTING

If you encounter any issues with your treadmill, please review the following common solutions before contacting support:

- Treadmill Not Starting:** Ensure the power cord is securely plugged into both the treadmill and the wall outlet. Verify that the master power switch is in the 'ON' position. Confirm the safety key is correctly attached to the control panel.
- Belt Slipping or Sticking:** Check the running belt tension and adjust if necessary (refer to Maintenance section). Ensure adequate lubrication has been applied to the belt.
- Unusual Noises:** Inspect the treadmill for any loose parts. Ensure the unit is placed on a flat, stable surface. If noises persist, contact customer support.
- Display Not Working:** Check all power connections. If the display remains blank, try detaching and reattaching the safety key.

SPECIFICATIONS

Feature	Detail
Brand	TOPUTURE
Model Name	TP4
Color	Black
Product Dimensions	50"D x 23"W x 4.5"H
Item Weight	21.6 Kilograms
Material	Alloy Steel

Feature	Detail
Maximum Speed	7.6 Miles per Hour
Maximum Horsepower	2.5 Horsepower
Maximum Incline Percentage	9.00% (Manual)
Assembly Required	No
Power Source	Corded Electric
Connectivity Technology	Bluetooth
Included Components	Safety Key; PowerCord; RemoteControl; UserManual; L-Wrench
Maximum Weight Recommendation	130 Kilograms (300 LBS)
Folded Size	50 x 23 x 4.5 inches
Screen Size	12.7 Centimeters

WARRANTY & SUPPORT

The TOPUTURE 4 in 1 Walking Pad Treadmill comes with a 1-year warranty.

For warranty activation or after-sales service, please contact TOPUTURE customer support:

- **US/CA:** toputure_service@outlook.com
- **UK/EU:** toputure.service@gmail.com