

## ANJANK KX213-Pink

# ANJANK Loud Alarm Clock with Wireless Bed Shaker User Manual

Model: KX213-Pink

Brand: ANJANK

## PRODUCT OVERVIEW

The ANJANK Loud Alarm Clock is designed to provide a comprehensive wake-up experience, combining light, vibration, and sound. It is particularly suited for deep sleepers, individuals with hearing impairment, and those who prefer a gentle yet effective awakening.

Key features include:

- **Light, Vibration & Loud Alarm Clock:** Features a gradual orange light, a powerful wireless bed shaker, and extra-loud front-facing alarm sounds.
- **Powerful Wireless Vibrations:** The bed shaker has a built-in 1500mAh rechargeable battery, offering 2-3 months of vibration on a single charge with a 10m (32.8ft) wireless range. It supports magnetic and Type-C charging and has 3 vibration intensity levels (High, Medium, Low).
- **Extra Loud Sound & Dual Alarms:** Set two separate alarms with 5 gradual sounds, including 2 sharp sounds for the hearing impaired, a chime, a bird chirp, and a buzzer. The front-facing speaker provides up to 112dB volume with 10-level precise control.
- **RGB Time Display & 0-100% Dimmer:** Choose from White, Red, Blue, or RGB gradient colors for the time display, with brightness adjustable from 0% to 100%.
- **Dimmable 9-Color Nightlight:** Features 9 vibrant colors (Orange, Yellow, Red, Green, Cyan, Blue, Purple, White, Rainbow Flow) and Off Mode, with 6 brightness levels.
- **USB-C Phone Charging:** Equipped with a Type-C output port for convenient phone charging.



Image: The ANJANK alarm clock with its wireless bed shaker, showcasing the digital time display and the surrounding light ring.

## SETUP

- Unpacking:** Carefully remove all components from the packaging. Verify that you have the alarm clock unit, the wireless bed shaker, and the power adapter.
- Power Connection:** Connect the power adapter to the alarm clock unit and plug it into a standard electrical outlet. The display will illuminate.
- Charging the Wireless Bed Shaker:** The bed shaker has a built-in rechargeable battery. It can be charged via its Type-C port or by magnetically attaching it to the designated charging area on the back of the alarm clock unit. Ensure the shaker is fully charged before first use for optimal performance (indicated by an LED on the shaker). A full charge provides 2-3 months of use.
- Placement:** Place the alarm clock on a stable surface, such as a nightstand. Position the wireless bed shaker under your pillow or mattress for effective vibration.

Even the deepest sleepers feel it –thanks to front-directed sound



Image: The wireless bed shaker being charged by magnetically attaching it to the main alarm clock unit.

## OPERATING INSTRUCTIONS

### Setting Time

Refer to the specific buttons on your device (usually labeled "Time Set" or a clock icon) to enter time setting mode. Use the +/- buttons to adjust hours and minutes. Confirm your selection to save the time.

### Setting Alarms

The clock supports dual alarms. Press the "Alarm 1" or "Alarm 2" button to activate alarm setting mode. Adjust the desired wake-up time using the +/- buttons. You can then select the alarm sound (5 options including sharp sounds, chime, birdsong, buzzer), volume level (10 levels), and choose the wake-up mode (vibration, light, sound, or a combination).

## Innovative Triple-Tech Wake-Up System



**112dB Front-Facing Sound**  
Delivers loud, focused alarm tones directly to your ears

**Strong Wireless Vibration**  
Silent, powerful vibrations placed under the pillow – perfect for shared rooms.

**Softer Light Morning Call**  
Gently mimics sunlight to ease your body out of sleep – no jolts, just calm.

Image: Diagram showing the internal speaker and various alarm sound options like chime, birdsong, and buzzer sound.

### Adjusting Display Brightness and Color

Use the dedicated dimmer button or controls to adjust the display brightness from 0% (off) to 100%. The time display can be set to White, Red, Blue, or an RGB gradient. The nightlight feature offers 9 vibrant colors and 6 brightness levels, including an Off mode for complete darkness.

# 112dB front facing super loud sound!

Custom 10-level volume



Chime



Birdsong



Buzzer Sound



2 Loud Sharp Sounds



Image: Three alarm clocks displaying different vibrant mood lighting colors, illustrating the customizable RGB time display and nightlight.

## Wireless Bed Shaker Operation

The bed shaker automatically activates with the alarm. You can adjust its vibration intensity to High, Medium, or Low using the switch on the shaker unit itself. Ensure the shaker is within the 10m (32.8ft) wireless range of the alarm clock for reliable operation.



Image: Close-up of the wireless bed shaker with an overlay indicating High, Mid, and Low vibration intensity levels.

## USB-C Charging Port

A Type-C output port is located on the alarm clock unit. This port can be used to charge your smartphone or other compatible devices while the alarm clock is powered on.

## MAINTENANCE

- Cleaning:** Use a soft, dry cloth to clean the surface of the alarm clock and bed shaker. Avoid using abrasive cleaners or solvents.
- Bed Shaker Battery:** To ensure consistent performance, regularly charge the wireless bed shaker. It is recommended to charge it when the battery indicator shows low power or if vibration strength decreases.
- Storage:** If storing the device for an extended period, ensure the bed shaker is fully charged and store all components in a cool, dry place.

## TROUBLESHOOTING

Problem	Possible Cause / Solution
Alarm does not sound or vibrate.	Check if the alarm is enabled and set correctly. Ensure alarm volume is not set to 0. Verify the wireless bed shaker is charged and within range. Confirm the correct wake-up mode (sound, vibration, light) is selected for the alarm.
Bed shaker vibration is weak or inconsistent.	The bed shaker battery may be low. Recharge it fully. Ensure the shaker is placed correctly under the pillow/mattress and not obstructed. Check the vibration intensity level setting on the shaker.
Display is too dim or too bright.	Adjust the dimmer setting using the dedicated controls on the alarm clock.
Time is incorrect.	Re-set the time manually following the "Setting Time" instructions.

## SPECIFICATIONS

**Brand:** ANJANK

**Model Number:** KX213-Pink

**Color:** Pink

**Display Type:** Digital

**Power Source:** Corded Electric

**Product Dimensions:** 3.2"W x 5.7"H

**Item Weight:** 1.59 pounds

**Wireless Shaker Battery:** 1500mAh rechargeable (provides 2-3 months of use)

**Wireless Shaker Range:** 10m (32.8ft)

**Alarm Volume:** Up to 112dB (10-level control)

**Nightlight Colors:** 9 (Orange, Yellow, Red, Green, Cyan, Blue, Purple, White, Rainbow Flow)

**Dimmer:** 0-100% for time display, 6 brightness levels for nightlight

**Charging Port:** USB-C output for phone charging

## **WARRANTY AND SUPPORT**

For warranty information or technical support, please contact ANJANK customer service directly. Refer to the product packaging or the official ANJANK website for contact details.

**Website:** [ANJANK Official Store on Amazon](#)