

Slevoo SW-01

Slevoo 2-in-1 Baby Jumper and Swing Instruction Manual

Model: SW-01

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use of the Slevoo 2-in-1 Baby Jumper and Swing. Failure to follow these instructions could result in serious injury or death.

- **Adult Supervision Required:** Never leave a child unattended in the jumper or swing. Constant adult supervision is necessary.
- **Age and Weight Limits:** This product is suitable for children aged 6 months to 6 years. The maximum weight capacity is 200 pounds. Ensure your child meets the age and weight requirements.
- **Secure Installation:** Always ensure the stand is fully assembled and all connections are securely fastened before placing a child in the jumper or swing.
- **Outdoor Use:** When using outdoors, utilize the provided ground stakes to ensure maximum stability and prevent tipping.
- **Inspect Regularly:** Before each use, inspect the product for any signs of wear, damage, or loose parts. Discontinue use immediately if any damage is found.
- **Clear Surroundings:** Ensure there is ample clear space around the jumper/swing to prevent collisions with furniture, walls, or other objects.

2. PACKAGE CONTENTS

Verify that all components listed below are present in your package:

- Baby Jumper (x1)
- Foldable Stand (x1)
- Baby Swing (x1)
- Ground Nails (x4)



Figure 2.1: All components included in the package.

3. SETUP INSTRUCTIONS

3.1 Unpacking

Carefully remove all components from the packaging. Retain packaging for future storage or transport if desired.

3.2 Assembling the Foldable Stand

1. Unfold the stand by extending its legs until they lock into place. The stand features heavy-duty metal pipes for stability.
2. Ensure all locking mechanisms are engaged to prevent accidental folding during use.




Figure 3.1: Details of the foldable stand and its construction.

3.3 Attaching the Jumper or Swing

1. Select either the baby jumper or the baby swing attachment.
2. Locate the hooks on the top of the jumper or swing straps.
3. Securely attach these hooks to the designated attachment points on the top bar of the foldable stand. Ensure the hooks are fully closed and locked.




Figure 3.2: Attaching the swing to the stand.

3.4 Adjusting the Straps

The jumper and swing feature adjustable straps to accommodate your child's height and ensure a secure fit.

1. For the jumper, locate the adjustment buckle on the strap. Thread the strap through the buckle as shown in the video to achieve the desired height.
2. For the swing, adjust the length of the ropes to ensure the child's feet can comfortably touch the ground in jumper mode or swing freely in swing mode.
3. Always secure the safety belt and any detachable handrails when placing your child in the swing or jumper.

Your browser does not support the video tag.

Video 3.1: Demonstrates the correct installation and adjustment of the strap for the baby jumper.



Figure 3.3: Safety features of the baby swing, including the safety belt and adjustable seat.

3.5 Outdoor Use (Ground Stakes)

For enhanced stability during outdoor use, especially on uneven surfaces or in windy conditions, use the provided ground stakes.

1. Position the stand on a flat, stable outdoor surface.
2. Insert one ground stake through the designated holes at the base of each leg of the stand.
3. Push or gently hammer the stakes into the ground until they are flush with the base of the stand, ensuring a firm anchor.

Play Outside!

Comes with four ground nails



Figure 3.4: Outdoor setup with ground nails for stability.

4. OPERATING INSTRUCTIONS

4.1 Jumper Mode (Ages 6-12 Months)

Jumper mode is designed for infants who can hold their head up unassisted. It encourages leg strength and coordination.

1. Ensure the jumper attachment is securely fastened to the stand and adjusted to the correct height so your baby's feet can touch the ground.
2. Carefully place your baby into the jumper harness, ensuring their legs are positioned correctly and the harness is snug.
3. Fasten all safety buckles and adjust straps for a secure fit.
4. Allow your baby to bounce naturally. Always supervise your child during use.

01

Baby jumper mode 



Play swing mode 

02



Figure 4.1: Baby in jumper mode.

4.2 Swing Mode (Ages 6 Months to 6 Years)

Swing mode provides a gentle swaying motion for relaxation and entertainment. The swing seat is designed to grow with your child.

1. Ensure the swing attachment is securely fastened to the stand and adjusted to an appropriate height.
2. Carefully place your child into the swing seat. For younger children (6-36 months), ensure they are properly supported by the full bucket seat. For older children (4-6 years), the seat can be adjusted to a more open style.
3. Fasten the safety belt and ensure the detachable handrail is in place if applicable.
4. Gently push the swing to initiate motion. Do not push excessively hard.

Package includes



Figure 4.2: Baby in swing mode.

3 Modes to Grow with Your Child



Figure 4.3: Three modes of use for different age groups.

Your browser does not support the video tag.

Video 4.1: A demonstration of the Slevoo 2-in-1 Baby Jumper and Swing in use, showcasing both jumper and swing modes.

5. MAINTENANCE

5.1 Cleaning

- **Fabric Parts (Jumper/Swing Seat):** The cotton fabric parts can be spot cleaned with mild soap and water. Allow to air dry completely before reassembly or use. Do not bleach or machine wash unless specified on a care label (check product for specific care tags).
- **Metal Frame:** Wipe the metal frame with a damp cloth and mild detergent. Dry thoroughly to prevent rust.

5.2 Inspection

Regularly inspect the following components:

- **Straps and Buckles:** Check for fraying, tears, or damage. Ensure buckles engage securely.
- **Frame Connections:** Verify all bolts, screws, and locking mechanisms are tight and secure.
- **Hooks and Rings:** Ensure all metal hooks and rings are not bent, rusted, or damaged.
- **Ground Stakes:** If used, check that ground stakes are not bent or corroded.

6. TROUBLESHOOTING

- **Product feels unstable:**
 - Ensure the foldable stand is fully extended and all locking pins are engaged.
 - Check that all connections between the stand and the jumper/swing are secure.
 - If using outdoors, ensure ground stakes are fully inserted into stable ground.
- **Difficulty adjusting strap height:**
 - Refer to Video 3.1 for correct strap adjustment technique.
 - Ensure the strap is threaded correctly through the buckle without twisting.
- **Child does not fit securely:**
 - Re-adjust all straps and buckles to ensure a snug fit for your child's size.
 - Verify your child is within the recommended age and weight limits for the product.

7. SPECIFICATIONS

Brand	Slevoo
Model Number	SW-01
Material	Cotton, Metal
Assembled Dimensions (L x W x H)	52.7" x 35" x 56.6"
Item Weight	22 Pounds
Maximum Weight Recommendation	200 Pounds
Required Assembly	Yes

8. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact Slevoo directly through their official website or the retailer where the product was purchased. Please have your model number (SW-01) and purchase date available when contacting support.