Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- UREVO /
- > UREVO SYWP002 Walking Pad Treadmill with 9% Incline and Remote Control User Manual

UREVO SYWP002

UREVO SYWP002 Walking Pad Treadmill User Manual

Model: SYWP002

1. IMPORTANT SAFETY INFORMATION

Please read this entire manual carefully before operating the UREVO SYWP002 Walking Pad Treadmill. Retain this manual for future reference. Failure to follow these instructions may result in injury or damage to the product.

- Always place the treadmill on a flat, stable surface.
- Ensure adequate clear space around the treadmill during operation.
- · Keep children and pets away from the treadmill during use.
- Do not operate the treadmill if it is damaged or malfunctioning.
- Wear appropriate athletic footwear during exercise.
- Consult a physician before starting any new exercise program.
- The maximum user weight for this treadmill is 136 kg (300 lbs).
- Unplug the treadmill from the power outlet when not in use or before cleaning/maintenance.

2. PACKAGE CONTENTS

Verify that all components are present in the package:

- UREVO SYWP002 Walking Pad Treadmill
- Remote Control
- Power Cord
- User Manual (this document)

3. PRODUCT OVERVIEW

The UREVO SYWP002 is a versatile walking pad treadmill designed for both walking and light jogging, suitable for home and office environments. It features a manual incline, a quiet motor, and a compact design for easy storage.



Image 1: UREVO Walking Pad Treadmill in both jogging and under-desk walking configurations.

Key Features:

- 9% Manual Incline: Adjust the incline manually to increase workout intensity and calorie burn.
- 2.5 HP Quiet Motor: Operates at less than 45 decibels, ideal for quiet environments.
- 6-Point Shock Absorbing System: Protects joints by cushioning impact during exercise.
- 5-Layer Anti-Slip Belt: Provides a secure and comfortable running surface.
- 2-in-1 Design: Functions as both a walking pad for under-desk use and a jogging machine.
- Compact and Lightweight: Easy to move and store with built-in wheels.
- LED Display & Remote Control: Conveniently monitor workout data and adjust settings.




Image 2: Visual representation of the 9% manual incline for enhanced calorie burning.




Image 3: The treadmill's dual functionality for jogging and under-desk walking.




Image 4: Details of the powerful yet quiet 2.5 HP motor and weight capacity.




Image 5: The compact design and portability features, including dimensions and pulley wheels.



Image 6: The LED display and remote control for monitoring and adjusting workout settings.

4. SETUP

The UREVO SYWP002 Walking Pad Treadmill comes largely pre-assembled. Follow these steps for initial setup:

- 1. **Unpacking:** Carefully remove the treadmill and all accessories from the packaging.
- 2. **Placement:** Place the treadmill on a firm, level surface. Ensure there is at least 0.6 meters (2 feet) of clear space behind the treadmill and 0.3 meters (1 foot) on each side.

- 3. **Power Connection:** Connect the power cord to the treadmill's power input port, then plug the other end into a grounded electrical outlet.
- 4. **Incline Adjustment (Manual):** To adjust the incline, lift the rear of the treadmill and manually position the support legs to the desired height. Ensure both sides are set equally and securely. The treadmill offers a manual incline up to 9%.

5. OPERATING INSTRUCTIONS

5.1 Remote Control Functions

The treadmill is operated using the included remote control.

- Power Button: Press to turn the treadmill ON or OFF.
- Start/Stop Button: Press to start or pause the treadmill belt.
- Speed +/- Buttons: Adjust the speed of the treadmill belt.
- Mode Button: Cycle through display modes (Time, Distance, Calories, Speed).

5.2 Starting a Workout

- 1. Ensure the treadmill is plugged in and the power switch (if present, usually near the power cord) is ON.
- 2. Stand on the side rails of the treadmill, not directly on the belt.
- 3. Press the 'Power' button on the remote control to activate the display.
- 4. Press the 'Start' button on the remote. The belt will begin to move at a low speed.
- 5. Carefully step onto the moving belt and use the 'Speed +' button to increase to your desired walking or jogging pace.

5.3 Adjusting Speed and Incline

- **Speed:** Use the 'Speed +' and 'Speed -' buttons on the remote control to adjust the belt speed. The walking mode speed range is 0.6-3 mph, and the jogging mode speed range is 0.6-4 mph.
- Incline: The incline is adjusted manually. To change the incline, you must stop the treadmill, unplug it, and then physically adjust the rear support legs to the desired height. Ensure the treadmill is stable before resuming use.

5.4 LED Display

The integrated LED display shows important workout metrics:

- Time: Duration of your workout.
- Distance: Total distance covered.
- Calories: Estimated calories burned.
- Speed: Current speed of the treadmill belt.

Press the 'Mode' button on the remote to cycle through these display options.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your treadmill.

6.1 Cleaning

- Always unplug the treadmill before cleaning.
- · Wipe down the treadmill surface with a damp cloth after each use to remove sweat and dust.
- Do not use abrasive cleaners or solvents.

6.2 Running Belt Lubrication

The running belt requires periodic lubrication to reduce friction and extend its lifespan. Refer to the specific lubrication instructions provided with your treadmill's lubricant kit (if included) or contact customer support for recommendations.

6.3 Running Belt Adjustment

If the running belt shifts to one side or feels loose, it may need adjustment. This typically involves using an Allen wrench to turn the tension bolts at the rear of the treadmill. Refer to the detailed instructions in the full user manual or contact customer support for guidance to avoid damage.

7. TROUBLESHOOTING

If you encounter issues with your treadmill, refer to the following common problems and solutions:

- Treadmill does not power on: Ensure the power cord is securely plugged into both the treadmill and a working electrical outlet. Check the power switch on the treadmill.
- Belt does not move: Press the 'Start' button on the remote. Ensure no objects are obstructing the belt.
- Belt shifts to one side: The running belt may need adjustment. Refer to Section 6.3 or contact customer support.
- **Unusual noises:** Stop the treadmill immediately. Check for any loose parts or foreign objects. If the noise persists, contact customer support.
- Remote control not responding: Check the battery in the remote control and replace if necessary. Ensure there are no obstructions between the remote and the treadmill's receiver.

For problems not listed here or if issues persist, please contact UREVO customer support.

8. SPECIFICATIONS

Feature	Specification
Model Name	SYWP002
Brand	UREVO
Motor Peak Power	2.5 HP
Noise Level	<45 dB
Incline	Manual, up to 9% (2.7° lift angle)
Walking Mode Speed	0.6 - 3 mph
Running Mode Speed	0.6 - 4 mph
Runway Size	15" x 35.4" (approx. 38 cm x 90 cm)
Product Dimensions (L x W x H)	108D x 50.8W x 11.4H Centimeters (42.7" L x 19.7" W x 4.5" H)
Item Weight	16 kg (35.3 lbs)
Maximum User Weight	136 kg (300 lbs)
Material	Alloy Steel
Display Type	LED
Power Source	Corded Electric

Feature	Specification	
Included Components	Treadmill, Remote Control, Power Cord, User Manual	
Metrics Measured	Distance, Speed, Time, Calories	

9. WARRANTY AND SUPPORT

UREVO products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official UREVO website. If you require technical assistance, have questions about operation, or need to report a defect, please contact UREVO customer support through the contact information provided on the official website or your purchase documentation.

Related Documents - SYWP002

Cyterited for Office B deliverage for office B deliver	UREVO CyberPad for Office Auto Incline Smart Walking Pad Treadmill User Manual This comprehensive user manual for the UREVO CyberPad for Office Auto Incline Smart Walking Pad Treadmill (Model URTM051) guides users through setup, operation, safety protocols, maintenance, and troubleshooting. Discover features like the auto incline system and UREVO SmartCoach App integration for a smarter fitness experience.
Spoonwards Co. In annual control of the control of	UREVO SpaceWalk 5L Auto Incline Smart Walking Pad Treadmill User Guide Comprehensive user guide for the UREVO SpaceWalk 5L Auto Incline Smart Walking Pad Treadmill. Includes safety instructions, UREVO app integration, remote control operation, and LED display information for optimal use.
SPACEWALK 2 And tride Wide of Trades And tride Wide of Trades	UREVO SPACEWALK 2 Auto Incline Walking Treadmill User Manual Comprehensive user manual for the UREVO SPACEWALK 2 Auto Incline Walking Treadmill (Model URTM020), covering safety instructions, specifications, operation, maintenance, and warranty information.
Spoonwinds State of the state	UREVO SpaceWalk 5L Auto Incline Smart Walking Pad Treadmill User Guide User guide for the UREVO SpaceWalk 5L Auto Incline Smart Walking Pad Treadmill (Model URTM054), covering safety instructions, app connection, remote control operation, and specifications. Features 24-month warranty and lifetime customer service.
Constraint of Calculations and Calculati	UREVO CyberPad for Office Treadmill User Manual & SmartCoach App Guide Comprehensive user manual for the UREVO CyberPad for Office treadmill, including setup, safety instructions, SmartCoach app integration, and remote control operation. Model URTM051.
Spacovall, E1 Viving Tractival Viving Tractival Control	Spacewalk E1 Walking Treadmill User Manual User manual for the UREVO Spacewalk E1 Walking Treadmill (Model URTM025), providing instructions for setup, operation, maintenance, safety, and warranty.