

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [iDiskk](#) /

› [iDiskk Security Lock Box Shoulder Bag User Manual - Model B0F9P1BWTY](#)

iDiskk B0F9P1BWTY

iDiskk Security Lock Box Shoulder Bag User Manual - Model B0F9P1BWTY

Brand: iDiskk

Model: B0F9P1BWTY

PRODUCT OVERVIEW

This manual provides instructions for the iDiskk Security Lock Box Shoulder Bag, a secure and stylish accessory designed to protect your valuables. It features advanced fingerprint and password unlocking mechanisms, MFi certification, and compatibility with Apple's Find My app for enhanced tracking and security.

Key Features

- **Fingerprint Unlocking:** Set 1-3 fingerprints for quick, touch-based access.
- **Password Unlocking:** Set a 5-digit password for dual protection, useful when fingerprints are unclear.
- **Apple MFi Certification & Find My App Compatibility:** Locate your bag if lost or stolen, display contact information, or make it emit a sound to find it nearby (iOS only).
- **Multi-Scenario Use:** Ideal for daily commuting, vacations, gatherings, and business activities. Accommodates passports, wallets, bank cards, cosmetics, and mobile phones.
- **RFID Blocking Protection:** Safeguards cards from unauthorized scanning.

SETUP INSTRUCTIONS

Initial Unlocking

Upon receiving your iDiskk Security Lock Box, it will be locked. The default password is typically provided in the included user guide.

1. Locate the default password in the packaging or quick start guide.
2. Enter the default password using the keypad on the bag.
3. Press the unlock button (often indicated by a fingerprint icon or a specific key).

Setting Up Fingerprint Unlocking

The bag supports 1-3 registered fingerprints.

1. Open the bag using the default password or an already registered fingerprint.
2. Locate the "SETTING" button inside the bag (often a small button near the hinge).
3. Press and hold the "SETTING" button until an indicator light (e.g., blue or green) starts flashing.
4. Place your desired finger on the fingerprint sensor. Lift and press repeatedly until the indicator light confirms successful registration (e.g., a solid green light or a specific tone).
5. Repeat for additional fingerprints if desired.

Setting Up Password Unlocking

You can set one custom 5-digit password.

1. Open the bag.
2. Press and hold the "SETTING" button until the indicator light flashes.
3. Enter your desired 5-digit password.
4. Press the '#' key to confirm.
5. Re-enter the 5-digit password and press '#' again to confirm. The indicator light should confirm successful password setup.

Pairing with Apple Find My App (iOS Only)

This feature allows you to track your bag's location.

1. Ensure Bluetooth is enabled on your iPhone or iPad.
2. Open the "Find My" app.
3. Navigate to the "Items" tab.
4. Tap the '+' icon and select "Add Other Item".
5. Follow the on-screen prompts to connect to "safeBag" (or similar device name).
6. You may be prompted to rename your bag and choose an emoji.
7. Once paired, you can use the app to locate the bag, get directions, or make it play a sound.



Image: Step-by-step guide for connecting the iDisk Security Lock Box to the Apple Find My application on an iOS device.

Your browser does not support the video tag.

Video: An official iDisk video demonstrating the Apple Find My app integration, showing how to locate and retrieve the

bag if it is lost or misplaced.

OPERATING YOUR iDISKK SECURITY LOCK BOX

Unlocking with Fingerprint

1. Place a registered finger on the fingerprint sensor.
2. Hold until the green indicator light illuminates and you hear a click.
3. The bag will unlock.

Unlocking with Password

1. Press the '*' key to activate the keypad.
2. Enter your 5-digit password.
3. Press the '#' key to confirm.
4. The bag will unlock.


Locking the Bag

To lock the bag, simply close the lid firmly. It will automatically re-lock after a few seconds.

Using Find My Features

Once paired with the Apple Find My app:

- **Locate:** View the bag's current or last known location on a map.
- **Play Sound:** If the bag is nearby, you can make it emit a sound to help you find it.
- **Lost Mode:** Mark the bag as lost to display a custom message and contact information to anyone who finds it.



**NEVER LOSE YOUR BAG
TRACK IT WITH APPLE FIND MY**



Left-Behind Alarm
(iOS Only)



Worldwide Tracking



Loud Alarm
Up-to 80dB

 Works with
Apple Find My

 **Hey Siri**

Note: Android devices are not supported.

Image: Close-up view of the iDiskk Security Lock Box showing the intelligent unlocking methods, including the fingerprint sensor and secure code keypad.

Your browser does not support the video tag.

Video: An official iDiskk video showcasing the various features and usage scenarios of the Security Lock Box Shoulder Bag, including its design and functionality.

MAINTENANCE

Charging

The iDiskk Security Lock Box is powered by a rechargeable Lithium Ion battery.

- Connect the provided USB-C charging cable to the charging port on the bag.
- Connect the other end to a suitable USB power adapter (not included).
- An indicator light will show charging status (e.g., red for charging, green for fully charged).
- Ensure the bag is fully charged before extended use.

Cleaning

- Wipe the exterior with a soft, damp cloth. Avoid abrasive cleaners.
- For the interior, use a soft, dry cloth. The silicone lining is stain-resistant.

Storage

Store the bag in a cool, dry place when not in use. Avoid extreme temperatures.

TROUBLESHOOTING

Bag Does Not Open with Fingerprint/Password

- **Check Battery:** Ensure the bag is charged. If the battery is completely depleted, the bag may not open. Charge the bag for at least 30 minutes and try again.
- **Correct Finger Placement:** Ensure your registered finger covers the entire sensor surface.
- **Clean Sensor/Finger:** Dust or moisture on the sensor or your finger can prevent recognition. Clean both and try again.
- **Correct Password Entry:** Double-check that you are entering the correct 5-digit password, starting with '*' and ending with '#'.
#
- **Reset Password/Fingerprint:** If you have forgotten your password or fingerprints are not recognized, you may need to perform a factory reset. Refer to the "Factory Reset" section below.

Cannot Connect to Find My App

- **Bluetooth On:** Ensure Bluetooth is active on your iOS device.
- **Bag Powered On:** The bag must have sufficient battery and be powered on to be discoverable.
- **Proximity:** Ensure your iOS device is within Bluetooth range of the bag during initial pairing.
- **Re-pair Device:** If issues persist, try removing the bag from the Find My app and re-pairing it.

Factory Reset

A factory reset will erase all registered fingerprints and custom passwords, reverting the bag to its default settings.

1. Open the bag.
2. Locate the reset button inside the bag (often a small pinhole or button near the "SETTING" button).
3. Use a small pin or paperclip to press and hold the reset button for approximately 6 seconds.
4. The bag will beep 3 times and the red light will flash twice, indicating a successful reset.
5. You can now set new fingerprints and passwords.

SPECIFICATIONS

Feature	Detail
Brand	iDiskk
Model Number	B0F9P1BWTY

Lock Type	Biometric (Fingerprint) & Digital Keypad (Password)
Control Method	App (iOS Find My), Touch (Fingerprint), Keypad
External Dimensions (L*W*H)	7.56 x 2.56 x 5.24 inches
Internal Dimensions (L*W*H)	7.3 x 2.2 x 3.4 inches
Shoulder Strap Length	47.2 inches
Item Weight	1.47 lbs (0.67 kg)
Battery Type	1 Lithium Ion battery (included)
MFi Certified	Yes
RFID Blocking	Yes



Image: Visual representation of the iDiskk Security Lock Box with key dimensions (length, width, height) and strap length, along with its weight.

WARRANTY AND SUPPORT

For any issues, including difficulties opening the bag or product defects, please contact iDiskk Direct customer support immediately for assistance, replacement, or a full refund.

For further assistance or to report issues, please visit the official iDiskk website or contact their customer service.



Image: A customer service representative, symbolizing available support for product inquiries and issues.