



Manuals.plus /

› KINGJOY /

› KINGJOY 2-in-1 Cordless Shiatsu Back Massager with Heat, Model 839A Instruction Manual

KINGJOY 839A

KINGJOY 2-in-1 Cordless Shiatsu Back Massager with Heat - Model 839A Instruction Manual

Brand: KINGJOY | Model: 839A

INTRODUCTION

This manual provides comprehensive instructions for the KINGJOY 2-in-1 Cordless Shiatsu Back Massager with Heat, Model 839A. This device is designed to offer deep tissue kneading and soothing heat for muscle relaxation and pain relief. Key features include upgraded 4D liftable massage nodes, dual-sided heating with two adjustable levels, and a cordless, portable design for use in various settings.



The KINGJOY 2-in-1 Cordless Shiatsu Back Massager, showcasing its ergonomic design and compact form factor.

SAFETY INFORMATION

Always supervise the use of the massager and follow safety precautions. Keep the massager away from water. Do not use the massager while sleeping or lying down. If you have any medical conditions, consult with a doctor before use. Do not use the massager on injured or inflamed areas. Keep the massager clean and dry when not in use. Unplug the massager when not in use and store the power cord properly.

SETUP

Before first use, ensure the massager is fully charged. Use the provided Type-C charging cable to connect the device to a power source. The built-in 2500mAh battery allows for cordless operation.

1. Charge the massager using the Type-C charging port.




The massager is equipped with a 2500mAh rechargeable battery and charges via a Type-C port, offering cordless convenience.

OPERATING INSTRUCTIONS

The KINGJOY massager features intuitive one-button controls for ease of use. It offers various massage modes and heat settings to customize your experience.

1. **Power On/Off:** Long press the power button to turn the device on or off.
2. **Massage Mode Selection:** Short press the mode button to cycle through different shiatsu massage patterns. The 4D liftable nodes adjust to target upper back, lower back, and lumbar areas.
3. **Heat Settings:** The massager features dual-side heating. Short press the heat button to select between two adjustable heat levels (104°F/113°F) on the massager side. The back area provides a consistent single heat option.
4. **Speed Adjustment:** Use the speed button to choose between two intensity levels for gentle comfort or stronger deep tissue kneading.
5. **Placement:** Place the massager on the desired target area (upper back, lower back, or lumbar). For full body massage, refer to the usage guide below.




The massager features a simple one-button control interface: long press for power on/off, short press for massage head

adjustment, short press for massager heating, long press for cushion heating, and a speed adjustment button.

Versatile Use

The KINGJOY massager is designed for versatile application across various body parts:

- **Back Massage:** Position for upper back, lower back, or lumbar relief.
- **Neck & Shoulder Kneading:** Place behind the neck for targeted shiatsu massage.
- **Abdomen Heat:** Use the cushion side for soothing warmth on the abdominal area.
- **Calves Massage:** Position under calves for muscle relaxation.



The versatile design allows for full body application, providing massage and heat to the lumbar, neck, shoulders, abdomen, and calves.

MAINTENANCE

To ensure the longevity and hygiene of your KINGJOY massager, follow these simple maintenance guidelines:

- Always keep the massager clean and dry when not in use.
- The massager is made with skin-friendly fabric. Wipe the surface with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- Store the massager in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

If you encounter any issues with your KINGJOY massager, please refer to the following common troubleshooting tips:

- **Device not turning on or shutting off quickly:** Ensure the massager is fully charged. If the issue persists, try charging it for a longer period.
- **Heat function not noticeable:** Verify that the heat setting is activated. The massager side offers two heat levels (104°F/113°F). If the heat is still not felt, ensure the device is in direct contact with the body area.
- **Massage nodes not moving or weak:** Check the battery level. If the battery is low, the massage intensity may decrease. Recharge the device.

If these steps do not resolve the issue, please contact KINGJOY customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Product Dimensions	5.43 x 12.59 x 14.76 inches
Item Model Number	839A
Batteries	1 AAA batteries required (included)
Manufacturer	KINGJOY
Use for	Back, Legs, Neck, Whole Body
Power Source	Battery Powered
Material	Nylon
Item Weight	3.7 Pounds

WARRANTY & SUPPORT

The KINGJOY 2-in-1 Cordless Shiatsu Back Massager comes with a 1-year warranty, providing peace of mind for your purchase.

For any product inquiries, technical support, or warranty claims, please contact KINGJOY customer service. Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.