

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [COLAMY](#) /

› [COLAMY W509 Push Back Recliner Chair User Manual](#)

COLAMY W509

COLAMY W509 Push Back Recliner Chair User Manual

Model: W509

1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Maximum Weight Capacity:** This recliner chair is designed to support a maximum weight of **300 lbs**. Do not exceed this limit to prevent damage or injury.
- **Assembly Required:** Ensure all parts are correctly assembled and tightened before use. Refer to the "Assembly Instructions" section for detailed steps.
- **Reclining Mechanism:** Use caution when adjusting the reclining position to avoid injury. Ensure no body parts or objects are in the path of the moving parts.
- **Children and Pets:** Keep children and pets away from the recliner during assembly and operation.
- **Placement:** Place the recliner on a level surface. Avoid placing it near heat sources or in direct sunlight to prevent material degradation.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

PRODUCT DIMENSION



SHIP IN 2 BOX

!!!IMPORTANT NOTES

- Packages may ship separately and arrive on different days.
- Please allow up to 7 business days for ALL packages to arrive.



Image: Overview of all components included in the package for the COLAMY W509 Push Back Recliner Chair.

- Seat Part (1)
- Backrest (1)
- Left Leg Frame (1)
- Right Leg Frame (1)
- Metal Connectors (2)
- Grub Screws (2)
- Bolts (16)
- Wrench (1)
- Felt Mats (4)

3. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your COLAMY W509 Push Back Recliner Chair. It is recommended to have two people for assembly.

1. Prepare the Leg Frames:

Stick the four felt mats to the bottom of the leg frames to protect your floor. Insert one grub screw into the middle screw hole on each leg frame (Right Leg C and Left Leg D) and tighten by hand. Align the grub screw on the leg frame with the screw hole on the seat base and push the leg frame up with your hand to hold it in place. Ensure the "L" and "R" labels on the legs correspond to the correct sides.

2. Attach Leg Frames to Seat Base:

Place the seat part upside down on the ground. Use two metal connectors (E) on each leg to fix the legs with the seat base (B). Align the screw holes on the metal connectors, legs, and seat. Insert sixteen bolts (F) and tighten them to 50% using the provided wrench (H). Once all bolts are in place, tighten them to 100% securely.

Your browser does not support the video tag.

Video: Step-by-step assembly guide for the COLAMY W509 Push Back Recliner Chair, demonstrating how to attach the legs and backrest.

3. Attach the Backrest:

Attach the backrest (A) onto the finished seat part. Press down the backrest firmly until the connection is secure and you hear a click.

4. Secure the Cover Fabric:

Pull the cover fabric down tightly and secure it to the back of the seat using the velcro strips. This conceals the internal mechanism.

4. OPERATING INSTRUCTIONS

The COLAMY W509 recliner features a simple push-back mechanism for effortless adjustment.

- **To Recline:** To adjust the recliner, simply push against the backrest with your body weight. The chair will smoothly recline, and the footrest will extend automatically.
- **Reclining Positions:** The chair offers three adjustable reclining angles:
 - **Upright (approx. 105°):** Ideal for reading or working.
 - **Mid-Recline (approx. 120°):** Comfortable for watching TV.
 - **Full Recline (approx. 135-150°):** Perfect for napping or deep relaxation.
- **To Return to Upright Position:** Lean forward and gently push the footrest down with your legs until it locks into the upright position.

PREMIUM BREATHABLE LEATHER



Breathable



Soft Touch



Easy To Clean

Image: Visual representation of the three reclining positions (reading, watching TV, sleeping) for the COLAMY W509 Push Back Recliner Chair.

Your browser does not support the video tag.

Video: Demonstration of the push-back reclining mechanism and various comfortable positions of the COLAMY W509 Recliner Chair.

5. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your recliner.

- **Cleaning Upholstery:** The PU leather is easy to clean. For spills and stains, wipe immediately with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the material.
- **Dusting:** Regularly dust the chair with a soft, dry cloth.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading and cracking of the upholstery.

- **Moving the Chair:** When moving the chair, lift it rather than dragging it to prevent damage to the legs and frame.
- **Inspecting Connections:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if necessary.

6. TROUBLESHOOTING

If you encounter any issues with your recliner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Recliner does not recline smoothly or fully.	Mechanism obstruction, loose connections, or incorrect operation.	Ensure no objects are blocking the mechanism. Check all bolts and connections for tightness. Apply firm, consistent pressure to the backrest when reclining.
Footrest does not stay up.	Mechanism not fully engaged or worn springs.	Ensure the backrest is reclined to a position where the footrest can fully extend and lock. If the issue persists, contact customer support.
Chair feels wobbly or unstable.	Loose leg connections or uneven placement.	Check and tighten all bolts securing the leg frames to the seat. Ensure the chair is placed on a flat, even surface.
Missing parts upon delivery.	Packaging error or transit damage.	Immediately contact customer support with your purchase details for assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	COLAMY
Model Name	W509 Pushback Recliner Chair
Color	Cocoa
Product Dimensions	35"D x 32"W x 41.54"H
Item Weight	63 pounds
Maximum Weight Recommendation	300 Pounds
Material	Engineered Wood, Polyester, Wood (Upholstery: PU Leather, Fill: Memory Foam)
Back Style	Wing Back

Feature	Detail
Reclining Position Count	3
Recommended Uses	Reading, Relaxing, Sleeping



Image: Detailed product dimensions of the COLAMY W509 Push Back Recliner Chair, including height, width, and depth.

8. WARRANTY AND SUPPORT

Your COLAMY W509 Push Back Recliner Chair comes with certain protections and support options.

- **Return Policy:** Enjoy 30-day easy returns for your purchase.
- **Protection Plans:** Optional protection plans are available for extended coverage:
 - 2-Year Protection Plan

- 3-Year Protection Plan
- Asurion Complete Protect (monthly billing)
- **Customer Support:** For any questions, missing parts, or assistance, please contact COLAMY customer support. You can also visit the official [COLAMY Store](#) for more information.