

TIMEURE TU-2509

TIMEURE TU-2509 Pedometer Watch User Manual

Model: **TU-2509** | Brand: **TIMEURE**

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your TIMEURE TU-2509 Pedometer Watch. This device is designed to track your steps, calories, and distance without the need for a smartphone application or Bluetooth connection, offering a straightforward approach to fitness monitoring.

Key Features:

- **Simple & Easy to Use:** Instant step counting, calorie, and distance measurement directly on your wrist. No smartphone app or Bluetooth pairing required.
- **Accurate Step Tracking:** Filters out untrue steps from small daily movements, recording only continuous movement exceeding 10 seconds for effective tracking.
- **Large, Clear Display & Waterproof:** Bright, easy-to-read display for steps, calories, distance, and time. Features 50M water resistance and a 5-second EL bright backlight.
- **Comfortable Design:** Equipped with an American pedometer core and a soft silicone strap, suitable for wrists measuring 4.33-7.67 inches (110-197 mm).
- **Long Battery Life:** Includes a replaceable CR2032 battery that can last for over one year.

AVAILABLE IN DIFFERENT COLORS



Figure 1.1: The TIMEURE TU-2509 Pedometer Watch emphasizes ease of use with no app, no watch, no charging, and no Bluetooth/Wi-Fi required.

2. PRODUCT OVERVIEW

The TIMEURE TU-2509 Pedometer Watch features a clear digital display and intuitive button controls for easy navigation and data access.



Figure 2.1: The TIMEURE TU-2509 Pedometer Watch in Gold Black, showcasing its design and display.

Watch Components:

- **Display:** Shows time, date, steps, calories, and distance.
- **MODE Button:** Cycles through different display modes (Time, Steps, Calories, Distance).
- **LI/SET Button:** Used to enter and confirm settings.
- **CHECK Button:** Used to review historical data or adjust values during setting.
- **SWITCH Button:** Used to switch between units or adjust values during setting.
- **Backlight:** Illuminates the display for 5 seconds in low-light conditions.

PRODUCT SIZE

ADJUSTABLE WRISTBAND SIZE



Suitable for wrist width



11.2mm/0.44in  Net weight:48.8g/1.721oz

The image shows a side view of the watch case with a dimension line indicating its thickness. To the right is a small icon of a weight scale with 'KG' next to it, followed by the net weight in grams and ounces.

NOTE: manual measurement, there may be a little error

Figure 2.2: Product dimensions and adjustable wristband size (141-210mm or 5.5-8.2 inches) for the TIMEURE TU-2509 Pedometer Watch.

THE NIGHT MAKES IT STAND OUT MORE



Sunlight Effect



Night-light effect



Figure 2.3: Detailed view of the watch's etched case back, indicating model TU-2509 and CR2032 battery, and the polished metal buckle.

3. SETUP

3.1. Initial Activation

The watch comes with a CR2032 battery pre-installed. If the display is not active, remove any protective film from the battery compartment or ensure the battery is properly seated. No further activation is typically required.

3.2. Setting Time and Date

1. From the time display mode, press and hold the **LI/SET** button until the time digits begin to flash.
2. Use the **CHECK** or **SWITCH** buttons to adjust the flashing value (e.g., hours).
3. Press the **MODE** button to move to the next setting (e.g., minutes, 12/24-hour format, year, month, day).
4. Repeat steps 2 and 3 until all desired settings are adjusted.
5. Press the **LI/SET** button again to exit the setting mode and save your changes.

3.3. Wearing the Watch

Fasten the watch securely on your wrist. For accurate step tracking, ensure the watch is not too loose. The soft silicone strap is designed for comfort and fits wrist sizes between 4.33-7.67 inches (110-197 mm).

4. OPERATING INSTRUCTIONS

4.1. Navigating Display Modes

Press the **MODE** button repeatedly to cycle through the different display modes:

- **Time Display:** Shows current time and date.
- **Step Counter:** Displays the total steps taken for the current day.
- **Calorie Tracker:** Shows estimated calories burned.
- **Distance Tracking:** Displays the estimated distance traveled (Km/Miles switchable).
- **Alarm:** Allows setting and viewing of the alarm.
- **Countdown:** (If available, refer to specific on-screen prompts).



MULTIPLE SPORTS MODES

Equipped with a variety of physical exercise modes to accompany you to do a variety of exercises, sports data display is more clear and intuitive, each step counted.

-  Steps
-  Calories
-  Mileage
Km / Miles switchable
-  Countdown
-  Historical steps
Check yesterday's steps
-  30m waterproof
Swimming and shower
-  5-second EL backligh!

Figure 4.1: The watch offers multiple sports modes including steps, calories, mileage, countdown, historical steps, 30m

4.2. Step Tracking

The watch automatically tracks your steps. To ensure accuracy, the pedometer filters out small, incidental movements. Step counting will begin to record only when continuous movement exceeds 10 seconds.

4.3. Calorie and Distance Tracking

Based on your steps, the watch estimates calories burned and distance traveled. These values are displayed in their respective modes. You can switch between Kilometers (Km) and Miles for distance tracking using the **SWITCH** button when in distance mode, if supported by the model.

4.4. Setting the Alarm

1. Navigate to the Alarm mode using the **MODE** button.
2. Press and hold the **LI/SET** button until the alarm time digits flash.
3. Use the **CHECK** or **SWITCH** buttons to adjust the alarm hour.
4. Press the **MODE** button to move to the alarm minutes.
5. Use the **CHECK** or **SWITCH** buttons to adjust the alarm minutes.
6. Press the **LI/SET** button to save the alarm time.
7. To activate/deactivate the alarm, press the **CHECK** button while in Alarm mode. An alarm icon will appear/disappear on the display.

4.5. Using the Backlight

In low-light conditions, press the **LI/SET** button to activate the EL backlight. The display will illuminate for approximately 5 seconds.



Figure 4.2: The watch display with the 5-second EL backlight activated, enhancing visibility in the dark.

4.6. Checking Historical Steps

The watch may store historical step data. To check previous day's steps, navigate to the step counter mode and press the **CHECK** button. Refer to the on-screen prompts for specific navigation.

5. MAINTENANCE

5.1. Cleaning Your Watch

To clean your watch, wipe it with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the watch's finish and seals.

5.2. Water Resistance

The TIMEURE TU-2509 Pedometer Watch is rated for 50M water resistance. This means it is suitable for showering, bathing, and swimming in shallow water. It is not recommended for diving, snorkeling, or high-pressure water activities.

Waterproof and capricious



swim



rinse



bathe



sweat



Figure 5.1: The watch is designed to be waterproof for activities like swimming, rinsing, bathing, and during sweating.

5.3. Battery Replacement

The watch uses one CR2032 button cell battery. When the display becomes dim or unresponsive, it is time to replace the battery. The battery life is approximately one year.

1. Using a small screwdriver, carefully open the battery compartment cover on the back of the watch.
2. Remove the old CR2032 battery.
3. Insert a new CR2032 battery with the positive (+) side facing up.
4. Replace the battery compartment cover and tighten the screws securely to maintain water resistance.

6. TROUBLESHOOTING

- **Watch not counting steps accurately:**

Ensure the watch is worn snugly on your wrist. The pedometer requires continuous arm movement to register steps; very slight or inconsistent movements may be filtered out. If using a walker or pushing a cart, arm movement may be reduced, affecting step count accuracy.

- **Display is dim or blank:**

The battery may be low or depleted. Replace the CR2032 battery as described in Section 5.3.

- **Cannot set time or date:**

Ensure you are pressing and holding the **LI/SET** button long enough to enter setting mode. Follow the steps in Section 3.2 carefully.

- **Watch is unresponsive:**

Try replacing the battery. If the issue persists, contact customer support.

7. SPECIFICATIONS

Feature	Specification
Model Number	TU-2509
Brand	TIMEURE
Display Type	Digital
Screen Size	42 Millimeters
Sensor Type	Pedometer
Water Resistance	50M
Battery Type	CR2032 (Replaceable)
Battery Life	Approximately 1 year
Material	Metal (case), Silicone (strap)
Item Weight	91 g
Wrist Size Compatibility	110-197 mm (4.33-7.67 inches)
Compatible Devices	NO (Standalone device)

8. WARRANTY AND SUPPORT

8.1. Warranty Information

Warranty details for the TIMEURE TU-2509 Pedometer Watch are typically provided at the point of purchase or can be obtained directly from the manufacturer. Please retain your proof of purchase for any warranty claims.

8.2. Customer Support

For further assistance, technical support, or inquiries regarding your TIMEURE TU-2509 Pedometer Watch, please refer to the contact information provided by your retailer or visit the official TIMEURE website.

