

REACHER GX2

REACHER GX2 Travel Vibrating Alarm Clock

USER MANUAL

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your REACHER GX2 Travel Vibrating Alarm Clock. Designed for heavy sleepers, travelers, and those in shared spaces, the GX2 offers a silent yet effective wake-up experience through its powerful vibration and user-friendly features.

Key features include a rechargeable battery with up to 7 days of life, dual alarms for flexible scheduling, an auto-dimming display for optimal visibility, and a compact, portable design.



Figure 1: REACHER GX2 Travel Vibrating Alarm Clock

Package Contents

Please check the package for the following items:

- REACHER GX2 Travel Vibrating Alarm Clock
- USB-C Charging Cable
- Instruction Sheet

Setup

1. Charging the Device

Before first use, fully charge the alarm clock. Connect the provided USB-C cable to the charging port on the side of the device and plug the other end into a compatible USB power adapter (not included). A full charge typically takes approximately 3 hours and provides up to 7 days of battery life.



Figure 2: USB-C Charging Port

2. Initial Time Setting

Refer to the instruction sheet for specific steps on setting the current time. Generally, this involves pressing the 'SET' button and using the '+' and '-' buttons to adjust hours and minutes.

Operating Instructions

1. Controls Overview

The alarm clock features intuitive controls located on its side:

- **SET Button:** Used to enter time and alarm setting modes.
- **SNOOZE Button:** Activates the snooze function when an alarm sounds.
- **'+' Button:** Increases values during setting, adjusts vibration intensity.
- **'-' Button:** Decreases values during setting, adjusts vibration intensity.

Easy-to-Use Design

Fewer Buttons — No Manual Needed



Figure 3: Control Buttons

2. Setting Alarms

The GX2 supports two independent alarms. To set an alarm:

1. Press the 'SET' button repeatedly until 'AL1' or 'AL2' appears on the display.
2. Use the '+' and '-' buttons to adjust the desired wake-up time.
3. Press 'SET' again to confirm and move to the next setting (e.g., alarm intensity).
4. Repeat for the second alarm if needed.

Dual Alarms for Two Schedules



Figure 4: Dual Alarm Functionality

3. Vibration Alarm

The GX2 utilizes a gradual vibration pattern to gently wake users. The vibration intensity increases over time to ensure effective wake-up without sudden jolts. Place the device under your pillow for optimal effect.

Dual Alarm, Double Reminder

Ensure you wake up, never oversleep



Figure 5: Powerful Bed Shaker Mechanism

Gradual Vibration Alarm

Wake up gradually, not with a jolt




Figure 6: Gradual Vibration Alarm Progression

Silent Yet Powerful Wake-Up Bed Shaker



Figure 7: Silent Wake-Up Experience

4. Snooze Function

When an alarm is active, press the 'SNOOZE' button to temporarily pause the alarm. The alarm will reactivate after a set period (refer to the instruction sheet for default snooze duration, typically 9 minutes).

5. Auto-Dimming Display

The GX2 features an intelligent display that automatically adjusts its brightness based on ambient light conditions. This ensures clear visibility during the day and a soft, non-disruptive glow at night, promoting a restful sleep environment.



Figure 8: Auto-Dimming Display in Different Light Conditions

Maintenance

1. Cleaning

To clean the device, gently wipe the exterior with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or spraying liquids directly onto the device.

2. Battery Care

To prolong battery life, avoid fully discharging the device frequently. Recharge the battery when the low battery indicator appears. If storing the device for an extended period, charge it to approximately 50% every few months.

Troubleshooting

- **Device not turning on:** Ensure the device is charged. Connect it to a power source using the USB-C cable.
- **Alarm not activating:** Verify that the alarm is set correctly and enabled. Check the alarm time and ensure it is not set for AM/PM incorrectly.
- **Display not visible:** The auto-dimming feature adjusts brightness. In very dark environments, the display may be very dim. Move the device or press a button to temporarily brighten it. Ensure the device is charged.
- **Vibration is weak:** Ensure the device is fully charged. Adjust vibration intensity settings using the '+' and '-' buttons in alarm setting mode.

Specifications

Brand	REACHER
-------	---------

Model Number	GX2
Display Type	Digital
Special Features	Auto Dimmable, Rechargeable, Snooze, Vibrate
Product Dimensions	3.2"W x 3.2"H
Power Source	Battery Powered
Item Weight	10.9 ounces (0.68 Pounds)
Battery Life	Up to 7 days (rechargeable)
Charging Port	USB-C

Warranty and Support

Warranty Information



The REACHER GX2 Travel Vibrating Alarm Clock comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use. It does not cover damage caused by misuse, accidents, or unauthorized modifications.





Customer Support

For technical assistance, warranty claims, or any questions regarding your REACHER GX2 alarm clock, please contact REACHER customer support. Refer to the product packaging or the official REACHER website for the most current contact information.


© 2025 REACHER. All rights reserved.

Related Documents - GX2

	<p>Reacher GX Alarm Clock User Manual: Setup, Features, and Safety Guide</p> <p>Comprehensive user guide for the Reacher GX portable alarm clock. Learn how to set time, alarms, wake-up modes, vibration, auto-dimming, and safety features. Includes troubleshooting and support information.</p>
	<p>Reacher ACR-2P Radio Alarm Clock User Manual</p> <p>Comprehensive user manual for the Reacher ACR-2P Radio Alarm Clock, covering features like FM radio, dual alarms, snooze, dimmer, USB charging, thermometer, sleep timer, and detailed instructions for setting time, alarms, and using radio functions.</p>

	<p>Reacher R7 Sunrise Alarm Clock User Manual - Setup, Features, and Troubleshooting</p> <p>Comprehensive user manual for the Reacher R7 Sunrise Alarm Clock. Learn how to set up, use features like the alarm, sound machine, nightlight, and understand safety instructions and warranty information.</p>
	<p>Reacher Clock-A1C1S Digital Alarm Clock User Manual</p> <p>Comprehensive user manual for the Reacher Clock-A1C1S digital alarm clock, covering setup, time and alarm settings, snooze, volume, dimmer, USB charging, and care instructions.</p>
	<p>Reacher R3 Digital Alarm Clock User Manual</p> <p>Comprehensive user manual for the Reacher R3 digital alarm clock, covering setup, time and alarm settings, snooze, sound machine functions, and battery backup.</p>
	<p>Reacher C50 LED Digital Alarm Clock User Manual</p> <p>User manual for the Reacher C50 LED Digital Alarm Clock. Provides instructions on setting time, alarms, using the night light, timer, snooze function, and safety guidelines.</p>

Documents - REACHER – GX2

	<p>[pdf] Instructions</p> <p>Manuals instructions and parts books Hobkirk Sewing Machines zoje zj600 blindstitch instruction book hobkirk co uk images pictures industrial </p> <p>TABLE BLIND STITCH MACHINE 1* - --- mt PARTS BOOK 1i ffl tji PJ.I PARTS BOOK . IIJ 1 1 IIJ JI ... 1 GS9-2 8 G07-2 9 GZZ-2 10 G04-2 11 Gsso 12 GSSO 13 GHI- 2 14 GX3-2 15 GOS-2 16 GX2-2 11 G06-2 GCI-2 GX102-2 18 GCZ-2 1JJ GS43 zo GC4-2 GC3-2 GOI0-2 GZ3-2 GXI03-2 G0...</p> <p>lang:i-klngon score:31 filesize: 1.47 M page_count: 49 document date: 2018-10-06</p>
