



Manuals.plus /

- › Homaskylynn /
- › Siaasoo Massage Master Shiatsu Neck and Shoulder Massager User Manual

## Homaskylynn Massage Master

# Siaasoo Massage Master Shiatsu Neck and Shoulder Massager User Manual

Model: Massage Master | Brand: Homaskylynn

## 1. INTRODUCTION

Thank you for choosing the Siaasoo Massage Master Shiatsu Neck and Shoulder Massager. This device is designed to provide deep tissue kneading and soothing heat therapy to help relieve tension and discomfort in your neck, shoulders, and other targeted areas. Please read this manual thoroughly before use to ensure safe and effective operation.



Image: The Siasoo Massage Master, a green, ergonomic massager with hand-like massage heads, shown both individually and being worn on a user's neck and shoulder.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

To reduce the risk of electric shock, burns, fire, or injury, always follow these basic safety precautions:

- Do not use this massager near water or in damp environments.
- Unplug the device from the power outlet when not in use and before cleaning.
- Do not operate if the cord or plug is damaged, or if the device malfunctions or has been dropped.
- Keep the device away from heated surfaces.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Consult a doctor before use if you have any medical conditions, are pregnant, or have a pacemaker.
- Do not use the massager for more than 15 minutes at a time to avoid overheating.

### 3. PACKAGE CONTENTS

---

Verify that all items are present in your package:

- Siaasoo Massage Master (1 or 2 units, depending on purchase)
- USB Charging Cable
- User Manual



## Package List

Image: A view of the product packaging, including the green massager, its retail box, a user manual, and a white USB charging cable, laid out on a white surface.

### 4. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your Siaasoo Massage Master.

## Realistic hand grasp Fits the shoulder and neck curvature



V-multi-dimensional fit to the neck's curve



✓ Like a thumb pressing and pushing  
the thick trapezius muscle

Image: A detailed view of the massager's ergonomic design, highlighting the 'Upper massage head' and 'Lower massage head' positions, which conform to the neck's curvature and mimic a thumb-pressing sensation.

**Silicone massage head firmly grips shoulder and neck muscles, massage without shaking or constantly adjusting position, more comfortable to massage**

**0 upper  
massage head**



**0 lower  
massage head**



Image: A woman demonstrating the use of the massager, showing how the silicone massage heads firmly grip the shoulder and neck muscles for comfortable and stable massage.

- **Massage Heads:** Flexible, food-grade silicone heads designed to mimic a realistic fingertip massage sensation.
- **Control Panel:** Located on the main unit, typically includes power, mode, and heat buttons.
- **Adjustable Straps:** For securing the massager comfortably around the neck and shoulders.
- **Charging Port:** For connecting the USB charging cable.

**30 degrees flexible food-grade silicone**  
**Strong grip feeling    Easy to Clean**



**Realistic fingertip massage sensation**


**Makes the massage head press with fingertip-like elasticity**

Image: A close-up of the massager's silicone heads, showing a red glow, indicating the heat function. Text highlights the 30-degree flexible food-grade silicone, strong grip, easy cleaning, and realistic fingertip massage sensation.

## **5. SETUP AND CHARGING**

1. **Initial Charge:** Before first use, fully charge the massager using the provided USB cable. Connect the cable to the charging port on the device and a suitable USB power adapter (not included). The indicator light will show charging status.
2. **Positioning:** Place the massager around your neck and shoulders. Adjust the straps for a snug, comfortable fit. Ensure the massage heads are positioned on the desired muscle areas.

## Comfortable work



Shiatsu Back and Neck Massager for pain relief deep tissue  
Relieves strain on shoulders and neck

Image: A woman comfortably using the Siaasoo Massage Master while working at a desk, illustrating how the device can relieve strain on shoulders and neck during daily activities.

## 6. OPERATING INSTRUCTIONS

Follow these steps to operate your massager:

1. **Power On/Off:** Press and hold the power button on the control panel to turn the massager on or off.
2. **Massage Modes:** Short press the mode button to cycle through different massage techniques (e.g., kneading, shiatsu, combination).
3. **Heat Function:** Press the heat button to activate the soothing heat function. The massager offers two heat levels: Low-end (40°C) and High-end (45°C). Press again to cycle or turn off.
4. **Automatic Shut-off:** The massager is equipped with an automatic shut-off feature, typically after 10-15 minutes, to prevent overuse and conserve battery.



Image: An illustration of the massager in use on a neck, highlighting the two available heat settings: 40°C (Low-end) and 45°C (High-end).



## Use small power to exert great energy

10 minutes a day, up to 12 days of battery life

Integrated design reduces loose connections and part friction inside the movement, improves energy transfer efficiency, optimizes circuit design, and reduces power consumption



Image: An X-ray style view of the massager's internal components, emphasizing its integrated design for energy efficiency and extended battery life (up to 12 days with 10 minutes of daily use).

## 7. MAINTENANCE

---

- **Cleaning:** Wipe the massager with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the massager in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge regularly, even if not used for extended periods.

## 8. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Massager does not turn on.	Low battery or not charged.	Charge the device fully using the USB cable.
Massage intensity feels weak.	Improper positioning or low battery.	Adjust the massager's position. Ensure the device is fully charged.
Heat function not working.	Heat function not activated or device not powered on.	Ensure the massager is on and press the heat button. Allow a few minutes for the heat to build up.

## 9. SPECIFICATIONS

---

- **Brand:** Homaskylynn
- **Model Name:** Massage Master
- **ASIN:** B0FKBNDWKH
- **Dimensions (L x W x H):** 7.9 x 7.9 x 7.9 cm (approximately 3.1 x 3.1 x 3.1 inches)
- **Item Weight:** 790 Grams (approximately 1.74 lbs)
- **Heat Levels:** 40°C (Low-end), 45°C (High-end)
- **Power Source:** Rechargeable Battery (USB charging)
- **Country of Origin:** China

## 10. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the documentation included with your purchase or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.