

[Manuals.plus](#) /

› [Dreamegg](#) /

› Dreamegg Digital Alarm Clock Radio with Night Light (Model CH09) User Manual

Dreamegg CH09

Dreamegg Digital Alarm Clock Radio with Night Light

MODEL: CH09 USER MANUAL

Introduction

Thank you for choosing the Dreamegg Digital Alarm Clock Radio (Model CH09). This versatile 4-in-1 device combines an alarm clock, FM radio, white noise sound machine, and a night light, designed to enhance your sleep and waking experience. It features dual alarms, 25 soothing sounds, an adjustable LED display, a customizable night light, a sleep timer, and convenient USB charging ports. Please read this manual carefully to ensure proper use and to fully enjoy all the features of your new device.

Safety Information

- Do not expose the device to water or excessive moisture.
- Avoid placing the device near heat sources or in direct sunlight.
- Use only the provided power adapter to prevent damage.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Keep out of reach of children.
- Ensure proper ventilation around the device.

Package Contents

Please check the package for the following items:

- Dreamegg CH09 Digital Alarm Clock Radio
- Power Adapter
- USB Cable
- User Manual (this document)

Product Overview

Familiarize yourself with the various parts and controls of your Dreamegg CH09 device.

4-in-1 Alarm Clock Radio



FM Radio



Dual Alarm



Night Light




Sound Machine



Figure 1: Front view of the Dreamegg CH09, highlighting its 4-in-1 functionality: FM Radio, Dual Alarm, Night Light, and Sound Machine.

Commandes claires, ports pratiques



Port de charge

Ports USB doubles

Prise casque

Antenne radio

Figure 2: Rear panel of the device, illustrating the clear controls and practical ports including the charging port, dual USB ports, headphone jack, and radio antenna.

Controls and Ports:

- **LED Display:** Shows time, alarm status, and other settings.
- **Control Buttons:** For setting time, alarms, radio, and sound modes.
- **Night Light Dimmer:** A rotary knob to adjust the night light brightness.
- **Dual USB Ports:** For charging external devices.
- **Headphone Jack:** For private listening.

- **FM Antenna:** For radio reception.

Setup

1. Power Connection

1. Connect the provided USB cable to the charging port on the back of the alarm clock.
2. Plug the power adapter into a standard electrical outlet.
3. The LED display will light up, indicating the device is powered on.

2. Setting the Time

1. Press and hold the 'Time Set' button (usually indicated by a clock icon) until the hour digits flash.
2. Use the '+' or '-' buttons to adjust the hour.
3. Press 'Time Set' again to confirm the hour and move to minute adjustment.
4. Use the '+' or '-' buttons to adjust the minutes.
5. Press 'Time Set' one more time to save the time.

3. Setting the Alarm

The device supports dual alarms, allowing for separate settings for weekdays and weekends.




Figure 3: Illustration of dual alarm settings for personalized scheduling, showing separate times for weekends and weekdays.

1. Press and hold the 'Alarm 1' button (usually indicated by an alarm clock icon with '1') until the hour digits flash.
2. Use the '+' or '-' buttons to adjust the alarm hour.
3. Press 'Alarm 1' again to confirm the hour and move to minute adjustment.
4. Use the '+' or '-' buttons to adjust the alarm minutes.
5. Press 'Alarm 1' again to select the alarm sound (FM radio or a white noise sound).
6. Press 'Alarm 1' one more time to save the alarm setting.
7. Repeat the process for 'Alarm 2' using the 'Alarm 2' button.

Operating Instructions

1. FM Radio

Enjoy your favorite radio stations with the built-in FM radio (76.0 - 108.0 MHz).



Figure 4: The device features a built-in FM radio, allowing you to tune into your favorite stations.

1. Extend the FM antenna on the back of the device for better reception.
2. Press the 'FM' button to turn on the radio.
3. Press the '+' or '-' buttons to manually tune to a frequency.
4. Press and hold the '+' or '-' buttons to auto-scan for the next available station.
5. To save a station, press and hold the 'FM' button until the preset number flashes, then use '+' or '-' to select a preset slot and press 'FM' again to save.

6. Press the 'FM' button again to turn off the radio.

2. White Noise Sound Machine

Choose from 25 soothing sounds to help you relax or fall asleep.



Figure 5: A selection of 25 calming sounds available, including nature sounds, colored noises, baby lullabies, meditation melodies, and fan sounds.

- Press the 'Sound' button (usually indicated by a musical note icon) to cycle through the available sounds.
- Use the volume '+' or '-' buttons to adjust the sound level.

- The 25 sounds include 6 nature sounds (bird song, waves, river, 2 rain sounds, crickets), 6 colored noises (2 brown, 2 pink, 2 white), 8 baby lullabies, 3 meditation melodies, and 2 fan sounds.

3. Night Light

The integrated night light offers continuous dimming from 0% to 100% to create a comfortable ambiance.



Figure 6: The night light features a 5-level dimmer, allowing you to adjust brightness for reading, nighttime, or complete darkness.

- Rotate the 'Night Light Dimmer' knob (located on the side/back) to adjust the brightness of the night light.
- The night light can be adjusted from 0% (off) to 100% brightness.

4. LED Display Brightness

The large LED display has 5 adjustable brightness levels to suit your preference and protect your eyes at night.



Figure 7: The clear LED display shows the time with adjustable brightness levels.

- Press the 'Display Brightness' button (often combined with the snooze button or a sun icon) to cycle through the 5 brightness levels.
- Select the desired brightness for the time display.

5. Sleep Timer

Set a timer for sounds or radio to play for a duration of 10 to 480 minutes before automatically turning off.



Figure 8: The sleep timer function allows you to set playback duration from 10 to 480 minutes.

1. While a sound or FM radio is playing, press the 'Sleep Timer' button (often indicated by a 'Zz' or moon icon).
2. Each press will cycle through preset timer durations (e.g., 10, 30, 60, 120, 180, 240, 480 minutes).
3. Select your desired duration. The sound/radio will automatically turn off after the set time.

6. Snooze Function

When the alarm sounds, press the 'Snooze' button (usually a large button on top) to temporarily silence the alarm for a few minutes. The alarm will sound again after the snooze period.

7. USB Charging Ports

The device includes two USB ports for convenient charging of your mobile devices.



Figure 9: Dual USB ports allow you to charge two devices simultaneously, helping to keep your desk clutter-free.

- Connect your device's charging cable to one of the USB ports on the back of the alarm clock.
- The alarm clock must be powered on for the USB ports to function.

8. Headphone Jack

For private listening of the FM radio or white noise sounds, use the headphone jack.



Figure 10: The headphone jack allows for private listening without disturbing others.

- Plug your 3.5mm headphones into the headphone jack on the back of the device.
- The sound will automatically switch from the speaker to your headphones.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, unplug the device and store it in a cool, dry place.
- **Casing:** The casing is made of durable plastic with a wood-like finish. Avoid harsh chemicals that may damage the finish.

Troubleshooting

Here are solutions to common issues you might encounter:

Problem	Solution
Device does not power on.	Ensure the power adapter is securely plugged into both the device and a working electrical outlet.
Alarm does not sound.	Check if the alarm is enabled and set to the correct time. Verify the alarm volume is not set to zero.
FM radio reception is poor.	Fully extend the FM antenna. Try repositioning the device or the antenna for better signal.
USB charging is slow.	The USB ports are designed for standard charging. For faster charging, use a dedicated fast charger. Ensure your cable is not damaged.
Display is too bright/dim.	Adjust the LED display brightness using the dedicated button.
Night light is not working or too dim/bright.	Rotate the 'Night Light Dimmer' knob to adjust the brightness.

Frequently Asked Questions (FAQ):

- **Q: Can I use the FM radio in timer mode?**
A: Yes, you can freely choose between FM radio or 25 soothing sounds for sleep. The sound will automatically stop at the end of the timer.
- **Q: What type of power supply does this alarm clock use?**

A: The alarm clock must be plugged into an electrical outlet to function. A charger and charging cable are included in the box. It is ready for use right out of the box.

• **Q: Does this alarm clock allow setting multiple alarm times?**

A: Yes, it supports dual alarms. You can set one for weekday mornings and another for more relaxed weekends, without having to reprogram it every night.

Specifications

Feature	Detail
Brand	Dreamegg
Model Number	CH09
Color	Brown
Display Type	Digital LED
Style	Modern
Special Features	Alarm, FM Radio, White Noise Machine, Night Light, Dual USB Ports, Headphone Jack
Product Dimensions (L x H)	7.8 x 7.8 centimeters
Power Source	Corded Electric
Shape	Cube
Usage	Indoor
Frame Material	Metal (with wood-look finish)
Item Weight	217 Grams
Connectivity Technology	USB
Number of Items	1

Warranty and Support

Dreamegg products are designed for reliability and performance. For warranty information or technical support, please refer to the warranty card included in your package or visit the official Dreamegg website. If you encounter any issues not covered in this manual, please contact our customer service team for assistance.

Contact Information: Please refer to your product packaging or the Dreamegg official website for the most up-to-date customer support contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question