

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Potupus](#) /

› [Potupus T300 Pro Max Electric Walking Pad with Handle Bar User Manual](#)

Potupus T300 Pro Max

Potupus T300 Pro Max Electric Walking Pad with Handle Bar User Manual

Model: T300 Pro Max

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Potupus T300 Pro Max Electric Walking Pad with Handle Bar. Please read this manual thoroughly before assembly, operation, or maintenance to ensure proper function and user safety. Keep this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of burns, fire, electric shock, or injury to persons, read the following important precautions and information before operating the treadmill.

- Always place the treadmill on a level surface.
- Keep children and pets away from the treadmill during operation.
- Ensure adequate clear space (at least 2 meters behind and 0.6 meters on each side) around the treadmill.
- Wear appropriate exercise clothing and athletic shoes. Avoid loose clothing that could get caught.
- Do not operate the treadmill if it has a damaged cord or plug, or if it is not working properly.
- Always hold the handle bar when starting or stopping the treadmill, and during operation if needed for balance.
- Do not exceed the maximum user weight of 350 lbs (158 kg).
- Disconnect power before cleaning or performing maintenance.
- Use the safety key/clip at all times. In case of emergency, the safety key will stop the treadmill.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Potupus T300 Pro Max Walking Pad Treadmill
- User Manual
- L-shaped wrench and screws

4. SETUP AND ASSEMBLY

Assembly is required for the Potupus T300 Pro Max Walking Pad. It is recommended to have assistance during assembly due to potential alignment challenges and the need for force to secure components.

1. **Unpacking:** Carefully remove all components from the packaging. Place the main treadmill unit on a flat, stable surface.
2. **Handle Bar Installation:**
 - Position the handle bar assembly over the designated slots on the treadmill base.
 - Align the screw holes. This step may require significant effort and adjustment to ensure proper alignment. It is crucial to ensure the internal wiring is not pinched or damaged during this process.
 - Secure the handle bar using the provided L-shaped wrench and screws. Ensure all screws are tightened securely.
3. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Note on Folding: The handle bar is designed to be detachable for storage. To fold the treadmill flat, the handle bar screws and bolts must be removed. The unit does not fold with the handle bar fully assembled and attached.



Figure 4.1: Detachable Handlebar and Storage Options. The handlebar can be removed for flat storage, and the unit features wheels for easy

5. OPERATING INSTRUCTIONS

The Potupus T300 Pro Max offers versatile exercise modes and an intuitive LED display.

5.1 Getting Started

1. **Power On:** Connect the power cord and flip the main power switch (if present). The LED display will illuminate.
2. **Attach Safety Key:** Clip the safety key to your clothing and insert it into the designated slot on the console. The treadmill will not operate without the safety key in place.
3. **Start Exercise:** Press the 'Start' button on the console or remote control. The treadmill will begin at a low speed (e.g., 0.6 MPH).

5.2 Adjusting Speed and Modes

The treadmill supports a speed range of 0.6 to 7.6 MPH.

- Use the '+' and '-' buttons on the console or remote to increase or decrease speed.
- The treadmill features multiple modes:
 - **Walking Mode:** 0.6 - 2.0 MPH
 - **Jogging Mode:** 2.0 - 4.0 MPH
 - **Running Mode:** 4.0 - 7.6 MPH
- Press the 'M' button on the console or remote to set a countdown for your workout (e.g., time, distance, or calories). The auto-stop feature will halt the treadmill once the countdown is complete.

3-IN-1 Compact Walking Pad Treadmill with Handles and Incline

Multiple Speed Modes for Home & Office Workouts



Figure 5.1: Exercise Modes and Speed Ranges.

5.3 LED Display

The integrated LED display provides real-time workout data:

- **TIME:** Duration of your workout.
- **DIST:** Distance covered in miles.
- **MPH:** Current speed in miles per hour.
- **CAL:** Estimated calories burned.

Electric Walking Pad Treadmill with LED Display

Clear Exercise Data Display, Easy to Read




Figure 5.2: LED Display showing workout metrics.

5.4 Stopping the Treadmill

To stop the treadmill, press the 'Stop' button on the console or remote control. Alternatively, pulling the safety key will immediately stop the treadmill.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your walking pad.

- **Cleaning:** Wipe down the treadmill surface with a damp cloth after each use. Avoid abrasive cleaners or solvents.
- **Belt Lubrication:** The walking belt requires periodic lubrication to reduce friction and wear. Refer to the specific lubrication instructions provided with your treadmill's lubricant. Generally, apply silicone lubricant under the belt every 3-6 months, depending on usage.
- **Belt Adjustment:** If the walking belt shifts to one side or slips, it may need adjustment. Use the provided wrench to turn the rear roller bolts in small increments (quarter turns) to center and tension the belt.
- **Motor Compartment:** Keep the motor compartment clean and free of dust. Do not open the motor cover

unless instructed by customer support.

7. TROUBLESHOOTING

If you encounter issues with your Potupus T300 Pro Max, refer to the following common solutions:

Problem	Possible Cause	Solution
Treadmill does not start	Power cord not plugged in; Safety key not inserted; Main power switch off.	Check power connection; Insert safety key; Turn on main power switch.
Walking belt slips or stops	Belt too loose; Belt needs lubrication; Overload.	Adjust belt tension; Lubricate belt; Reduce user weight or speed.
Unusual noise during operation	Loose parts; Belt friction; Motor issue.	Check and tighten all visible bolts; Lubricate belt; Contact customer support if noise persists.
Speed display is inaccurate	Calibration issue; Sensor malfunction.	While the display provides an estimate, for precise tracking, use a personal fitness tracker. If significantly off, contact customer support.
Handle bars wobble	Loose assembly screws.	Ensure all handle bar assembly screws are fully tightened. Re-tighten if necessary.

If the problem persists after attempting these solutions, please contact Potupus customer support.

8. SPECIFICATIONS

Brand	Potupus
Model Name	T300 Pro Max
Color	Black-b
Product Grade	Home-use
Product Dimensions (LxWxH)	42"D x 21"W x 36"H
Folded Size	38.9"x16.3"x3.7"
Item Weight	31 Pounds
Material	Carbon Steel, Plastic
Maximum Horsepower	3 HP
Minimum Speed	0.6 MPH
Maximum Speed	7.6 MPH
Maximum Weight Recommendation	350 Pounds

Deck Length	38.95 Inches
Deck Width	16.3 Inches
Display Type	LED
Screen Size	18 Inches
Metrics Measured	Calories Burned, Distance, Speed, Time
Power Source	Corded Electric
Assembly Required	Yes

9. WARRANTY AND SUPPORT

9.1 Manufacturer's Warranty

The Potupus T300 Pro Max Electric Walking Pad is covered by a **1-Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

Potupus offers **365-Day 24/7 Worry-Free Service Support**. If you have any questions, concerns, or require assistance with your product, please contact our customer service team. Refer to the product packaging or the official Potupus website for contact information.