

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CULT](#) /

› [Cult Walking pad Prime Treadmill User Manual \(Model: Cultwalkpadprime\)](#)

## CULT Cultwalkpadprime

# Cult Walking pad Prime Treadmill User Manual

Model: Cultwalkpadprime

## INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Cult Walking pad Prime Treadmill. Please read it thoroughly before assembly or operation and retain it for future reference. This compact and foldable under-desk treadmill is designed for home use, offering a convenient way to incorporate walking into your daily routine.

## IMPORTANT SAFETY INFORMATION

To ensure safe operation and prevent injury, adhere to the following guidelines:

- **Maximum Weight Capacity:** The treadmill supports users up to 100 kg. For optimal safety, select a treadmill that can support at least 20 kg more than your current weight.
- **Usage Recommendation:** This product is designed for walking only. Running on this treadmill is not recommended and may void the warranty.
- **Power Supply:** Use the treadmill with a stabilizer (1000 VA recommended) to maintain the 220 - 240V rated voltage. This is crucial for the 2-year warranty validity and machine longevity.
- **Placement:** Position the treadmill on a flat, stable surface, ensuring adequate clearance around it for safe entry and exit.
- **Supervision:** Keep children and pets away from the treadmill during operation.
- **Footwear:** Always wear appropriate athletic footwear while using the treadmill.
- **Emergency Stop:** If you feel faint, dizzy, or experience pain, stop your workout immediately.

# Made to Keep You Moving

Low-noise motor built for smooth, everyday use



Image: A user walking on the Cult Walking pad Prime Treadmill, illustrating its use and highlighting the maximum weight capacity of 100 kg and speed range of 1-10 km/h.

## PACKAGE CONTENTS

Before proceeding with assembly, verify that all the following components are present in your package:

- Walking pad Treadmill Unit
- Remote Control
- Tool kit
- User Manual & Warranty card
- Lubrication oil

# Engineered for **Stability**

Max Weight  
**100 kg**

Speed Range  
**1-10 km/h**



Image: The Cult Walking pad Prime Treadmill displayed with its essential accessories, including the remote control, tool kit, and lubrication oil.

## SETUP INSTRUCTIONS

Follow these steps to set up your treadmill:

- 1. Unpacking:** Carefully remove all components from the packaging. Retain packaging for potential future transport or returns.
- 2. Placement:** Position the treadmill on a firm, level surface. Ensure there is at least 2 meters of clear space behind the treadmill and 0.5 meters on each side.
- 3. Unfolding the Handle (if applicable):** If the handle is folded, gently raise it to the upright position until it securely locks into place.
- 4. Power Connection:** Connect the power cord to the treadmill's power inlet, then plug it into a grounded electrical outlet via a 1000 VA stabilizer.
- 5. Initial Inspection:** Before first use, visually inspect all parts and connections to ensure they are tight and secure.



Image: The Cult Walking pad Prime Treadmill fully assembled and ready for use, showcasing its complete profile.

## OPERATING INSTRUCTIONS

### Powering On/Off

After connecting the treadmill to power, the LED display will illuminate. To begin a session, press the power button on the remote control. To end your session, press the power button on the remote control again or disconnect the power cord.

### Using the Remote Control

The included remote control provides convenient, hands-free operation:

- **Start/Stop:** Press this button to initiate or conclude your walking session.
- **Speed Adjustment:** Use the '+' button to increase speed and the '-' button to decrease speed. The speed range is 1-10 km/h.



Image: A user operating the Cult Walking pad Prime Treadmill with the remote control, demonstrating its hands-free functionality for adjusting speed and controlling the workout.

## LED Display

The integrated LED display provides real-time feedback on your workout progress:

- **Time:** Displays the duration of your current workout session.
- **Distance:** Shows the total distance walked during the session.
- **Speed:** Indicates your current walking speed in kilometers per hour.
- **Calories:** Provides an estimate of calories burned during your workout.

# Track Your Progress Instantly

LED display for real-time stats, remote for easy control

Time Distance Calories Speed



Hands-free Control



Image: A close-up view of the Cult Walking pad Prime Treadmill's LED display, clearly showing workout statistics such as time, distance, speed, and calories.

## Walking Guidelines

Always begin your walking session at a slow speed and gradually increase it to a comfortable pace. Maintain proper posture and a steady rhythm. Remember, this treadmill is intended for walking only.

## MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your treadmill.

### Lubrication

The walking belt requires periodic lubrication to reduce friction and ensure smooth operation. Refer to the instructions provided with the lubrication oil for recommended frequency and application method.

### Cleaning

After each use, wipe down the treadmill's surfaces with a slightly damp cloth to remove sweat and dust. Avoid using abrasive cleaners or solvents, as these can damage the finish.

### Storage

The treadmill's compact and foldable design allows for easy storage. Fold the unit and store it in a dry, safe location, such as under a bed or desk, away from direct sunlight and moisture.

# Room to Move with Confidence

Spacious, slip-resistant surface for safer, smoother workouts



Image: The Cult Walking pad Prime Treadmill folded flat and stored discreetly under a sofa, demonstrating its space-saving design and ease of storage.

## TROUBLESHOOTING

If you encounter any issues with your treadmill, refer to the following common solutions:

- **Treadmill not powering on:** Ensure the power cord is securely connected to both the treadmill and a functional, grounded electrical outlet. Verify that the 1000 VA stabilizer is correctly connected and operational.
- **Walking belt slipping or uneven:** The walking belt may require adjustment or lubrication. Consult the user manual or warranty card for specific instructions on belt adjustment and refer to the lubrication section for maintenance.
- **Remote control not responding:** Check the batteries in the remote control and replace them if necessary. Ensure there are no obstructions between the remote and the treadmill's receiver.

For persistent issues not resolved by these steps, please contact customer support.

## SPECIFICATIONS

Feature	Detail
Brand	CULT
Model Name	Cultwalkpadprime
Motor Peak Power	3.5 HP
Motor Continuous Power	1.75 HP
Maximum Weight Capacity	100 kg
Speed Range	1 - 10 km/h

Walking Belt Dimensions	360 x 950 mm
Product Dimensions	110D x 52.5W x 94H Centimeters
Item Weight	15 Kilograms
Material	Alloy Steel
Power Source	Corded Electric
Metrics Measured	Distance, Speed
Country of Origin	China

## WARRANTY AND SUPPORT

The Cult Walking pad Prime Treadmill is covered by a **2-year warranty** against manufacturing defects and electronic parts.

**Important Warranty Condition:** The warranty is valid only if the treadmill is used with a stabilizer (1000 VA recommended) to ensure proper voltage regulation.

For warranty claims, technical support, or any other assistance, please contact the manufacturer directly:

**CULTSPORT PRIVATE LIMITED**

*No 17 & 17C BDA, 3rd Sector, HSR Layout,  
Bangalore, Karnataka, India - 560102*