

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CREATE](#) /

› [CREATE STUDIO CRYSTAL 4.2L Oil-Free Air Fryer Instruction Manual](#)

CREATE STUDIO CRYSTAL 4.2L

CREATE STUDIO CRYSTAL 4.2L Oil-Free Air Fryer Instruction Manual

Model: STUDIO CRYSTAL 4.2L

1. INTRODUCTION

Thank you for choosing the CREATE STUDIO CRYSTAL 4.2L Oil-Free Air Fryer. This appliance is designed to cook a variety of foods using hot air circulation, offering a healthier alternative to traditional deep frying. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your air fryer. Please read it thoroughly before first use and retain it for future reference.

Key features of your CREATE STUDIO CRYSTAL Air Fryer include:

- **4.2 Liters Capacity:** Ideal for 5-6 servings.
- **1300W Power:** Ensures efficient and fast cooking.
- **Glass Basket:** Allows visual monitoring of food during cooking and is Teflon-free for enhanced safety and durability.
- **6 Pre-set Programs:** For convenient cooking of various dishes.
- **Adjustable Time and Temperature:** For customized cooking control.

2. SAFETY INSTRUCTIONS

To prevent personal injury or damage to the appliance, always follow these basic safety precautions:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse the cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.

- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use the appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from walls or other appliances to allow adequate ventilation.
- The glass basket is designed to withstand high temperatures and is free from Teflon, reducing the risk of toxic vapor release.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your CREATE STUDIO CRYSTAL Air Fryer:



Figure 1: Front view of the CREATE STUDIO CRYSTAL Air Fryer, showcasing its compact design and the visible glass cooking basket.



Figure 2: The air fryer with the glass basket and metal rack removed, illustrating the internal components and the ease of access for cleaning.

Components:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Digital display with touch controls for power, temperature, time, and pre-set programs.
- **Glass Cooking Basket:** The primary cooking container, made of durable, transparent glass.

- **Removable Cooking Rack:** Sits inside the glass basket to elevate food for optimal air circulation.
- **Handle:** For safely pulling out and inserting the glass basket.



Figure 3: A user demonstrating the removal of the glass cooking basket and metal rack from the air fryer, highlighting the Teflon-free design.

4. SETUP AND FIRST USE

Before using your air fryer for the first time, follow these steps:

1. **Unpack:** Remove all packaging materials, stickers, and labels from the appliance.
2. **Clean Components:** Wash the glass cooking basket and the removable cooking rack with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely. The glass basket is dishwasher safe.
3. **Wipe Main Unit:** Wipe the inside and outside of the main unit with a damp cloth.
4. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space around the back and sides of the appliance to allow for proper air circulation.
5. **Initial Run (Optional):** For the first use, it is recommended to run the air fryer empty for about 10 minutes at 180°C (350°F) to eliminate any manufacturing odors. A slight smell or smoke may occur, which is normal and will dissipate.

5. OPERATING INSTRUCTIONS

Control Panel Overview



Figure 4: Close-up view of the digital control panel with touch buttons for various functions and pre-set programs.

- **Power Button:** Turns the appliance on/off and starts/pauses cooking.
- **Temperature Control (Up/Down Arrows):** Adjusts the cooking temperature.
- **Time Control (Up/Down Arrows):** Adjusts the cooking time.
- **Pre-set Program Icons:** Selects one of the 6 automatic cooking programs.

General Operation Steps

1. **Prepare Food:** Place your ingredients in the glass cooking basket, ensuring not to overfill. For best results, food should be in a single layer or shaken periodically.
2. **Insert Basket:** Slide the glass basket with the cooking rack firmly into the main unit.
3. **Power On:** Plug the power cord into a grounded wall outlet. The power button will illuminate. Press the power button to turn on the display.
4. **Select Cooking Method:**
 - **Pre-set Program:** Press the desired pre-set program icon. The display will show the default time and temperature for that program.
 - **Manual Setting:** Use the temperature and time control arrows to set your desired cooking temperature and time.
5. **Start Cooking:** Press the power button again to start the cooking process. The fan and heating element will activate.
6. **Monitor Food:** The transparent glass basket allows you to visually monitor the cooking progress without opening the fryer, preventing heat loss.
7. **Shake/Turn Food:** For even cooking, especially with items like fries or nuggets, the air fryer may beep halfway through the cooking cycle to remind you to shake or turn the food. Carefully pull out the basket, shake or turn the food, and reinsert the basket. The cooking will resume automatically.
8. **End of Cooking:** Once the set time has elapsed, the air fryer will beep and automatically shut off.
9. **Remove Food:** Carefully pull out the glass basket using the handle. Use heat-resistant tongs to remove the cooked food.
10. **Cool Down:** Allow the appliance to cool down completely before cleaning or storing.



Figure 5: The air fryer in operation, with food visible inside the glass basket, demonstrating the transparent design feature.

Cooking Tips

- **Preheating:** For best results, preheat the air fryer for 3-5 minutes at the desired temperature before adding food.
- **Oil Application:** While an oil-free fryer, a small amount of oil (1 tablespoon) can be tossed with some foods (e.g., fresh potatoes) to enhance crispiness.

- **Do Not Overfill:** Avoid overcrowding the basket to ensure proper air circulation and even cooking. Cook in batches if necessary.
- **Shake or Turn:** Regularly shake or turn smaller items (like fries, nuggets) and flip larger items (like chicken breasts) for uniform browning.
- **Adjust Times:** Cooking times may vary based on food type, quantity, and desired crispiness. Adjust as needed.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool down completely before cleaning.
2. **Clean Glass Basket and Rack:** The glass cooking basket and removable cooking rack are dishwasher safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak in warm soapy water before cleaning.
3. **Clean Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water or any other liquid.
4. **Clean Heating Element:** Use a soft brush to remove any food residue from the heating element inside the appliance.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

7. TROUBLESHOOTING

If you encounter any issues with your air fryer, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Power outlet is not working.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Food is not cooked evenly.	Basket is overcrowded. Food was not shaken/turned.	Cook food in smaller batches. Shake or turn food halfway through cooking.
Food is not crispy.	Not enough oil (for certain foods). Temperature too low or time too short.	Lightly brush or spray food with oil. Increase temperature or cooking time. Ensure food is not overcrowded.
White smoke coming from the appliance.	Grease residue from previous use. Fatty ingredients being cooked.	Clean the basket and heating element thoroughly after each use. For fatty foods, absorb excess oil with a paper towel.

If the problem persists after checking these solutions, please contact CREATE customer support.

8. SPECIFICATIONS

Feature	Detail

Feature	Detail
Brand	CREATE
Model	STUDIO CRYSTAL 4.2L
Capacity	4.2 Liters
Power	1300 Watts
Voltage	240 Volts
Material	ABS + Glass
Dimensions (L x W x H)	26.1 x 24.8 x 27.3 cm
Weight	5.8 kg
Special Feature	Programmable, Glass Basket
Control Method	Touch

9. WARRANTY AND SUPPORT

Your CREATE STUDIO CRYSTAL Air Fryer is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, spare parts, or any inquiries regarding your product, please contact CREATE customer service.

You can find more information and support on the official CREATE store page:[CREATE Official Store](#)