

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Soozier](#) /
- › [Soozier Walking Pad 2.5HP Under Desk Treadmill User Manual](#)

Soozier USA90-389V80ND0131

Soozier Walking Pad 2.5HP Under Desk Treadmill User Manual

Model: USA90-389V80ND0131

1. INTRODUCTION

Thank you for choosing the Soozier Walking Pad 2.5HP Under Desk Treadmill. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new walking pad. Please read this manual thoroughly before initial use and retain it for future reference.



Image: Soozier Walking Pad in use under a standing desk.

2. SAFETY INFORMATION

To ensure safe operation, please observe the following precautions:

- Always place the walking pad on a flat, stable surface.
- Ensure adequate clear space around the walking pad (at least 2 feet on all sides).
- Do not exceed the maximum weight capacity of 264 lbs (120 kg).
- Keep children and pets away from the walking pad during operation.
- Wear appropriate athletic footwear.
- If you feel dizzy, nauseous, or experience any pain, stop exercising immediately.
- Unplug the walking pad from the power outlet when not in use or before cleaning/maintenance.
- Do not use the walking pad if the power cord or plug is damaged.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- Soozier Walking Pad Treadmill
- Remote Control
- User Manual (this document)



Image: Illustration of the product packaging.

4. SETUP

The Soozier Walking Pad is designed for immediate use with no assembly required.

1. **Unpacking:** Carefully remove the walking pad from its packaging.
2. **Placement:** Place the walking pad on a firm, level surface. Ensure there is sufficient space around the unit for safe operation.
3. **Power Connection:** Plug the power cord into a standard grounded electrical outlet.
4. **Initial Check:** Before stepping on, ensure the walking belt is centered and moves freely.



Image: Soozier Walking Pad positioned on a floor in a room.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- To power on, ensure the walking pad is plugged in and press the power button on the unit or the remote control. The LED display will illuminate.
- To power off, press the power button again.

5.2 Using the Remote Control

The remote control allows you to adjust speed and start/stop the walking pad without interrupting your exercise.

- **Start/Stop Button:** Press to start or pause the walking pad.
- **Speed Up (+):** Press to increase the walking speed.
- **Speed Down (-):** Press to decrease the walking speed.
- **Mode (M):** Press to cycle through display modes (if applicable).

LED DISPLAY & REMOTE CONTROL

Track your motion data in real time



Image: LED display showing workout data and the remote control.

5.3 LED Display

The integrated LED display shows real-time workout data:

- **Time:** Duration of your workout.
- **Distance:** Total distance walked.
- **Speed:** Current walking speed (0.6 to 3.7 mph).
- **Calories:** Estimated calories burned.

5.4 Walking Belt Features

The walking pad features a 5-layer anti-slip running belt for comfort and safety.

SPACIOUS & ANTI-SLIP RUNNING BELT



+ 10% running area more



5 shock-absorbing layers reduce joint impact



Image: Demonstrating the spacious and anti-slip running belt.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your walking pad.

6.1 Cleaning

- Always unplug the walking pad before cleaning.
- Wipe down the unit with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- Keep the area under the walking pad clean and free of dust and debris.

6.2 Belt Adjustment and Lubrication

The walking belt may require occasional adjustment or lubrication to maintain smooth operation. Refer to the specific instructions provided with your walking pad for detailed steps on belt centering and lubrication, typically performed every few months depending on usage.

7. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---------------------------------|---|--|
| Walking pad does not power on. | Power cord not plugged in; power switch off; circuit breaker tripped. | Check power connection; ensure power switch is on; reset circuit breaker. |
| Walking belt stops or slips. | Belt too loose; insufficient lubrication; motor overload. | Adjust belt tension; apply lubricant; reduce user weight or speed. |
| Remote control not working. | Batteries dead; remote out of range; interference. | Replace batteries; ensure remote is pointed at the display; remove obstructions. |
| Unusual noise during operation. | Loose components; belt friction; motor issue. | Inspect for loose parts; lubricate belt; contact customer support if noise persists. |

8. SPECIFICATIONS

Detailed technical specifications for the Soozier Walking Pad:

- **Model Name:** Walking Treadmill
- **Model Number:** USA90-389V80ND0131
- **Motor Horsepower:** 2.5 HP
- **Speed Range:** 0.6 - 3.7 Miles per Hour
- **Weight Capacity:** 264 lbs (120 kg)
- **Running Area (L x W):** 39.4" x 15.7"
- **Overall Dimensions (L x W x H):** 47.2" x 20.9" x 5"
- **Item Weight:** 40 Pounds
- **Material:** ABS, Alloy Steel
- **Display Type:** LED
- **Power Source:** Corded Electric
- **Special Features:** Compact Design, Shock Absorbent, Timer, Wheeled



Image: Product dimensions diagram.

9. WARRANTY AND SUPPORT

The Soozier Walking Pad comes with a **1-Year Warranty Against Manufacturer Defects**.

For warranty claims, technical support, or any questions not covered in this manual, please contact Soozier customer service. Keep your purchase receipt as proof of purchase for warranty validation.