

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OQIMAX](#) /

› [OQIMAX Kids Alarm Clock User Manual - Model WA175USKM](#)

OQIMAX WA175USKM

OQIMAX Kids Alarm Clock User Manual - Model WA175USKM

Brand: OQIMAX

ABOUT YOUR OQIMAX KIDS ALARM CLOCK

This manual provides instructions for the OQIMAX Kids Alarm Clock, Model WA175USKM. This device is designed to assist children with sleep training, provide ambient lighting, and function as a dual alarm clock to promote healthy sleep habits.

KEY FEATURES

- **Sleep Training Clock:** Features a moon icon that lights up with a gentle red hue to signal bedtime. The night light automatically turns off after 1 hour. Default sleep time is 7 PM to 11 PM.
- **Colorful Ambient Light & Music:** Offers 11 vibrant light colors and 10 soothing music melodies, including lullabies, nature sounds, and white noise, to create a peaceful environment.
- **Wake-Up Feature & Dual Alarm:** A soft yellow light appears 20 minutes before the alarm, turning green when the alarm sounds for a pleasant wake-up. Set two independent alarms with four workday modes and a 5-minute snooze function.
- **Easy Control & Child Lock:** Adjust sound and light with simple button presses. Tap the clock to change light colors. Activate child lock by holding both "TUNES" buttons for 3 seconds to prevent accidental setting changes.
- **Plug-in Operation:** This Type-C plug-in alarm clock must be continuously plugged in for operation and features a power-off memory function. (Note: Power adapter is not included).

SETUP

Power Connection

Connect the provided Type-C USB cable to the clock's power port and a compatible USB power adapter (not included). The clock requires continuous power to operate. The power-off memory function retains settings during power interruptions.

Setting Time

1. Press and hold the **TIME SET** button for 3 seconds to enter time setting mode. The hour digits will flash.
2. Use the **UP** (+) or **DOWN** (-) buttons to adjust the hour.

3. Press **TIME SET** again to confirm the hour and move to minute setting. The minute digits will flash.
4. Use the **UP** (+) or **DOWN** (-) buttons to adjust the minutes.
5. Press **TIME SET** a third time to confirm minutes and exit time setting mode.
6. To switch between 12-hour and 24-hour format, press the **DISPLAY** button during normal time display.



Figure 1: Front view of the OQIMAX Kids Alarm Clock with display and control buttons.

OPERATING INSTRUCTIONS

Sleep Training Function

The sleep training function helps children understand when it's time for bed and when it's okay to wake up. The moon icon and red light indicate bedtime, while the sun icon and green light indicate wake-up time.

1. **Bedtime:** The moon icon lights up, and the clock glows red. This signals it's time to sleep. The red night light will automatically turn off after 1 hour. The default bedtime period is 7 PM to 11 PM.
2. **Wake-Up:** 20 minutes before the set alarm time, a soft yellow light will appear. When the alarm rings, the light turns green, indicating it's time to wake up.
3. To activate/deactivate the sun/moon icon display, short press the **SUN/MOON ON/OFF** button.
4. To set the appearance time of the moon icon (bedtime), long press the **SUN/MOON ON/OFF** button.


BEDTIME

Red light tells your child it is time for bed



SOON

Yellow light turn on 20 minutes before the alarm ring



WAKE UP

Green light tell your child it is time to wake up



Figure 2: Alarm clock displaying red light for bedtime.

6.3in/160mm

4.1in/105mm

ALARM CLOCK
A great helper for
waking up and
sleeping

NIGHT LIGHT
11 Colors & 4 levels
Brightness

**MUSIC & WHITE
NOISE**
12 wake up sounds
& 4 levels volume

CHILD LOCK
Prevent settings from
being changed

Figure 3: Alarm clock displaying yellow light 20 minutes before wake-up.

Color Change Soft Night Light

7 solid colors + 4 dynamic colors & 4 brightness



Press the top of the alarm clock to switch the night light color.



Figure 4: Alarm clock displaying green light for wake-up.

Setting Dual Alarms

The clock supports two independent alarms (Alarm 1 and Alarm 2) with customizable schedules.

1. Press the **ALARM 1** or **ALARM 2** button (located on the bottom of the clock) to select the alarm you wish to set.
2. Use the **UP** (+) or **DOWN** (-) buttons to adjust the hour and minutes.
3. Press the **ALARM** button again to select the workday mode:
 - **1-1:** Single day alarm
 - **1-5:** Monday to Friday
 - **1-7:** Monday to Sunday

- 6-7: Saturday and Sunday

4. Press the **ALARM** button a final time to confirm and activate the alarm.

Snooze Function

When an alarm sounds, press the top of the alarm clock to activate the 5-minute snooze function.



Enjoy Tunes



Help Sleep

Best Gifts for everybody



Night Light



Wake UP

Figure 5: Illustration of dual alarm settings and snooze function.

Night Light & Color Adjustment

The clock features 11 vibrant light colors and multiple brightness levels for both the display and the nightlight.

1. To change the night light color, press the top of the alarm clock.
2. To adjust the brightness of the night light, use the **UP** (+) or **DOWN** (-) buttons (located on the bottom of the

clock) when the night light is active.

3. To adjust the display brightness, short press the **DISPLAY** button.




Figure 6: Examples of the 11 available night light colors.

Sound Machine & Volume Control

Choose from 10 soothing melodies, nature sounds, or white noise to create a peaceful atmosphere.

1. To select a melody or sound, short press the **TUNES** button.
2. To adjust the volume, use the **UP** (+) or **DOWN** (-) buttons (located on the bottom of the clock) when a sound is playing.

Child Lock

The child lock prevents accidental changes to the clock's settings while still allowing access to music and light

functions.

1. To activate the child lock, press and hold both **TUNES** buttons for 3 seconds. A lock icon will appear on the display.
2. To deactivate the child lock, press and hold both **TUNES** buttons for 3 seconds again. The lock icon will disappear.

Best Gifts for Family & kids



Figure 7: Overview of control buttons and their functions.

Official Product Video

Video 1: An official product video demonstrating the OQIMAX Kids Alarm Clock's features, including its 11-color night light and wake-up functions. This video provides a visual guide to the clock's operation and design.

MAINTENANCE

To clean your OQIMAX Kids Alarm Clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish. Keep the device away from water and extreme temperatures to ensure its longevity.

TROUBLESHOOTING

- **Clock not powering on:** Ensure the Type-C USB cable is securely connected to the clock and a working USB power adapter.
- **Alarm not sounding:** Verify that the alarm is activated for the desired time and day mode. Check that the alarm volume is not set to its lowest level.
- **Settings changing unexpectedly:** Activate the child lock function by holding both "TUNES" buttons for 3 seconds to prevent accidental adjustments by children.
- **Night light not changing colors/brightness:** Ensure the child lock is not preventing these adjustments, or try deactivating and reactivating the night light.

PRODUCT SPECIFICATIONS

- **Brand:** OQIMAX
- **Model:** WA175USKM
- **Package Dimensions:** 6.65 x 5.04 x 2.52 inches
- **Item Weight:** 0.23 Kilograms (8.15 ounces)
- **Power Source:** Type-C USB (adapter not included)
- **Night Light Colors:** 11
- **Ringtones/Melodies:** 10
- **Style:** Contemporary
- **Shape:** Irregular (Cat-shaped)

WARRANTY AND SUPPORT

For detailed warranty information or technical support regarding your OQIMAX Kids Alarm Clock, please refer to the manufacturer's official website or contact their customer service department directly. Contact details may be found on the product packaging or the brand's online store.