

## KitchenAid KHBRV75

# KitchenAid Go Cordless Hand Blender User Manual

**MODEL: KHBRV75**

Porcelain White

## Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the hand blender.
- Do not immerse the motor body, battery, or charger in water or other liquid.
- Keep hands, hair, and clothing, as well as spatulas and other utensils, away from moving blades during operation to prevent injury and/or damage to the hand blender.
- Always unplug the charger from the outlet before cleaning or when not in use.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use outdoors.

## Product Overview and Package Contents

The KitchenAid Go Cordless Hand Blender system provides versatility for various kitchen tasks. Familiarize yourself with the components included in your package.



Image: Overview of the KitchenAid Go Cordless Hand Blender system, displaying the main blender unit, blending arm, whisk attachment, chopper attachment, 4-cup BPA-free pitcher with lid, removable battery, USB-C cable, and wall adapter.

### Package Contents:

- 1 Cordless Hand Blender Motor Body
- 1 Removable 7-inch Blending Arm with 4-point stainless steel blade
- 1 Whisk Attachment
- 1 Chopper Attachment
- 1 4-cup BPA-free Pitcher with Lid
- 1 Removable 12V MAX Battery
- 1 USB-C Cable
- 1 Wall Adapter
- 1 Removable Pan Attachment (for blending arm)

# One battery. No limits.

Single battery powers 8+ kitchen tools and counting



\*Battery sold separately on select models

Image: Labeled diagram showing the main components: 1. Removable battery, 2. 7-inch blending arm, 3. BPA-free pitcher with lid, 4. Chopper attachment, 5. Whisk attachment.

## Assembly

Follow these steps to assemble your KitchenAid Go Cordless Hand Blender:

1. **Attach the Blending Arm:** Align the blending arm with the motor body and twist clockwise until it locks securely into place.
2. **Attach the Whisk:** Insert the whisk into the adapter, then align the adapter with the motor body and twist clockwise until it locks.
3. **Attach the Chopper:** Place the chopper blade onto the center post inside the chopper bowl. Place the chopper lid onto the bowl, then align the motor body with the lid and twist clockwise until it locks.
4. **Insert the Battery:** Slide the charged battery into the base of the motor body until it clicks into place.

## Charging the Battery

The KitchenAid Go Cordless Hand Blender is powered by a rechargeable 12V MAX battery. Ensure the battery is fully charged before first use and whenever the power indicator lights are low.

1. Remove the battery from the hand blender by pressing the release buttons on the sides and sliding it

out.

2. Connect the USB-C cable to the charging port on the battery.
3. Plug the USB-C cable into the provided wall adapter, then plug the adapter into a standard electrical outlet.
4. The battery indicator lights will illuminate to show charging progress. All lights will be solid when fully charged.
5. Once fully charged, disconnect the charger and reinsert the battery into the hand blender.



Image: Close-up of the removable 12V MAX battery, highlighting its compact design and indicating its role in powering the cordless system.

## Operating Instructions

### Using the Blending Arm:

The blending arm is ideal for smoothies, shakes, soups, and sauces.

1. Ensure the blending arm is securely attached to the motor body and the battery is inserted.
2. Place the blending arm into the ingredients in the 4-cup pitcher or a suitable deep container. Ensure the blade guard is fully submerged.
3. Press and hold the power button to begin blending. Move the blender up and down gently to process ingredients evenly.
4. Release the power button to stop.



Image: A KitchenAid Go Cordless Hand Blender being used to efficiently blend soup directly in a pot, demonstrating its versatility for various food preparations like smoothies, shakes, and sauces.

### Using the Whisk Attachment:

The whisk attachment is perfect for whipping egg whites, cream, or making vinaigrettes.

1. Attach the whisk to the motor body as described in the Assembly section.
2. Place the whisk into the ingredients in a bowl.
3. Press and hold the power button to start whisking. Move the whisk gently to incorporate air or mix

ingredients.

4. Release the power button to stop.



Image: Close-up of the whisk attachment, showing its design for whipping and aerating ingredients.

### Using the Chopper Attachment:

The chopper attachment is suitable for chopping herbs, nuts, cheeses, and more.

1. Assemble the chopper attachment with the blade and lid, then attach the motor body as described in the Assembly section.
2. Place desired ingredients into the chopper bowl. Do not overfill.
3. Press and hold the power button in short pulses to chop ingredients to your desired consistency.
4. Release the power button to stop.





Image: The chopper attachment displayed with examples of ingredients it can process, such as herbs, cheeses, and nuts.

## Care and Cleaning

Proper cleaning ensures the longevity and performance of your hand blender.

1. **Before Cleaning:** Always remove the battery from the motor body before cleaning any part of the appliance.
2. **Motor Body:** Wipe the motor body with a damp cloth. Do not immerse in water or other liquids.
3. **Blending Arm, Whisk, Chopper Blade, Pitcher, Chopper Bowl/Lid:** These parts are top-rack dishwasher safe. Alternatively, wash in warm, soapy water, then rinse thoroughly and dry.
4. **Battery and Charger:** Wipe with a clean, dry cloth. Do not immerse in water.
5. **Storage:** Store the hand blender and its accessories in a clean, dry place.

## Troubleshooting

If you encounter issues with your KitchenAid Go Cordless Hand Blender, refer to the following table for common problems and solutions.

| Problem  | Possible Cause  | Solution   |
|--|---|--|
| Hand blender does not turn on.                     | Battery is not charged or not properly inserted.  | Ensure the battery is fully charged and securely clicked into the motor body. Check battery indicator lights.  |
| Appliance stops during operation.                  | Battery charge is low or appliance is overloaded.                                       | Recharge the battery. Reduce the amount of ingredients or cut them into smaller pieces. Allow the motor to cool if it feels warm.                                  |
| Ingredients are not blending/chopping effectively. | Too many ingredients, ingredients are too large, or attachment is not properly secured. | Reduce ingredient quantity. Cut ingredients into smaller, uniform pieces. Ensure the blending arm, whisk, or chopper attachment is correctly assembled and locked. |
| Loud noise or vibration during use.                | Attachment not properly secured or foreign object present.                              | Turn off and remove battery. Check that the attachment is securely locked. Inspect for any foreign objects obstructing the blades or whisk.                        |

## Specifications

| Feature | Detail |
|---------|--------|
|---------|--------|



