

TOPUTURE TP6

TOPUTURE TP6 Walking Pad Treadmill with 12% Incline - User Manual

1. INTRODUCTION AND SAFETY INFORMATION

This manual provides essential instructions for the safe operation, setup, and maintenance of your TOPUTURE TP6 Walking Pad Treadmill. Please read this manual thoroughly before initial use and retain it for future reference. Proper use and maintenance ensure optimal performance and longevity of your equipment.

Important Safety Precautions

- Always consult with a physician before starting any new exercise program.
- Place the treadmill on a flat, stable surface with adequate clearance around it.
- Keep children and pets away from the treadmill during operation.
- Ensure the safety key is properly attached to your clothing before beginning your workout.
- Do not operate the treadmill if it is damaged or malfunctioning.
- Maximum user weight capacity is 300 lbs. Do not exceed this limit.
- Wear appropriate athletic footwear during use.
- Unplug the treadmill from the power source when not in use or before cleaning/maintenance.

2. INCLUDED COMPONENTS

Upon unpacking, verify that all the following components are present:

- Power Cord
- Remote Control
- Safety Key
- Tool Kit
- User Manual (this document)

3. SETUP AND ASSEMBLY

The TOPUTURE TP6 Walking Pad Treadmill features an installation-free design, meaning it is ready for use directly out of the box with minimal setup.

Unpacking and Placement

1. Carefully remove the treadmill from its packaging.
2. Place the treadmill on a firm, level surface. Ensure there is at least 2 feet of clear space behind the treadmill and 1 foot on each side.
3. Connect the power cord to the treadmill and then to a grounded electrical outlet.

Adjusting the Handlebar

The handlebar is adjustable in both height and tilt to accommodate various user heights and exercise preferences.

- **Height Adjustment:** The handlebar can be adjusted from 32 inches (820mm) to 45 inches (1150mm). Locate the adjustment knobs or levers on the handlebar supports, loosen them, adjust to the desired height, and then securely tighten.
- **Tilt Adjustment:** The handlebar can be tilted to 95° (vertical mode) or 105° (tilt mode). Adjust the angle by manipulating the designated mechanism at the base of the handlebar uprights. Ensure it clicks securely into place for your chosen mode.

Adjustable Height Handlebar

Comfortable for the Whole Family



Image: Adjustable Handlebar Height. The handlebar can be set to various heights between 32 and 45 inches for user comfort.

Two-angle Upright Column Adjustment



Image: Two-angle Upright Column Adjustment. The handlebar can be adjusted to a 95-degree vertical mode or a 105-degree tilt mode to suit different exercise preferences.

4. OPERATING INSTRUCTIONS

The TOPUTURE TP6 Treadmill offers multiple modes and features for a versatile workout experience.

Powering On and Safety Key

1. Ensure the treadmill is plugged into a power outlet.
2. Attach the safety key clip to your clothing. The treadmill will not operate without the safety key in place.
3. Press the power button on the treadmill or remote control to turn it on.

Understanding the LED Display

The integrated LED display provides real-time workout data:

- **Time:** Duration of your workout.
- **Calories:** Estimated calories burned.
- **Speed:** Current speed in miles per hour (mph).
- **Distance:** Total distance covered.

2.5HP Powerful & Quiet Motor



Low Noise
45db



Speed Range
0.6-7.5MPH



Motor Power
2.5HP



Weight Capacity
300 LBS



Image: Multi-Function Display. The LED display shows key workout metrics, and the remote control allows for easy adjustments.

Adjusting Speed and Incline

- **Speed Range:** The treadmill operates from 0.6 mph to 7.5 mph. Adjust speed using the remote control or the control panel.
- **Incline Function:** The treadmill features 1%, 6%, and 12% incline levels. Adjust the incline manually or via the control panel/remote to simulate uphill walking or running, enhancing calorie expenditure.

1%-6%-12% Three Levels of Slope Adjustment for Better Calorie Burning

200Kcal/H 🔥

300Kcal/H 🔥

650Kcal/H 🔥

1% Incline

6% Incline

12% Incline



Image: 1%-6%-12% Three Levels of Slope Adjustment. The treadmill offers adjustable incline levels to increase workout intensity and calorie burning.

Workout Modes

The TOPUTURE TP6 supports various exercise scenarios:

- **Walking Mode:** Ideal for light exercise or under-desk use.
- **Fat-Burning Mode:** Optimized for calorie expenditure.
- **Running Mode:** For higher intensity cardiovascular workouts.
- **Working Mode:** Suitable for use with a standing desk.
- **Family Sharing Mode:** Allows multiple users to track their progress.

- **Training Mode:** For structured workout routines.



Image: 6-in-1 Folding Treadmill with Incline. The treadmill supports various modes including walking, fat burning, office work, pet training, running, and rehabilitation.

Smart App Integration

Enhance your workout experience by connecting the treadmill to a compatible fitness application.

1. Download the recommended Sport APP or other compatible apps like Fitshow, Zwift, or Kinomap from your device's app store.
2. Enable Bluetooth on your smartphone or tablet.

3. Open the app and follow the on-screen instructions to pair with your TOPUTURE TP6 treadmill.
4. The app allows you to record exercise data, track progress, and share with friends. The integrated device holder securely holds your phone or tablet.

Smart and Personalized Workout App Control



Image: Smart and Personalized Workout App Control. Connect to fitness apps like Fitshow, Zwift, or Kinomap to track and personalize your workouts.

5. MAINTENANCE AND STORAGE

Regular maintenance ensures the longevity and safe operation of your treadmill.

Cleaning

- Always unplug the treadmill before cleaning.
- Wipe down the treadmill surface with a damp cloth. Avoid using abrasive cleaners or solvents.
- Periodically clean the running belt and deck to prevent dust and debris buildup.

Lubrication

The running belt may require periodic lubrication to reduce friction and extend its lifespan. Refer to the specific instructions in the included tool kit or contact customer support for guidance on proper lubrication procedures and recommended lubricants.

Storage

The TOPUTURE TP6 treadmill is designed for easy storage due to its compact and foldable nature.

- Fold the handlebar down completely.
- Utilize the integrated wheels for easy movement.
- Store the treadmill in a dry, cool place, such as under a bed or sofa, to save space.

6-IN-1 Folding Treadmill with Incline



Walking Mode



Fat Burning Mode



Office Mode



Pet Training



Running Mode



Rehabilitation Mode



Image: Easy Storage & Space Saving. The treadmill is lightweight and features flexible wheels for convenient movement and compact storage.

6. TROUBLESHOOTING

If you encounter any issues with your TOPUTURE TP6 Treadmill, please refer to the following common solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Treadmill does not power on.	Power cord not securely plugged in; Safety key not in place; Power switch off.	Check power cord connection; Ensure safety key is properly inserted; Turn on the power switch.
Running belt slips or hesitates.	Belt tension too loose; Belt requires lubrication.	Adjust belt tension according to manual; Lubricate the running belt as instructed.
Unusual noise during operation.	Loose components; Foreign object under the belt; Motor issue.	Inspect for loose parts and tighten; Carefully check under the belt for obstructions; If noise persists, contact support.
Remote control not responding.	Dead batteries; Remote not paired.	Replace remote control batteries; Refer to pairing instructions in the manual.

7. PRODUCT SPECIFICATIONS

Technical details for the TOPUTURE TP6 Walking Pad Treadmill:

Specification	Detail
Brand	TOPUTURE
Model Name	TP6
Color	Black
Product Dimensions (LxWxH)	50"D x 25"W x 5"H (127cm x 63.5cm x 12.7cm)
Item Weight	56 Pounds (25.4 kg)
Material	Alloy Steel
Maximum Speed	7.5 Miles per Hour (12 km/h)
Minimum Speed	0.6 Miles per Hour (1 km/h)
Maximum Incline Percentage	12%
Maximum Horsepower	2.5 HP
Maximum Weight Recommendation	300 Pounds (136 kg)
Running Area	40" x 16" (101.6cm x 40.6cm)
Display Type	LED
Power Source	Corded Electric

Specification	Detail
Assembly Required	No
Special Features	Adjustable Height, Compact Design, Foldable, Shock Absorbent, Wheeled
Metrics Measured	Calories Burned, Distance, Speed, Time

Easy Storage & Space Saving



Image: 2.5HP Powerful & Quiet Motor. The treadmill features a 2.5HP motor, operates quietly at 45db, has a speed range of 0.6-7.5 MPH, and supports up to 300 LBS.

8. WARRANTY AND CUSTOMER SUPPORT

Warranty Information

The TOPUTURE TP6 Walking Pad Treadmill comes with a **one-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product meets quality standards under normal use.

Contacting Customer Support

Should you require assistance, have questions, or need to claim warranty service, please follow these steps:

1. Log in to your Amazon account.
2. Navigate to "Your Orders."
3. Locate the order ID for your TOPUTURE TP6 Treadmill.
4. Click on "Contact Seller" to reach TOPUTURE customer support directly.

Please have your order details and a description of the issue ready to expedite the support process.

© 2025 TOPUTURE. All rights reserved.

Related Documents - TP6

 The image shows the cover of the user manual for the Toputure TP3 Incline Walking Pad. It features the Toputure logo at the top, a line drawing of the walking pad, and a yellow banner at the bottom with the text "USER MANUAL (Model TP3) INCLINE WALKING PAD".	<p>Toputure TP3 Incline Walking Pad User Manual</p> <p>User manual for the Toputure TP3 Incline Walking Pad, covering installation, usage, maintenance, and troubleshooting.</p>
 The image shows the cover of the user manual for the Toputure TP1 Folding Treadmill. It features the Toputure logo at the top, a line drawing of the treadmill, and a yellow banner at the bottom with the text "USER MANUAL (Model TP1) FOLDING TREADMILL".	<p>Toputure TP1 Folding Treadmill User Manual</p> <p>Comprehensive user manual for the Toputure TP1 Folding Treadmill, covering installation, operation, safety, maintenance, and troubleshooting.</p>

 <p>The image shows the cover of the Toputure TP1 Folding Treadmill User Manual. It features a line drawing of the treadmill and a yellow banner at the bottom with the text 'USER MANUAL Model TP1 FOLDING TREADMILL'.</p>	<p>Toputure TP1 Folding Treadmill User Manual Comprehensive user manual for the Toputure TP1 Folding Treadmill, covering installation, operation, maintenance, and troubleshooting.</p>
 <p>The image shows the cover of the Toputure TP2 Home Treadmill User Manual. It features a list of contents in Chinese and a yellow banner at the bottom with the text 'USER MANUAL'.</p>	<p>Toputure TP2 Home Treadmill User Manual User manual for the Toputure TP2 Home Treadmill, covering installation, operation, maintenance, and safety guidelines.</p>
 <p>The image shows the cover of the Toputure Exercise Bike TEB1 User Manual. It features a line drawing of the exercise bike and a yellow banner at the bottom with the text 'USER MANUAL Exercise Bike Model TEB1'.</p>	<p>Toputure Exercise Bike TEB1 User Manual User manual for the Toputure Exercise Bike, Model TEB1, covering installation, product instructions, LCD indicator functions, app connection, maintenance, troubleshooting, and warranty information.</p>
 <p>The image shows the cover of the Toputure TEB1 Exercise Bike User Manual. It features a line drawing of the exercise bike and a yellow banner at the bottom with the text 'USER MANUAL Exercise Bike Model TEB1'.</p>	<p>Toputure TEB1 Exercise Bike User Manual Comprehensive user manual for the Toputure TEB1 Exercise Bike, covering safety precautions, parts identification, assembly instructions, product usage, and electronic display features.</p>