

Melchioni Family Marianna New 118340045

Melchioni Family Marianna New 5-Liter Air Fryer User Manual

Model: Marianna New 118340045

1. IMPORTANT SAFETY INSTRUCTIONS

Before using the Melchioni Family Marianna New Air Fryer, please read all instructions carefully and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is placed on a stable, heat-resistant surface.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children.
- Do not block any ventilation openings.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use accessories not recommended by the manufacturer.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not place the appliance against a wall or against other appliances. Leave at least 10 cm free space on the back and sides and 10 cm free space above the appliance.
- Do not place anything on top of the appliance.
- During hot air frying, hot steam is released through the air outlet openings. Keep your hands and face at a safe distance from the steam and from the air outlet openings.
- The surfaces may become hot during use.

2. PRODUCT OVERVIEW

The Melchioni Family Marianna New Air Fryer is designed for healthy cooking with minimal to no oil. It features a compact design, a 5-liter capacity, a transparent viewing window, and an intuitive touch display with 7 preset programs.

MARIANNA NEW

Friggitrice ad aria



Caratteristiche



Capacità
5 litri



Temperatura
80°-200°C



Assorbimento
1500W



Timer
1-60min



Luce
interna



Display
touch

Image: Overview of the Melchioni Family Marianna New Air Fryer's key features, including 5-liter capacity, 80-200°C temperature range, 1500W power, 1-60 minute timer, internal light, and touch display.

Components:

- Main Unit with Touch Display
- Removable Non-Stick Basket
- Transparent Viewing Window
- Power Cord

3. SETUP

1. **Unpacking:** Carefully remove the air fryer and all packaging materials. Keep packaging for future storage or disposal.
2. **Initial Cleaning:** Before first use, clean the basket and any removable parts with warm soapy water. Wipe the

main unit with a damp cloth. Ensure all parts are completely dry before use.

3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm of clear space around the back, sides, and top of the appliance for proper ventilation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet (220-240V AC, 50Hz).



Image: The Melchioni Family Marianna New Air Fryer showing its compact dimensions: approximately 37 cm depth, 29.3 cm width, and 33.2 cm height. This illustrates the space required for placement.

4. OPERATING INSTRUCTIONS

4.1 Basic Operation

1. **Prepare Food:** Place your ingredients into the non-stick basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the basket firmly back into the air fryer until it clicks into place.
3. **Power On:** Plug in the appliance. The display will illuminate.
4. **Select Program or Manual Settings:**

- **Preset Programs:** Use the touch display to select one of the 7 preset cooking programs (e.g., Pizza, Fish, Bread, Biscuits, Chicken, Steak, Potatoes). Each program has a default time and temperature.
 - **Manual Settings:** Alternatively, manually set the desired temperature (80-200°C) and cooking time (1-60 minutes) using the touch controls.
5. **Start Cooking:** Press the start button to begin the cooking process.
 6. **Monitor Cooking:** Use the transparent viewing window to monitor the cooking progress without opening the basket, which helps maintain consistent internal temperature.
 7. **Shake/Flip (Optional):** For some foods, it may be necessary to shake or flip the ingredients halfway through cooking. Pull out the basket, shake/flip, and reinsert. The air fryer will resume cooking automatically.
 8. **End of Cooking:** The air fryer will beep when the cooking time is complete. Carefully pull out the basket and transfer the cooked food to a serving dish.
 9. **Power Off:** Unplug the appliance after use.



7 programmi di cottura



Pizza



Pesce



Pane



Biscotti



Pollo



Bistecca



Patate

Image: The Melchioni Family Marianna New Air Fryer displaying its 7 preset cooking programs: Pizza, Fish, Bread, Biscuits, Chicken, Steak, and Potatoes, simplifying meal preparation.

4.2 Tips for Best Results

- For crispy results, lightly brush or spray food with oil.
- Smaller food items usually require shorter cooking times.
- Preheating the air fryer for 3-5 minutes can improve cooking results for some dishes.
- Do not cook extremely greasy foods in the air fryer.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Clean Basket:** The non-stick basket can be washed with warm soapy water and a non-abrasive sponge. For stubborn food residue, soak the basket in warm water for about 10 minutes before cleaning. The non-stick coating makes cleaning easy.
3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. Do not use abrasive cleaners or scouring pads.
4. **Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth.
5. **Do Not Immerse:** Never immerse the main unit in water or any other liquid.
6. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

Friggitrice ad aria

con contenitore di cottura in materiale antiaderente.



Image: The Melchioni Family Marianna New Air Fryer highlighting its non-stick cooking basket, which simplifies cleaning and prevents food from sticking.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in. Power outlet not working.	Ensure the power cord is securely plugged into a grounded outlet. Test the outlet with another appliance.
Food is not cooked evenly.	Basket is overfilled. Food not shaken/flipped.	Do not overfill the basket; cook in smaller batches if necessary. Shake or flip ingredients halfway through cooking.

Problem	Possible Cause	Solution
Food is not crispy.	Not enough oil (for some foods). Temperature too low or time too short.	Lightly brush or spray food with oil. Increase temperature or cooking time.
White smoke coming from the appliance.	Greasy food residue in the basket. Excess oil dripping onto the heating element.	Clean the basket thoroughly after each use. Avoid cooking excessively greasy foods. Remove excess oil from food before placing it in the basket.

7. SPECIFICATIONS

Model:	Marianna New 118340045
Brand:	Melchioni Family
Capacity:	5 Liters
Power:	1500 Watts
Voltage:	220-240V AC, 50Hz
Temperature Range:	80°C - 200°C
Timer:	1 - 60 minutes
Material:	Plastic (exterior), Non-stick (basket)
Dimensions (L x W x H):	Approx. 45 x 37.5 x 26 cm
Weight:	Approx. 4.2 kg
Special Features:	Transparent Viewing Window, Touch Display, 7 Preset Programs, Programmable

8. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact Melchioni Family customer support. For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact your retailer or the Melchioni Family customer service department. Keep your proof of purchase for warranty validation.

Contact Information: Please refer to the official Melchioni Family website or your product packaging for the most up-to-date contact details.

