



Manuals.plus /

- › OQIMAX /
- › OQIMAX Kids Alarm Clock WA175USKM Instruction Manual

OQIMAX WA175USKM

OQIMAX Kids Alarm Clock WA175USKM Instruction Manual

Model: WA175USKM | Brand: OQIMAX

INTRODUCTION

This manual provides detailed instructions for the OQIMAX Kids Alarm Clock, Model WA175USKM. This device is designed to assist children with sleep training, provide a comforting night light, and offer reliable dual alarm functions. Please read this manual thoroughly before use to ensure proper operation and maintenance.

SAFETY INFORMATION

- Ensure the device is plugged into a compatible power source (Type-C). An adapter is not included.
- Keep the device away from water or excessive moisture.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if issues arise.
- This product is intended for indoor use only.

PACKAGE CONTENTS

- OQIMAX Kids Alarm Clock (Model WA175USKM)
- Type-C USB Cable
- Instruction Manual

PRODUCT OVERVIEW

The OQIMAX Kids Alarm Clock features a friendly cat-shaped design with a digital display and intuitive controls. It combines multiple functions to support children's routines:

- **Sleep Training:** Visual cues (moon/sun icons, colored lights) guide children for bedtime and wake-up.
- **Night Light:** 11 vibrant colors and adjustable brightness levels create a soothing ambiance.

- **Music & Sounds:** 10 soothing melodies, nature sounds, or white noise options.
- **Dual Alarms:** Two independent alarms with customizable schedules and a snooze function.
- **Child Lock:** Prevents accidental changes to settings.

Color Change Soft Night Light

7 solid colors + 4 dynamic colors & 4 brightness



Press the top of the alarm clock to switch the night light color.

			
White	Red	Yellow	Green
			
Blue	Purple	Cyan	RGB Changing

Figure 1: Overview of the OQIMAX Kids Alarm Clock highlighting its main features.

SETUP

1. **Power Connection:** Connect the provided Type-C USB cable to the clock and plug it into a suitable USB power adapter (not included). The clock will power on automatically.
2. **Initial Time Setting:** The clock has a power-off memory function, but it's recommended to set the correct time upon first use or after extended power loss.

OPERATING INSTRUCTIONS

Button Functions

Familiarize yourself with the buttons located on the front of the alarm clock:




Figure 2: Button layout and functions for the OQIMAX Kids Alarm Clock.

- **TIME SET:** Short press to adjust time, long press to enter time setting mode.
- **SUN/MOON ON/OFF:** Short press to turn sun/moon icon on/off, long press to set appearance time of the moon.
- **TUNES:** Short press to select music (10 options), long press for 3 seconds to activate/deactivate child lock.
- **DISPLAY:** Adjust display brightness.
- **UP (U/P):** Increase value, adjust RGB brightness.
- **DOWN (D/WN):** Decrease value, adjust volume.
- **Top Surface:** Press the top of the clock to change night light colors or activate snooze.

Setting the Time

1. Long press the **TIME SET** button until the hour digits flash.
2. Use the **UP** or **DOWN** buttons to adjust the hour.
3. Press **TIME SET** again to move to minute adjustment, then use **UP** or **DOWN**.
4. Continue pressing **TIME SET** to cycle through year, month, day settings, adjusting each with **UP** or **DOWN**.
5. Press **TIME SET** one last time to confirm and exit.

Sleep Training Function

The sleep training feature uses visual cues to help children understand bedtime and wake-up times.

- **Bedtime (Moon Icon):** From 7 PM to 11 PM, a moon icon lights up, and the night light glows a gentle red, signaling it's time for bed. The red night light automatically turns off after 1 hour.
- **Wake-Up (Sun Icon):** 20 minutes before the set alarm time, a soft yellow light will appear. When the alarm rings, the light turns green, indicating it's time to wake up.

Time for Bed!



moon icon time period: 19:00-23:00

The moon icon is on, the ambient light is soft red, and it will automatically turn off after 1 hour



Figure 3: Bedtime mode with red light and moon icon.

Time to Get Up!

Sun icon time period: 7:00-18:59



Yellow light turn on 20 minutes before the alarm ring



Green light tell your child it is time to wake up

Figure 4: Wake-up mode with yellow light and sun icon.

Night Light Operation

The clock offers 11 vibrant light colors and 5 brightness levels for the display and nightlight.

- **Changing Colors:** Press the top surface of the alarm clock to cycle through the 11 light colors (7 solid colors + 4 dynamic colors).
- **Adjusting Brightness:** Use the **UP** or **DOWN** buttons to adjust the brightness of the night light. The display brightness can be adjusted using the **DISPLAY** button.

Press the Top of The Alarm Clock to Switch the Night Light Color

White	Red	Yellow	Green
Blue	Purple	Cyan	RGB Changing

Figure 5: Night light color options and how to change them.



Figure 6: Demonstrating 5 levels of screen brightness and automatic night brightness adjustment.

Music and Sound Selection

Choose from 10 soothing music melodies, nature sounds, or white noise options.

- **Selecting Tunes:** Short press the **TUNES** button to cycle through the 10 available melodies.
- **Adjusting Volume:** Use the **DOWN** button to adjust the volume level (4 levels available).

Your browser does not support the video tag.

Video 1: Demonstration of the OQIMAX Kids Alarm Clock's 11 colors night light and sound options.

Alarm Setup and Snooze

The clock supports two independent alarms with customizable schedules.

1. **Setting Alarms:** Use the dedicated Alarm 1 and Alarm 2 buttons (located on the back) to set individual alarm times and modes.
2. **Workday Modes:** Choose from four workday modes:
 - 1-1: Single day alarm
 - 1-5: Monday to Friday
 - 1-7: Monday to Sunday
 - 6-7: Saturday and Sunday
3. **Snooze Function:** When an alarm sounds, press the top surface of the clock to activate a 5-minute snooze.



Enjoy Tunes



Help Sleep

Best Gifts for everybody



Night Light



Wake UP

Figure 7: Dual alarm clock and snooze feature.

Child Lock

To prevent accidental changes to settings, activate the child lock.

- **Activate/Deactivate:** Hold both **TUNES** buttons for 3 seconds. When active, children can still enjoy music and lights without altering critical settings.

MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the device free from dust and debris to ensure optimal performance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock does not turn on.	Not properly plugged in or power adapter issue.	Ensure the Type-C cable is securely connected and the power adapter is working.
Alarm does not sound.	Alarm not set, volume too low, or child lock active.	Verify alarm settings, increase volume, and check child lock status.
Night light not changing colors.	Incorrect button press or child lock active.	Ensure you are pressing the top surface of the clock. Check if child lock is active.

SPECIFICATIONS

Feature	Detail
Product Dimensions	6.69 x 1.5 x 5.12 inches
Item Weight	8.1 ounces (0.23 Kilograms)
Model Number	WA175USKM
Brand	OQIMAX
Power Source	Type-C Plug-in (Adapter not included)
Night Light Colors	11 (7 solid, 4 dynamic)
Music Melodies	10 options
Display Brightness	5 levels
Volume Levels	4 levels

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact OQIMAX customer service directly. Keep your purchase receipt for any warranty claims.