

eufy T8026

eufy Video Doorbell Chime 2 Instruction Manual

Model: T8026

1. PRODUCT OVERVIEW

The eufy Video Doorbell Chime 2 (Model T8026) is designed to provide audible notifications for your eufy video doorbell. It features 10 built-in chime options, dual-band Wi-Fi connectivity (2.4 GHz and 5 GHz), and adjustable volume up to 80 dB. Its compact design allows for flexible placement within your home.




Image: Overview of the eufy Video Doorbell Chime 2 highlighting its features.

Key Features:

- **Wide Compatibility:** Works with most eufy video doorbells. Refer to the compatibility section for details.
- **Multiple Chime Options:** Includes 10 pre-installed tones.
- **Stable Dual-Band Connection:** Supports 2.4 GHz and 5 GHz Wi-Fi for reliable performance.
- **Quick and Easy Setup:** Features auto-discovery and Bluetooth auto-pairing.
- **Loud and Reliable Alerts:** Adjustable volume up to 80 dB.

2. SETUP GUIDE

Setting up your eufy Video Doorbell Chime 2 is a straightforward process. Follow these steps for quick installation:

1. **Plug into a Wall Outlet:** Insert the chime into a standard electrical wall outlet.
2. **Connect via the eufy App:** Open the eufy Security app on your smartphone. The app should automatically detect the new chime. If not, manually add the device. Ensure Bluetooth is enabled on your phone for auto-pairing.
3. **Enjoy Your Chime:** Once connected, you can customize settings such as chime tone and volume through the app.




Image: Visual guide for the three-step setup process: plug in, connect via app, and enjoy.

Video: Simple Setup Process

Your browser does not support the video tag.

Video: A user demonstrates the simple setup process of the eufy Video Doorbell Chime 2, plugging it in and connecting it.

3. OPERATING INSTRUCTIONS

Once your eufy Video Doorbell Chime 2 is set up, you can manage its functions through the eufy Security app.

Chime Options and Volume Adjustment:

- The chime comes with 10 distinct built-in tones. You can select your preferred tone from within the eufy Security app.
- The volume is adjustable up to 80 dB, ensuring you can hear notifications clearly throughout your home. Adjust the volume settings in the app to suit your environment.

Customizable Chime Options

Comes with 10 built-in tones so you can find the right sound for you.




Image: The eufy chime illustrating customizable chime options.

Loud and Adjustable

Adjustable up to 80 dB so it can be easily heard across floors.




Image: Diagram showing the eufy chime's loud and adjustable sound capabilities within a home.

Dual-Band Wi-Fi Connectivity:

The chime supports both 2.4 GHz and 5 GHz Wi-Fi networks, providing a stable and efficient connection to your eufy video doorbell system. This dual-band capability helps reduce network congestion and ensures smooth performance.

2.4/5 GHz Dual-Band Wi-Fi

Enjoy faster speeds and greater connectivity.



Image: Illustration of the eufy chime's 2.4/5 GHz dual-band Wi-Fi coverage within a home.

Video: Exploring Chime Sounds


Your browser does not support the video tag.

Video: A demonstration of the various chime sounds available on the eufy Video Doorbell Chime 2.

4. COMPATIBILITY

The eufy Video Doorbell Chime 2 is designed to work with a range of eufy video doorbells. Please refer to the table below for detailed compatibility information.

eufy Video Doorbell Chime 2 Compatibility



Product Name	PN	Pairing Method	Compatible?
Video Doorbell S4	T8215	HomeBase S380 / Router	✔ Yes
Video Doorbell E340	T8214	HomeBase 2 / HomeBase S380 / Router / MiniBase Chime (T8023)	✔ Yes
Video Doorbell S330	T8213	HomeBase 2 / HomeBase S380	✔ Yes
Video Doorbell C30	T8224	HomeBase 2 / HomeBase S380 / Router / MiniBase Chime (T8023)	✔ Yes
Video Doorbell C31	T8223	HomeBase 2 / HomeBase S380 / Router / MiniBase Chime (T8023)	✔ Yes
Battery Doorbell 1080p	T8220	HomeBase 2 / HomeBase S380	✔ Yes
		Wi-Fi Chime (T8020)	✘ No
Video Doorbell S220	T8210/ T8210C	HomeBase 2 / HomeBase S380	✔ Yes
		Wi-Fi Chime (T8020)	✘ No
Video Doorbell C210	T8222	HomeBase 2 / HomeBase S380	✔ Yes
		Wi-Fi Chime (T8020)	✘ No
Video Doorbell 2K (Wired)	T8200	Router	✘ No
Video Doorbell 1080p (Wired)	T8201	Router	✘ No
Video Doorbell 2K Pro (Wired)	T8202	Router	✘ No
Video Doorbell S330 (Wired)	T8203	Router	✘ No

Note: Only eufy Video Doorbell C30, C31, and E340 support connecting with Chime 2 on different networks. For all other models, the doorbell, chime and HomeBase must be on the same local Wi-Fi network to function properly.

Image: A table detailing the compatibility of the eufy Video Doorbell Chime 2 with different eufy doorbell models and their pairing methods.

Note: Only eufy Video Doorbell C30, C31, and E340 support connecting with Chime 2 on different networks. For all other models, the doorbell, chime, and HomeBase must be on the same local Wi-Fi network to function properly.

5. MAINTENANCE

The eufy Video Doorbell Chime 2 requires minimal maintenance to ensure optimal performance.

- **Cleaning:** Gently wipe the device with a soft, dry cloth to remove dust. Avoid using liquid cleaners or abrasive materials.
- **Placement:** Ensure the chime is plugged into a well-ventilated area, away from direct sunlight or extreme temperatures.
- **Software Updates:** Regularly check the eufy Security app for any available firmware updates to ensure your device has the latest features and security enhancements.

6. TROUBLESHOOTING

If you encounter issues with your eufy Video Doorbell Chime 2, try the following troubleshooting steps:

- **Chime Not Ringing:**
 - Check if the chime is properly plugged into a working power outlet.
 - Verify that the volume is not set to mute or a very low level in the eufy Security app.
 - Ensure the chime is correctly paired with your eufy video doorbell and that both devices are connected to the same Wi-Fi network (unless using compatible models C30, C31, E340 on different networks).

- **Connection Issues:**

- Restart the chime by unplugging it and plugging it back in.
- Check your Wi-Fi router to ensure it is functioning correctly and that the signal strength is adequate where the chime is located.
- Attempt to re-pair the chime with your eufy video doorbell through the eufy Security app.

- **App Not Detecting Chime:**

- Ensure Bluetooth is enabled on your smartphone during the setup process.
- Make sure the eufy Security app is updated to the latest version.

For further assistance, consult the eufy Security app's help section or visit the official eufy support website.

7. SPECIFICATIONS

Feature	Detail
Model Number	T8026
Manufacturer	eufy
Item Weight	4.6 ounces
Product Dimensions	6.65 x 2.76 x 1.67 inches
Color	White
Power Source	Corded Electric
Mounting Type	Wall Mount
Special Features	Motion Sensor (functionality depends on paired doorbell)
Included Components	Instruction Manual (this document)
Connectivity	2.4 GHz and 5 GHz Dual-Band Wi-Fi, Bluetooth Auto-Pairing
Volume	Up to 80 dB

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official eufy website or contact eufy customer service directly. Details regarding product registration, warranty claims, and technical assistance can typically be found in the eufy Security app or on the product packaging.

You may also find helpful resources and FAQs on the eufy support page www.eufylife.com/support