

ASTi LectroFan Micro2 Sleep Sound Machine and Bluetooth Speaker with Fan Sounds User Guide

Home » asti » ASTi LectroFan Micro2 Sleep Sound Machine and Bluetooth Speaker with Fan Sounds User Guide ₺



Contents

- 1 ASTi LectroFan Micro2 Sleep Sound Machine and Bluetooth Speaker with Fan Sounds
- **2 USER GUIDE**
- 3 Warranty and Licensing Information:
- **4 FCC Warnings**
- **5 IC WARNING**
- **6 Specifications**
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**

ASTi LectroFan Micro2 Sleep Sound Machine and Bluetooth Speaker with Fan Sounds



USER GUIDE




- 1. Microphone
- 2. Previous Track/Sound
- 3. Volume Down/Up
- 4. Play/Pause, Answer/Hang Up/Redial
- 5. Next Track/Sound
- 6. Indicator Lamp
- 7. Charging Port
- 8. Power Switch (left-right): Bluetooth, Off, Sleep Sounds



Off Charge Your Micro 2 Before First Use

Connect the Micro 2 to a USB power source using the supplied cable. The indicator lamp will glow red, then change to green when fully charged. A power adapter for any smartphone or a PC USB jack can be used to charge your Micro 2. Tip: to conserve battery power, always place the slider in the OFF position when not in use.





Sound Masking:

- 1. Slide switch to
- 2. Select sound



Warranty and Licensing Information:

astisupport.com

Bluetooth Audio:

Slide switch to the left

Select LectroFan MICRO 2 from your Bluetooth device. If it doesn't appear, make sure it is not connected to another phone and is within range.

Tip: Only one Bluetooth device can be connected at a time.

Answering Calls:

When your Micro 2 is connected to a smartphone, press to answer the call, and again to end the call. Double-press to redial the last dialed number.

FCC Warnings

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help. This equipment complies with FCC radiation exposure

limits set forth for an uncontrolled environment.

The device has been evaluated to meet general RF exposure requirements. The device can be used with a minimum distance 0mm between the radiator and your body.

IC WARNING

This radio transmitter has been approved by Industry Canada.

This Class B digital apparatus complies with Canadian standard ICES-003. This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions. This device may not cause interference.

This device must accept any interference, including interference? that may cause undesired operation of the device. This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirements. The device can be used with a minimum distance 0mm between the radiator and your body.

Specifications

- Power: 5V, 1A USB-A
- Audio Output: < = 3W
- Bluetooth Range: Up to 50 feet/15 meters Lithium-ion Battery Capacity: 1200 mAh Battery Run Time (at typical volumes):
- Bluetooth Audio: Up to 20 hours White Noise/Fan/Ocean Sounds: Up to 40 hours Battery Charge Time: 2 ½
 hours © 2018 Adaptive Sound Technologies, Inc. All Rights Reserved. LectroFan, LectroFan Micro 2, Adaptive
 Sound Technologies, the Sound of Sleep logo, and the ASTI logo are trademarks or registered trademarks of
 Adaptive Sound Technologies, Inc. All other marks, including Bluetooth®, are registered trademarks of their
 respective owners.
- astisupport.com

Documents / Resources



<u>ASTi LectroFan Micro2 Sleep Sound Machine and Bluetooth Speaker with Fan Sounds</u> [p df] User Guide

ASM1021A, 2AJGOASM1021A, LectroFan Micro2 Sleep Sound Machine and Bluetooth Speak er with Fan Sounds, LectroFan Micro2, Sleep Sound Machine and Bluetooth Speaker with Fan Sounds

References

Support – Sound of Sleep

Manuals+,